



Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for AYP 917.252580. You'll find the answers to all your questions on the AYP 917.252580 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual AYP 917.252580
User guide AYP 917.252580
Operating instructions AYP 917.252580
Instructions for use AYP 917.252580
Instruction manual AYP 917.252580

917.252580 (1999 & Before)
AIR INTAKE

Page 1 of 47

TRACTOR -- MODEL NUMBER 917.252580
KOHLER ENGINE - MODEL NUMBER CV15.5S, TYPE NUMBER PS41508



[You're reading an excerpt. Click here to read official AYP 917.252580 user guide](http://yourpdfguides.com/dref/437787)
<http://yourpdfguides.com/dref/437787>

Manual abstract:

HD.LH.CRFT. DECAL DECAL.PANEL.SIDE DECAL.SIDE.PANEL SUB= 918128314 SUB= 156439 DECAL T DECAL.BELT-V.SCHM CHASSIS DECAL DECAL SUB= 918145245 DECAL.

INS.HD.15.5 DECAL MWR QC SYS DECAL.INS.

STRG.WH DECAL.BATTERY DECAL BRAK PARK REFLECTOR-TAIL YT DECAL HANDLE LIFT FASTNER.POPIN.(8) MANUAL, OWNER'S (ENG) MANUAL, OWNER'S (SPAN) Page 14 of 47 917.

252580 (1999 & Before) DRIVE Page 15 of 47 917.252580 (1999 & Before) DRIVE Ref # 1 2 3 4 5 6 8 9 10 11 13 14 15 16 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 44 45 46 47 48 49 50 51 53 55 52 57 58 59 60 61 62 63 65 67 Part Number 145602 146682 123666X 12000028 121520X 17490512 141002 145028 STD561210 105701X 74550412 STD551125 74780544 73800500 73800600 71170768 106933X 130804 140475 STD541237 106888X STD551037 STD561210 145204 124236X 130807 127275X STD523107 72140506 122424X 120183X STD551062 STD571810 123674X STD523727 4470J 109070X 19131312 105706X 110812X 12000039 127783 123789X 123205X STD523715 STD541437 105710X 105709X STD541431 130801 127274X 140312 121218X 17490612 8883R 145868 STD551143 74760616 Qty Description SUB= 143794691 SPRING.BRAKE.RETU PULLEY TRANS SUB= 2267J STRAP TORQUE SCREW ROD SHIFT FEND YT CLUTCH.ELECT.EVX. PIN WASH-SHFT PLT LT BOLT.1/4-28.W/PAT WASHER BOLT HEX NUT NUT SUB= 150280 KNOB T (1/2-HOLE) BRAKE ROD SUB= 145411 NUT SPRING ROD LT WASHER PIN ROD.BRAKE.

PARK.LT CAP TRANSAXLE MTG BKT "KEEPER,BELT LH T" BOLT BOLT SUB= 149001 NYLON BEARING WASHER PIN, ROLL PULLEY.IDLER.FLAT BOLT SPACER T BELT KEEPER LT WASHER "LY, BEARING" WASHER LT KLIP RING SUB= 139245 ARM IDLER RETAIN BELT BOLT NUT "LINK, CLUTCH T" "SPRING, RETURN LT" NUT SUB= 138255 "KEEPER,BELT RH T" KEEPER BELT CNTSP KEEPER BELT ENGLH SCREW PEDAL COVER T PULLEY.CLUTCH.EVX WASHER BOLT Page 16 of 47 917.252580 (1999 & Before) DRIVE Ref# 68 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 96 100 110 112 113 114 Part Number 105730X 137057 121749X STD581075 123583X 121748X 2228M 145090 145092 123782X 19171216 145643 73530400 71208 19212016 12000008 139991 124346X 4497H 19111216 74760612 19091210 127285X 72110608 Qty Description "KEEPER,BLT ENG LT" SPACER AXLE WASHER E-RING SQUARE KEY WASHER SUB= 2228M1 "ARM.SHIFT.20""TIRE" SUB= 156049 "SPRING,TORSION" WASHER "ROD.TIE.

20""P930LT" NUT 1/4-28 BUSHING WASHER D KLIP RING CONSOLE SHIFT NUT RETAINER M WASHER M SUB= 74780612 WASHER LT "STRAP,TORQUE" BOLT D Page 17 of 47 917.252580 (1999 & Before) ELECTRICAL Page 18 of 47 917.252580 (1999 & Before) ELECTRICAL Ref # 1 2 3 4 6 7 8 9 10 11 12 19 20 21 22 24 25 26 28 29 30 31 32 33 36 38 39 40 41 42 43 44 45 46 50 55 70 80 Part Number 144926 74760412 STD551025 STD551125 STD541025 7697J 7603J 109596X 145211 145209 145769 STD551125 73350400 147430 4152J 4799J 146148 108824X 145491 121305X 140301 124211X 141226 109310X STD601005 140336 109553X 146059 71110412 131563 145673 73800400 121433X 141940 146283 17490508 142291 146685 Qty Description SUB= 123899X BOLT LT WASHER WASHER WASHER "DRAIN TU T, BATT" "TRAY T, BATTERY" HOSE CLAMP T SUB= 150177 SUB= 150109 SUB= 150177 WASHER NUT HARNESS.ASM.HDLIG HEADLAMP BULB "CABLE T, BATTERY" CABLE.

6GA.22W/16W FUSE HYT CABLE.GRND.6GA.21 SWITCH SEAT SWITCH IGN 4POS NUT IGNITION COVER KEY SWITCH KEY MOLDED T SCREW BRACKET SWITCH IN SWITCH INTERLOCKT SUB= 151215 BOLT.

HX.1/4-20 SUB= 154336 SUB= 146154 NUT SUB= 122822X PROTECTION LOOP SUB= 154963 SCREW LT HARNESS.ENG.KOHL HARNESS.CLUT.EVX. Page 19 of 47 917.252580 (1999 & Before) ENGINE Page 20 of 47 917.252580 (1999 & Before) ENGINE Ref # 1 2 3 4 10 14 15 16 23 24 29 31 32 33 34 35 36 37 38 39 40 41 62 77 79 80 81 Part Number 147025 17720410 140846 137350 145552 13280328 13200300 STD551231 128953 STD601005 137180 141069 123549X 123487X 106082X 17490512 19132012 8543R 109227X 3645J 139277 STD551131 STD551031 M740108025 STD523105 73510400 Qty Description SUB= 162156 SCREW LT ENG KOHLER MODEL NO. CV15S PS41508 MUFFLER.

LT.12.5 SHIELD.HEAT. @@@@ @@@@ ARM SUSP REAR RETAINER.SPRING WASHER KLIP RING NUT T WASHER SPRING T SUB= 3145 SUB= 532126971 NUT KNOB INF 3/8-16 TRUNION LT BEARING PVT LH NUT.CROWNLOCK.3/8 WASHER T POINTER HGT IND "PLUG,HOLE" SCREW WASHER HEIGHT INDICATOR Page 34 of 47 917.252580 (1999 & Before) O 67 68 69 70 71 72 72A 76 77 79 81 82 83 90 103 104 150 Part Number 780109 776135 776315A 786116 780051 786118 788069 792165 788091 780090 788078A 792144 786081 786082 786123 788067B 792166 792167 510334 Qty Description WASHER, THRUST SHAFT, INPUT SHAFT, BRAKE, 4 KEYED DISK WASHER THRUST SPACER SEAL SQUARE CUT THREADED PLUG 9/16-18 "O" RING WASHER, THRUST INVERTED RETAINING RING SPRING CHAIN, ROLLER SPROCKET 9T SPROCKET 18T (REV) GREASE BENTONITE, 32 OZ. @TUBE Page 47 of 47 .



[You're reading an excerpt. Click here to read official AYP 917.252580](http://yourpdfguides.com/dref/437787)

[user guide](http://yourpdfguides.com/dref/437787)

<http://yourpdfguides.com/dref/437787>