



# Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for AYP AY12536B. You'll find the answers to all your questions on the AYP AY12536B in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual AYP AY12536B**  
**User guide AYP AY12536B**  
**Operating instructions AYP AY12536B**  
**Instructions for use AYP AY12536B**  
**Instruction manual AYP AY12536B**

AY12536B (1999 & Before)  
BRAKE/REAR MOWER LIFT ASSEMBLY

Page 1 of 35

## TRACTOR -- MODEL NUMBER AY12536B BRAKE / REAR MOWER LIFT ASSEMBLY



NOTE: All component dimensions given in U.S. inches  
1 inch = 25.4 mm.



[You're reading an excerpt. Click here to read official AYP AY12536B user guide](#)

<http://yourpdfguides.com/dref/437981>

**Manual abstract:**

RETAINER LOCKNUT "LINK, MOWER REAR" LIFT ASM MOW REAR SUB= 72270506 NUT RETAINER.SPRING SUB= 73690600 Page 2 of 35  
AY12536B (1999 & Before) DANA TRANSAXLE Page 3 of 35 AY12536B (1999 & Before) DANA TRANSAXLE Ref# 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16  
17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 Part Number 142671  
2274J 134400 105904X 105905X 138235 134399 73810500 143045 142672 134793 143051 120415X 142674 138234 110078X 105909X 105910X 105911X  
142675 138246 138236 134791 142676 2244J 105916X 120470X 110070X 142677 120405X 108980X 134796 138239 106596X 105925X 2232J 108978X  
110079X 124639X 120472X 105928X 110084X 134394 120473X 142678 120407X 106589X 105937X 120523X 120951X 2226J 134401 2264J 120474X  
110081X 105941X 110071X 120952X Qty Description HOUSING UPPER TRN SUB= 74760412 SUB= 68003 "SPRING, DETENT LT" "SCREW, SET LT"  
KIT SHIFTER ASM SHIFTER BOOT NUT.LOCK.5/16-24 SEAL OIL DANA.5416 SUB= 2225J ASM KIT SHIM 4689 SUB= 148268 WASHER T KEY  
WOODRUFF-DANA AS KIT INPUT SHFT PINION 14T T "RING,RETAINING LT" "CHAIN,24 PTCH LT" BEARING.FLNG.5510 GEAR SPUR 14 TTH  
COLLAR CLUTCH ASM KIT CLTCH KEY SCREW TAP W/SEAL SHAFT INTERM DANA WOODRUFF KEY "RING,RETAINING LT" SPROCKET 18T T  
SPACER YT GEAR SPUR 37 TTH SUB= 124644X GEAR 25T LT SPUR GEAR 19T SPACER "SCREW, TAPPING LT" "WASHER, PLAIN LT" WASHER 025  
SPACER ASSM GEAR COMB SHAFT IDLER SPACER T SPROCKET 9T LT SUB= 167148 ASM KIT SHIM SHAFT T GEAR SPUR 12 TTH SUB= 124641X  
"GEAR, SPUR 25T LT" "GEAR, SPUR 31T LT" SPACER T PUCK T WASHER 060 NEOPRENE WASHER WASHER 031 SUB= 154658 GEAR 15T T  
"RING,RETAINING LT" SUB= 120478X SHAFT T Page 4 of 35 AY12536B (1999 & Before) DANA TRANSAXLE Ref# 59 60 61 62 63 64 65 66 67 68 69 70  
71 Part Number 110082X 120475X 142680 120961X 7294J 108989X 120953X 120954X 134799 138244 [68] 108996X 120956X 120416X Qty Description  
GEAR 1ST T SUB= 154659 HOUSING LOWER TNS PUCK T BRAKE DISC. T SPACER LT SUB= 918120953X PIN T TAP SCREW WASHER LT NLA  
SUB= 126976X Page 5 of 35 AY12536B (1999 & Before) DASH Page 6 of 35 AY12536B (1999 & Before) DASH Ref# 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16  
17 18 19 20 21 Part Number 141523 138392 123487X 8544R 8548R 73640400 2751R 19091216 74760428 19091413 121249X 3720R 126450X 126115X  
122023X 124346X 72110404 130745 134744 17060408 134014 Qty Description CAP BLK FUEL LR TANK.ASM.DASH.LR HOSE CLAMP SUB= 295J  
FUEL LINE T NUT HXKEP 1/4X20 CLIP T WASHER PM BOLT WASHER SPACER SPLIT SPRING M "KNOB,HGT RETAINER" KNOB ADJUSTER QUAD  
NUT BOLT SUPT ASSY DASH CROSS BRACE SCREW.  
1/4-20X1/2 PLUG DOME Page 7 of 35 AY12536B (1999 & Before) DECALS Page 8 of 35 AY12536B (1999 & Before) DECALS Ref# 1 3 4 5 7 8 9 10 12 13  
14 15 18 Part Number 145545 152195 152196 136830 145498 145494 152197 141517 146451 152198 125690X 272633 145437 138311 152633 153874  
CE36 MK36 Qty Description DECAL.OP.INST.SYM "DECAL,HOOD.RH" "DECAL,HOOD,LH" DECAL.  
V.BELT DECAL.READ.O.MANU DECAL.  
DANGER.CUTF "DECAL,FENDER" DECAL DECK WIZ + DECAL.BTRY.DANGER "DECAL,INSERT" DECAL DECAL, ENGINE DECAL.EURO.ST.CE.  
@@@SUB= 123888X LOCKNUT BRACKET LT SWITCH INTERLOCKT KEEPER.ACTUAT.LR.  
  
@@@SRTG. BEAR. AXLE ASM FRONT WASHER .T SPINDLE ASM RH WASHER COTTER PIN WASHER BUSHING.DRAGLINK TIE ROD  
SPINDLE ASM LH BOLT HEX 5/8-11 "NUT-LOC,FLANGE LT" BEARING ZERK M WASHER Page 17 of 35 AY12536B (1999 & Before) GROUND DRIVE  
Page 18 of 35 AY12536B (1999 & Before) GROUND DRIVE Ref# 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 Part Number 73680500  
74760512 141342 138029 10040700 71170744 124525X 123405X 72140612 123396X 150926 123674X 19131316 73930600 73680600 126471X 150932  
131459 73510500 139919 19111016 123404X 140916 17720408 150935 Qty Description SUB= 73690500 BOLT KEEPER RH PULLEY.ENGINE.LR  
LOCKWASHER HEX BOLT BELT "KEEPER,DRIVE BELT" BOLT "KEEP,IDLER DR BEL" ARM-IDLER.DR.GRND PULLEY.IDLER.  
FLAT WASHER LOCKNUT SUB= 73690600 "CLIP,INSULATOR" SPACER SUB= 532131459 NUT KEEPER.BELT.TA WASHER "KEEPER,FRA DR BEL"  
KEEPER MOWER LH SCREW BUSHING.NYLON Page 19 of 35 AY12536B (1999 & Before) HOOD Page 20 of 35 AY12536B (1999 & Before) HOOD Ref#  
1 2 3 4 5 6 7 8 9 10 11 12 13 14 18 19 Part Number 124657X 73640400 19091416 74780412 139888 122549X 122548X 17521312 73800400 123693X  
132918X550 122035X 127029X 2751R 19111116 11030400 Qty Description EXT SPRING NUT HXKEP 1/4X20 WASHER SUB= 74780414 BOLT.SHLD.  
5/16-18 BRKT HOOD RH BRKT HOOD LH SCREW SLTD HXHD NUT "BRACE,HOOD" HOOD.IMPREG.MS550 LENS GRILL CLIP T WASHER  
LOCKWASHER GT Page 21 of 35 AY12536B (1999 & Before) MOWER DECK Page 22 of 35 AY12536B (1999 & Before) MOWER DECK Ref# 1 2 3 4 5 6 7  
8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 Part Number 140064  
122052X 73680600 130840 131251 121316X 72110616 19131410 127744 72140610 130841 127356 72140506 73680500 127357 140609 128508 128511  
127380 138496 140296 10030600 850857 140329 138776 129963 129983 129207 137266 136631 17490508 122051X 139083 121980X 123713X 105304X  
19111016 110452X 131264 19171616 3146R 140608 110485X 128774 129895 137645 133943 71161010 136383 19070718 60867 130794 144973 Qty  
Description SPRING CLUTCH MWR SPACER RETAINER SUB= 73690600 BRAKE ASM IDLER BELT GUIDE PULLEY IDLER BOLT WASHER SUB=  
140092 BOLT.3/8-14X1.25 BRAKE ROD "BRKT,LIFT REAR" BOLT SUB= 73690500 "BRKT,LIFT REAR LH" SUB= 153298 MOWER LINK STAB  
"PIN,GROOVE" "BRKT,LINK STABILI" "BLADE.  
36"" HIPERF" WASHER.HARD.BLADE SUB= 10040600 BLADE BOLT STRIPPER RND MWR SUB= 157722 WASHER SUB= 156600 SUB= 153531  
SUB= 139729 SUB= 532136631 SCREW LT "SUPT,IDLER ARM" SHIELD.DEFL.36TUV HINGE ROD SPRING TORSION CAP-SLEEVE LT WASHER  
NUT PUSH M V-BELT.PRIM.78.5. @@TUBE Page 33 of 35 AY12536B (1999 & Before) TRANSAXLE Page 34 of 35 AY12536B (1999 & Before)  
TRANSAXLE Ref# 1 2 3 4 5 6 7 8 9 10 11 12 15 16 17 18 19 20 21 22 23 24 25 26 28 29 31 33 35 36 Part Number 123.



[You're reading an excerpt. Click here to read official AYP AY12536B](http://yourpdfguides.com/dref/437981)

[user guide](http://yourpdfguides.com/dref/437981)

<http://yourpdfguides.com/dref/437981>