



Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for AYP HD14542B. You'll find the answers to all your questions on the AYP HD14542B in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual AYP HD14542B
User guide AYP HD14542B
Operating instructions AYP HD14542B
Instructions for use AYP HD14542B
Instruction manual AYP HD14542B

HD14542B (1999)
CHASSIS AND ENCLOSURES

Page 1 of 24

TRACTOR - - MODEL NUMBER HD14542B
CHASSIS AND ENCLOSURES



[You're reading an excerpt. Click here to read official AYP HD14542B user guide](#)

<http://yourpdfguides.com/dref/438975>

Manual abstract:

STAMPING SUB= 145009 SCREW WASHER BUMPER-HOOD/DASH SADDLE CLIP.RETAINER DASH SILKSCREEN SUB= 72110608 "PANEL-DASH,LH" CLIP.TINNERMAN SUB= 169117X010 SCREW LT SCREW NUT "HOOD W/TRIM,MS428" SUB= 532126938 "PLATE-MTG,BATT/FU" SUB= 532124028 BOLT WASHER NUT GRILLE-MS428 LENS.GRILLE.PRIVATE LABEL FENDER ASM BRKT FENDER FOOTREST LH FOOTREST RH BOLT SCREW LT BRACKET ASM LH BRACKET ASM RH NUT WASHER BRACKET.GRILLE.LH SCREW.HEX.WS.HD BRACKET.

GRILLE.RH SUB= 74780414 AIR DUCT BRKT SUSPENSION "ROD POVOT,CHASSIS" PLUG BUTTON T Page 2 of 24 HD14542B (1999) DECALS/ACCESSORIES Page 3 of 24 HD14542B (1999) DECALS/ACCESSORIES Ref# 1 2 3 4 5 7 8 9 10 11 16 17 19 20 Part Number 158271 158168 167374 167375 166265 158166 157141 141897 165352 160396 158169 145005 166221 167376 138311 168191 168192 LBD48 LSB42 LC05 C42 LAO18 MK420 Qty Description DECAL OPER "DECAL WHEEL,STEER" DECAL HOOD RH DECAL HOOD LH DECAL.FENDER.SD.LAWN "DECAL FENDER,LOGO" "DECAL FENDER,DANG" DECAL CLUT/BRAKE DECAL. ENGINE "DECAL-SCHEM,BELT" "DECAL DECK,MULCH" DECAL.BATRY.3-3908 DECAL.REPLACEMENT.ENG DECAL DASH PNL DECAL HANDLE LIFT MANUAL.

O.HD14542B.E MANUAL.O.HD14542B.S SNOW BLADE SNOW THROWER WHEEL WTS. GRASS CATCHER TIRE CHAINS MULCHING KIT W/BLADES Page 4 of 24 HD14542B (1999) DRIVE Page 5 of 24 HD14542B (1999) DRIVE Ref# 1 1 2 3 4 5 6 8 10 11 13 14 18 19 21 22 24 25 26 27 28 29 30 32 34 35 36 37 38 39 40 41 42 47 48 49 50 51 52 53 55 56 57 59 61 62 63 64 65 66 70 72 74 75 76 77 78 79 Part Number PARTSIMAGE SUPPLIER 146682 123666X 12000028 121520X 17490512 165619 76020416 105701X 74550412 10040400 74780616 73800600 106933X 130804 73350600 106888X 19131316 76020412 145204 71673 130807 74760512 155071 120183X 19211616 1572H 131494 74760644 4470J 165838 19131312 127783 154407 123205X 74760624 73680600 73680500 105710X 105709X 74760620 130801 140312 17490612 8883R 140186 71170764 10040700 154778 134683 19132012 137057 121749X 12000001 123583X 121748X 2228M Qty Description REFER TO PARTS IMAGE CHECK WITH SUPPLIER SPRING.BRAKE.RETU PULLEY TRANS SUB= 2267J STRAP TORQUE SCREW ROD.SHIFT.

FENDER.ADJ.LT.CRD PIN COTTER 1/8 WASH-SHFT PLT LT BOLT.1/4-28.W/PAT LOCKWASHER BOLT NUT KNOB T (1/2-HOLE) BRAKE ROD NUT SPRING ROD LT WASHER COTTER PIN ROD.BRAKE.PARK.LT PLUNGER CAP T TRANSAXLE MTG BKT BOLT SHAFT ASM-PEDAL F NYLON BEARING WASHER LT SUB= 2882J FLAT IDLER PULLEY BOLT SPACER T "KEEPER,BELT.IDLER FLAT" WASHER SUB= 139245 BELLCRANK. CLUTCH RETAIN BELT SUB= 74930624 SUB= 73690600 SUB= 73690500 "LINK, CLUTCH T" "SPRING, RETURN LT" SUB= 74780620 SUB= 138255 KEEPER BELT CNTSP SCREW PEDAL COVER T PULLEY.ENGINE BOLT LOCKWASHER KEEPER-BELT KEEPER BELT ENG WASHER SPACER AXLE WASHER E-RING LT SQUARE KEY WASHER SUB= 2228M1 Page 6 of 24 HD14542B (1999) DRIVE Ref# 81 82 83 84 85 88 89 90 96 112 113 116 145 150 151 156 158 159 160 161 162 163 164 165 166 168 169 170 171 Part Number 165594 123782X 19171216 166228 150360 12000008 139964X428 124346X 4497H 19091210 127285X 72110610 74490540 165850 19133210 166002 165589 165494 19292016 72140406 73680400 74780416 19091010 165623 166880 165492 165581 165849 17490608 Qty Description SHAFT.ASM.CROSS "SPRING,TORSION" WASHER LINK.TRANSAXLE NUT. CNT.LOCK.1/4 KLIP RING CONSOLE.SHIFT.SLT NUT RETAINER M WASHER LT "STRAP,TORQUE" BOLT RDHD 3/8-16 BOLT. HEX.FLGH D BUSHING.BELLCRANK.GRD.DR WASHER WASHER.SRRTD.5/16 BRKT.SHIFT.MOUNT HUB.SHIFT WASHER BOLT T SUB= 73690400 NLA WASHER.

5/8X.281X10GA BRKT.PIVOT.LEVER SCREW.5/16-18X5/8 BOLT.SHOULDER.5/16-18X.561 PLATE.FASTENING KEEPER.BELT. TRANSAXLE SCREW LT Page 7 of 24 HD14542B (1999) ELECTRICAL Page 8 of 24 HD14542B (1999) ELECTRICAL Ref# Part Number REFER 1 144925 2 74760412 8 156417 16 153664 19 10090400 20 73350400 21 166181 22 4152J 24 4799J 25 146147 26 166180 27 73510400 28 4207J 29 121305X 30 140301 31 124211X 32 141226 33 122147X 40 166145 41 71110408 42 131563 43 145673 44 73640400 48 140844 52 141940 70 166659 Qty Description REFER TO IMAGE SUB= 123899X BOLT LT "CASE,BATTERY.MECH" SWITCH INTERLOCK SUB= 10040400 NUT HARNESS.ASM.LIGHT W/4152J HEADLAMP BULB "CABLE T, BATTERY" CABLE.BTRY. 6GA.RD FUSE.15 AMP NUT CABLE T SWITCH SEAT SWITCH IGN 4POS NUT IGNITION COVER KEY SWITCH KEY HARNESS.IGNITION BOLT HXHD FIN SUB= 154336 SUB= 146154 NUT HXKEP 1/4X20 ADAPTER AMMETER PROTECTION LOOP HARNESS.ENGINE. B&S Page 9 of 24 HD14542B (1999) ENGINE Page 10 of 24 HD14542B (1999) ENGINE Ref# 1 2 3 3 4 13 14 15 16 23 29 31 32 33 35 37 38 38 40 44 46 62 72 78 81 Part Number 140310 17720410 PARTSIMAGE SUPPLIER 137352 165291 13280324 13200300 11050600 159880 137180 161911 140527 123487X 17490512 137040 PARTSIMAGE SUPPLIER 124028X 17490412 19091416 10040500 71070512 17490620 128861 Qty Description CONTROL THROTTLE SCREW LT REFER TO PARTS IMAGE CHECK WITH SUPPLIER MUFFLER SUB= 272293 PIPE NIPPLE ELBOW LOCKWASHER SHIELD.BRN/DBR.GD SUB= 532137180 TANK.FUEL.FRONT. @@BRACKET.GWHL.RH. @@@@SRTG. BEAR.

@@TUBE Page 24 of 24.



[You're reading an excerpt. Click here to read official AYP HD14542B user guide](http://yourpdfguides.com/dref/438975)
<http://yourpdfguides.com/dref/438975>