



Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for AYP TMH1450H. You'll find the answers to all your questions on the AYP TMH1450H in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual AYP TMH1450H
User guide AYP TMH1450H
Operating instructions AYP TMH1450H
Instructions for use AYP TMH1450H
Instruction manual AYP TMH1450H

TMH1450H (1999 & Before)
BAGGER

Page 1 of 24

TRACTOR- -MODEL NO. TMH1450H (EN145RBHA)
BAGGER



[You're reading an excerpt. Click here to read official AYP
TMH1450H user guide
http://yourpdfguides.com/dref/440564](http://yourpdfguides.com/dref/440564)

Manual abstract:

HEAD" SCREW NUT.WIZ.LOCK COVER.BAG.CRD BOLT CARRIAGE SUPT.ASM.WLDMNT.BAG.CRD BRKT.SUPT.
UPPER.BAG.CRD BRKT.PIVOT.BAG.

LH.CRD BOLT BOLT.HEX.3/8-16X2-1/2 SUB= 83923 BOLT WASHER NUT "BRKT.PIVOT.
BAG,RH.CRD" BAG.ASM.CRD BRKT.SIDE.BAG.CRD TUBE.UPPER.BAG.CRD TUBE.

PIVOT.BAG.CRD TUBE.FT.BAG.CRD TUBE.LOWER.BAG.CRD. GROMMET.
EXTRUDED GRIP.HANDLE.BLACK PLATE.STOP.BAG.
HDLE.CRD BOLT.CARRIAGE RETAINER M RIVET.DRILL.1.

75 Page 2 of 24 TMH1450H (1999 & Before) CHASSIS AND ENCLOSURES Page 3 of 24 TMH1450H (1999 & Before) CHASSIS AND ENCLOSURES Ref#
1 2 3 4 5 6 8 9 10 11 12 13 14 15 16 17 18 24 25 26 28 29 30 31 33 34 35 37 38 39 51 52 53 54 55 57 58 102 140 145 162 163 164 165 167 168 169 170 171
172 173 174 175 176 177 178 179 180 Part Number 165480 165606 17490612 19131216 155272 155923 126471X 147631X011 72140608 155927 145660
169117X010 17490608 74180512 73510500 159639X520 126938X 74780616 19131312 73800600 157373 140273X599 165713X520 165156 145244X520
145243X520 72110606 17490508 139886 139887 73800400 19091416 144697 161464 144696 74780412 150127 2751R 158418 156524 165672 165673
165605 165742X428 165779 72050412 123976X 165607 74520640 19132016 73510600 165939 166212 128600 132796 76020312 165942 74760516 Qty
Description CHASSIS.STAMPING DRAWBAR.CRD SCREW WASHER BUMPER-HOOD/DASH SADDLE "CLIP,INSULATOR" DASH.SILKSCREEN SUB=
72110608 "PANEL-DASH,LH" CLIP.TINNERMAN PANEL.ASM.SLKSCR.DASH.RH SCREW LT SCREW NUT HOOD.STEEL.

ASSY SUB= 532126938 BOLT WASHER NUT GRILLE-MS428 LENS.GRILLE.PRIVATE LABEL FENDER BRKT.SUPT.FENDER.CRD FOOTREST PNT LH
FOOTREST.RH.LT/GT BOLT SCREW LT BRACKET ASM LH BRACKET ASM RH NUT WASHER BRACKET.GRILLE.LH SCREW.
HEX.WS.HD BRACKET.GRILLE.RH SUB= 74780414 AIR DUCT CLIP T BRKT SUSPENSION "ROD POVOT,CHASSIS" BRKT.
EXT.CHASSIS.LH.CRD BRKT.EXT.
CHASSIS.RH.CRD SUPPORT.BATTERY.CRD COVER.BATTERY.CRD.BLACK.LT SUPT.ASM.

BACKPLATE BOLT-RD HD SQ NK SUB= 73900400 COVER.BACKPLATE.BLACK BOLT.HEX.3/8-16X2-1/2 SUB= 19132012 NUT
BRKT.SWITCH.FBI.CRD GRUARD.DOOR.REAR.

CRD HINGE PIN SPRING.COVER.LH SUB= 3145 ROD.PIVOT.FBI.

CRD SUB= 77394 Page 4 of 24 TMH1450H (1999 & Before) CHASSIS AND ENCLOSURES Ref# 181 182 183 184 185 186 187 188 189 190 192 193 194
Part Number 73680500 138200 19131316 166139 165940 160793 2029J 19061216 10071000 71161010 17490624 17720410 17060612 5479J Qty

Description SUB= 73690500 WASHER.385X.625 WASHER BRKT.ACTUATOR.BAG.

CRD TUBE.LEVER.SWCH.FBI.CRD LATCH ASSY.BAGGER WELDNUT WASHER #10 LOCKWASHER SCREW SCREW LT SCREW LT SCREW PLUG
BUTTON T Page 5 of 24 TMH1450H (1999 & Before) DECALS Page 6 of 24 TMH1450H (1999 & Before) DECALS Ref# 1 2 3 6 8 9 10 11 12 13 14 15 16
17 19 20 21 22 Part Number 145498 165352 168873 126187X 145437 151634 145005 145494 159737 166959 159736 166961 162598 140837 166962
166960 166286 151635 138311 133671 168926 168927 Qty Description DECAL.READ.O.MANU DECAL.ENGINE DECAL SUB= 532126187 DECAL.

EURO.ST.CE. @@@@RELAY ASSY T Page 12 of 24 TMH1450H (1999 & Before) ENGINE Page 13 of 24 TMH1450H (1999 & Before) ENGINE
Ref# 1 2 3 4 13 14 15 16 23 29 31 32 33 35 37 38 44 46 62 66 72 78 81 Part Number 141359 17720410 SUPPLIER 137352 165291 13280324 13200300
11050600 159880 137180 109202X 140527 123487X 17490512 137040 SUPPLIER 17490412 19091416 10040500 127951 71070512 17490620 128861 Qty
Description CONTROL.THTL.23.5 SCREW LT CHECK WITH SUPPLIER MUFFLER SUB= 272293 PIPE NIPPLE ELBOW LOCKWASHER

SHIELD.BRN/DBR.GD SUB= 532137180 TANK.FUEL.

LT. @SUB= 72270506 CHUTE.BAGGER.CRD MANDREL ASM MANDREL.ASM.

CRD.LH.THREADS DECK.MOWER.COMPLETE Page 16 of 24 TMH1450H (1999 & Before) MOWER LIFT Page 17 of 24 TMH1450H (1999 & Before)
MOWER LIFT Ref# 1 2 3 4 5 6 7 8 11 12 13 15 16 17 18 19 20 31 32 Part Number 159460 159471 105767X 12000002 19211621 120183X 109413X

124526X 165829 165831 4939M 127218 73350800 130171 73680800 139868 163552 140302 73540600 Qty Description WIRE ASM W.

SPRING "SHAFT ASM LIFT,RH" PIN-GROOVE LT SUB= 2225J WASHER NYLON BEARING GRIP SUB= 125925X LINK.LIFT.LH.CRD

LINK.LIFT.RH.CRD SUB= 85902 LINK.FRONT NUT TRUNION NUT LTV ARM SUSP REAR RETAINER SPRING BEARING PVT LH

NUT.CROWNLOCK.3/8 Page 18 of 24 TMH1450H (1999 & Before) SEAT ASSEMBLY Page 19 of 24 TMH1450H (1999 & Before) SEAT ASSEMBLY Ref# 1
2 5 7 8 9 10 12 13 14 15 16 17 21 22 23 24 25 26 Part Number 127426X 140551 145006 124181X 17490616 19131614 155925 121246X 121248X 72050412
134300 121250X 123976X 153236 73800500 74780814 19171912 127018X 10040800 Qty Description SUB= 140119 BRACKET PVT SEAT CLIP.

PUSH-IN.HING SPRING COMPRESSIO SCREW GTV WASHER PAN-SEAT BRKT SWITCH BUSHING BOLT-RD HD SQ NK SPLIT SPACER SPRING
SUB= 73900400 "BOLT,SHOULDER" NUT BOLT WASHER "BOLT,SHOULDER" LOCKWASHER Page 20 of 24 TMH1450H (1999 & Before) STEERING
ASSEMBLY Page 21 of 24 TMH1450H (1999 & Before) STEERING ASSEMBLY Ref# 1 2 3 4 5 6 7 8 10 11 13 15 17 18 19 22 23 25 27 29 32 36 37 38 39 40
41 42 43 44 46 47 51 54 62 63 65 66 67 68 74 75 76 77 78 79 80 Part Number 133741 137094 157479 157478 6266H 121748X 19272016 12000029 154432
10040600 167118 73901000 156546 57079 160395 165857 165851 154406 136874 17490612 137347 155099 152927 133742 19133808 7810H 100711L
145054 121749X 153720 121232X 6855M 73800500 74780520 167902 74780616 154780 154404 74781044 154429 109850X 109851X 137156 73700600
73360600 19132012 74950612 Qty Description SUB= 150547 SUB= 532137094 "SPINDLE ASM,LH" "SPINDLE ASM,RH" WASHER .T WASHER
WASHER RING LINK.DRAG LOCKWASHER BEARING.FRT.SPACER.AXLE "NUT-LOC,FLANGE LT" SHAFT ASM STEERIN THRUST WASHER
SUPPORT.SHAFT.STEER SCREW.HX.

WSH.HD SHAFT.ASM.PITMAN BRKT-STEERING GEAR SECTOR SCREW ROD.ASM.

TIE.BALL BUSHING.STEERING "SCREW-TT,10-32 FL" ST WHL INSERT CAP WASHER T GRIPCO NUT ADAPTER LT BOOT.STEER.PL WASHER EXT
SHAFT STEERIN CAP ZERK M NUT BOLT KIT.

STEER.ASM BOLT SPACER AXLE "BEARING-ARM,PITMA" BOLT BRACE AXLE JOINT.RH JOINT.LH SUB= 137347 NUT NUT WASHER
BOLT.HX.NYLON3/8-16X3/ Page 22 of 24 TMH1450H (1999 & Before) WHEELS AND TIRES Page 23 of 24 TMH1450H (1999 & Before) WHEELS AND
TIRES Ref# 1 2 3 4 5 6 7 8 9 10 11 Part Number 59192 65139 106222X 59904 106732X421 278H 9040H 106108X421 138468 7152J 104757X 144334 Qty
Description VALVE CAP VALVE STEM LT SUB= 122073X TUBE.5.3/4.5/6 RIM..



[You're reading an excerpt. Click here to read official AYP
TMH1450H user guide
http://yourpdfguides.com/dref/440564](http://yourpdfguides.com/dref/440564)