



# Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for AYP YP5HY22CB. You'll find the answers to all your questions on the AYP YP5HY22CB in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual AYP YP5HY22CB**  
**User guide AYP YP5HY22CB**  
**Operating instructions AYP YP5HY22CB**  
**Instructions for use AYP YP5HY22CB**  
**Instruction manual AYP YP5HY22CB**

YP5HY22CB (1998)  
GEAR CASE

Page 1 of 7

**POWER PROPELLED LAWN MOWER - - MODEL NO. YP5HY22CB**  
**GEAR CASE ASSEMBLY PART NUMBER 702511**



[You're reading an excerpt. Click here to read official AYP YP5HY22CB user guide](http://yourpdfguides.com/dref/441406)  
<http://yourpdfguides.com/dref/441406>

*Manual abstract:*

1/4-20 BRACKET.GEARCASE SHIFTER SEAL KIT GEARCASE HALV BEARING SHAFT.WORM SHAFT.DRIVE THRUST WASHER CLUTCH YOKE  
BUSHING.GEAR BOX PLUG PM GEAR.HELICAL CLUTCH JAW SUB= 6066J RING T HI PRO KEY SPRING BRKT Page 2 of 7 YP5HY22CB (1998)  
ROTARY LAWN MOWER Page 3 of 7 YP5HY22CB (1998) ROTARY LAWN MOWER Ref# 1 3 4 5 6 7 8 9 11 12 14 15 16 17 18 19 20 21 22 23 24 26 27 28  
29 30 31 32 33 34 35 37 39 40 41 44 45 46 47 48 49 50 51 52 53 55 56 57 58 59 60 61 62 64 65 69 70 71 Part Number 164283 144929 63601 66426 136376  
63601 145794 147615 150050 54583 156378X479 700365X479 133190X479 133040X479 164265 147738 140540 163340 84596 87677 128415 700326X004  
146247 142748 62335 145935X004 87877 700331X004 145285 146630 700327X007 150078 701923X479 701921X479 146653 163010 83923 144229X004  
141114 851074 850263 851084 144964 107339X 851671 751592 88652 51793 151721X479 131959 851201X004 132001 134612 77400 133170X479  
148353 67510 Qty Description SUB= 164286 SCREW.HXHD.WASH. SUB= 73800400 SUB= 7192J KNOB HANDLE SUB= 73800400 BAIL.CNTRL.  
DLX. @@BOLT SHLD 3/8-16 "WASHER, BELLEVIL." ARM.AXLE.ASM.  
BZP. @@@@PAN HEAD SCREW SUB= 157769 SPRING.RETAINER. HUB CAP BUSHING.HEX WHEEL.  
8X2.LP.PR E-RING.7/16.RE. @@@@SUB= 48367 SPRING.TENSION SUB= 73800400 SPRING WHEEL.ADJ.ASM.RH.



[You're reading an excerpt. Click here to read official AYP  
YP5HY22CB user guide  
<http://yourpdfguides.com/dref/441406>](#)