



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT BT DRIVE FREE 111. You'll find the answers to all your questions on the BLAUPUNKT BT DRIVE FREE 111 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BLAUPUNKT BT DRIVE FREE 111**  
**User guide BLAUPUNKT BT DRIVE FREE 111**  
**Operating instructions BLAUPUNKT BT DRIVE FREE 111**  
**Instructions for use BLAUPUNKT BT DRIVE FREE 111**  
**Instruction manual BLAUPUNKT BT DRIVE FREE 111**



[You're reading an excerpt. Click here to read official BLAUPUNKT BT DRIVE FREE 111 user guide](http://yourpdfguides.com/dref/3349778)  
<http://yourpdfguides.com/dref/3349778>

**Manual abstract:**

Carefully read the operating instructions and follow the instructions. 2. To avoid any damages, do not drop the device from an elevated height. 3. Protect the device against humidity, water and other liquids. If it cannot be avoided, do not use the device until it is completely dry; otherwise, it may result in injuries or lead to short circuits and damages that can no longer be repaired. 4. Do not expose the device to extreme heat or direct sunlight (this may lead to damages that cannot be repaired). 5. Do not attempt to open the device or perform any modifications.

Do not place any heavy objects on the device. Repairs may be performed only by the manufacturer. 9. @@@@This device can be used as conference or office equipment as well as in the car. Technology for echo and noise reduction, it achieves an excellent voice communication quality. 48 GHz), the Bluetooth transmission operates 1,600 times per second between 79 separate frequencies with a data transmission range of approx. Follow the following steps for simple operation: Â Completely charge the BT Drive Free 111 before using it for the first time. Â For the pairing (connecting with the cell phone), both devices should be located within one metre of each other (the closer, the better). Â When using the BT Drive Free 111, the cell phone must be located within approx. The device is operated with a battery that is identical with Nokia BL-5B.

3 seconds until you hear a short sound. 3 seconds until you hear a long sound. IMPORTANT: After every switch-on, briefly press the MFB button again to establish the connection. Before making a phone call, ensure that the headphone icon on the display of your cell phone is displayed, otherwise proceed as follows: Â On the cell phone: In the Bluetooth menu, select "Paired devices", followed by "BT Speaker" or "BT Drive Free 111". â On the BT Drive Free 111: Briefly press the MFB button and confirm (accept) it on your cell phone. IMPORTANT: Always perform this brief activation if the headphone icon is not shown (e. g. After extended switch-off of one of the devices or if you were outside the range). @@The following steps explain the general procedure for pairing. @@6 seconds until you hear a long sound.

the LED starts to alternately flash red and blue. @@@@ ) Â Select "BT DF 111" from the displayed list. @@@@ 3 seconds. @@ (Note: The PIN code is preprogrammed and cannot be changed). @@The shorter the distance, the better the connection. @@In this case, start the pairing from the beginning. @@@@After 10 minutes, the BT Drive Free 111 completely switches off. @@@@3 seconds until you hear a short sound. @@@@@@@Â Press the two volume buttons again at the same time for approx. 2 seconds until two short sounds are emitted and the LED stops flashing.

The BT Drive Free 111 switches off and the factory settings are restored. Â After resetting the device and switching it on again, the red LED flashes every 3 seconds and 3 sounds are emitted every minute. This is normal and ends again with the next pairing. KG declares that this product complies with the basic requirements and the other relevant regulations of the directive 1999/5/EC. The declaration of conformity can be found on the Internet under www.

For devices purchased outside the European Union, the warranty terms issued by our respective responsible domestic agency are valid. The warranty terms can be called up from www. If a connection between BT Drive Free 111 and cell phone cannot be established, try the following first: Â Check whether the devices are connected (paired). â Ensure that the Bluetooth function is activated on your cell phone. Â Check whether the distance between the devices is less than 10 m or whether walls or other electronic devices are located between them.

If necessary, shorten this distance. Â Should none of these steps be successful, remove the battery from the BT Drive Free 111 for approx. 2 minutes. @@@@@@@Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Caution: (pertaining to FCC part 15. 21) Modifications not expressly approved by this company could void the user's authority to operate the equipment. .



**[You're reading an excerpt. Click here to read official BLAUPUNKT BT DRIVE FREE 111 user guide](http://yourpdfguides.com/dref/3349778)**  
**<http://yourpdfguides.com/dref/3349778>**