



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT BT DRIVE FREE 211. You'll find the answers to all your questions on the BLAUPUNKT BT DRIVE FREE 211 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BLAUPUNKT BT DRIVE FREE 211**  
**User guide BLAUPUNKT BT DRIVE FREE 211**  
**Operating instructions BLAUPUNKT BT DRIVE FREE 211**  
**Instructions for use BLAUPUNKT BT DRIVE FREE 211**  
**Instruction manual BLAUPUNKT BT DRIVE FREE 211**



[You're reading an excerpt. Click here to read official BLAUPUNKT BT DRIVE FREE 211 user guide](http://yourpdfguides.com/dref/3865156)  
<http://yourpdfguides.com/dref/3865156>

**Manual abstract:**

*blaupunkt.com Contents BT Drive Free 211 Bluetooth Car Kit.....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*. 16 Bluetooth technology...*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 16 Safety and general information ...*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*.... 17 Disposal notes .*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*.... 17 Scope of delivery .*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*... 18 Use headset separately .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 18 Overview ...*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*.. 19 Inserting the battery ...*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
.....

*20 Installation at the sun visor.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*. 20 Charging the battery.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*.... @@@@ @@@@ 24 Troubleshooting .*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*..... 25 Light indicators and signal sounds .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*. 26 Declaration of conformity .....*



shock or explosion. 4.

Do not expose the device to extreme heat sources, such as direct sunlight. This can cause explosions as well as reduce the performance and/or service life of the battery. 5. Do not make any changes or repairs to the device and do not attempt to disassemble it. (Particularly not on the battery since the risk of explosion exists.

) It will immediately void the warranty. 6. Do not place any heavy objects on the device. 7. Use only the supplied charger. 8. Repairs and service work may be performed only by a qualified service centre or the manufacturer. 9. In case of extended non-use or thunderstorms, disconnect the device from the power supply. Disposal notes Use the return and collection systems available to dispose of the old device.

@@@The complete charging of the headset takes approx. 1 hour. @@An existing connection to a cell phone is disconnected. @@@the complete charging of the docking station takes approx. 3 hours. @@Important: Switching the charging switch on switches the headset off. An existing connection to a cell phone is disconnected. The headset cannot be used during the charging process.

@@@The lithium-ion-polymer battery of the headset cannot be replaced. @@The full performance of a new battery is not achieved until after two or three complete charging-discharging cycles.

The battery can be charged and discharged several hundred times, but it loses its capacity over time. 22 Switching BT Drive Free 211 on/off Switching on If the headset is switched off, press the MF button of the headset until you hear 2 signal sounds and the MF button lights up blue 3 times. The headset is switched on and the MF button flashes blue. Note: If the pairing with the BT Drive Free 211 was successful, the device automatically connects with the last connected cell phone after switch-on. For this purpose, the Bluetooth function of the cell phone must be activated.

The initial pairing is described below. Switch-off If the BT Drive Free 211 is switched on, press the MF button until you hear 2 signal sounds and the MF button lights up red for 3 seconds. The device is switched off. Registering (pairing) and connecting with the cell phone Before you can use the BT Drive Free 211, you must register (pair) it with a Bluetooth-ready cell phone and connect it. The BT Drive Free 211 can be paired with two telephones, but connected only with one telephone at a time.

Pairing the headset can be done separately or together with the docking station. Note: If the headset is in the docking station, the MF button on the headset and on the docking station has the same function. Proceed as described to pair the BT Drive Free 211: Hold the headset within range of a Bluetooth-ready cell phone; the distance may not exceed one metre. The headset must be switched off. Press the MF button for approx. 5 seconds until you hear a signal sound and the MF button intermittently flashes red and blue. 23 ENGLISH Disconnect the BT Drive Free 211 from the power supply if you do not want to charge the batteries. Disconnect a completely charged battery from the charger since overcharging negatively impacts the service life of the battery. If a battery is not used over an extended period of time, it loses its capacity over time. Important: Docking station and headset should be charged completely if you do not use the devices for a longer period of time.

To avoid a deep discharge of the batteries, you should completely charge the Bluetooth car kit every 2 months. Activate the Bluetooth function of the cell phone and start the search for Bluetooth devices. (For further details, please read the operating instructions of your cell phone.). Select "BT DF 211" from the displayed list. If necessary, enter the PIN code "0000" and confirm the entry. After successful pairing, you hear a long signal sound and the MF button flashes blue 5 times. The BT Drive Free 211 automatically connects with the cell phone and changes to standby mode a few seconds later. In standby mode, the MF button flashes blue 2 times every 5 seconds. @@@@The headset can also be used separathe Internet under www.

blaupunkt.com. 26 Warranty We provide a manufacturer's warranty for products bought within the European Union. For devices purchased outside the European Union, the warranty terms issued by our respective responsible domestic agency are valid. The warranty terms can be called up from www.

blaupunkt.com. ENGLISH Technical data Bluetooth specifications Supported Bluetooth profile Operating frequency range Bluetooth range Dimensions Weight Battery charging time Talk time Standby time Battery type Version 2.1 + EDR, Class 2 Headset and hands-free profiles 2.402 to 2.

480 GHz ISM band Up to 10 metres 110 (L) x 58 (W) x 23 (H) mm 95 g Approx. 1 hour (headset) Approx. 3 hours (docking station) Up to 2 hours (headset) Up to 15 hours (docking station) Up to 80 hours (headset) Up to 400 hours (docking station) Lithium-ion, 3.



[You're reading an excerpt. Click here to read official BLAUPUNKT BT DRIVE FREE 211 user guide](http://yourpdfguides.com/dref/3865156)  
<http://yourpdfguides.com/dref/3865156>

7 V, 650 mAh, replaceable (compatible with Nokia battery BL-5B) 5 V - 6 V DC, 300 mA Charger Subject to change! 27 FCC-Statements All following FCC statements are valid for the Industry Canada Standard (IC) as well. General Interference Warning: (according to FCC part 15.19) This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Caution: (pertaining to FCC part 15.21) Modifications not expressly approved by this company could void the user's authority to operate the equipment. 150 Blaupunkt AudioVision GmbH & Co. KG Robert-Bosch-Str.

200 D-31139 Hildesheim 5 101 040 000 04/11 450 166 - de, gb, fr, es, pt, it, nl, sf, pl, hu, ro, bg .



[You're reading an excerpt. Click here to read official BLAUPUNKT  
BT DRIVE FREE 211 user guide](#)  
<http://yourpdfguides.com/dref/3865156>