



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT BT DRIVE FREE 411. You'll find the answers to all your questions on the BLAUPUNKT BT DRIVE FREE 411 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BLAUPUNKT BT DRIVE FREE 411**  
**User guide BLAUPUNKT BT DRIVE FREE 411**  
**Operating instructions BLAUPUNKT BT DRIVE FREE 411**  
**Instructions for use BLAUPUNKT BT DRIVE FREE 411**  
**Instruction manual BLAUPUNKT BT DRIVE FREE 411**



[You're reading an excerpt. Click here to read official BLAUPUNKT BT DRIVE FREE 411 user guide](http://yourpdfguides.com/dref/4303289)  
<http://yourpdfguides.com/dref/4303289>

**Manual abstract:**

8 Multi-connection function. 9 Establishing a connection with two cell phones. 14 2 BT Drive Free 411 This wireless Bluetooth hands-free system was developed specifically for users who want to use their cell phone while driving. The BT Drive Free 411 is conveniently attached to the steering wheel. The multi-connection function allows the simultaneous use of the BT Drive Free 411 with two cell phones. Its improved microphone system and DSP technology for echo cancelling and noise suppression achieve an excellent hand-free quality. The technology is based on a radio connection that ensures a fast and reliable transmission of voice and data information. Bluetooth is oriented to the worldwide applicable standard for operating in the internationally recognised ISM frequency band (Industrial Scientific & Medical). 48 GHz, the Bluetooth transmission operates 1600 times per second between 79 different frequencies with a data transmission range of up to 10 metres (Class 2). 3 Safety and general information

Carefully read the operating instructions and follow the instructions.

Observe all locally applicable laws for the use of cell phones and hands-free systems while driving. Operate the BT Drive Free 411 only if the traffic situation allows it and you are not creating a risk for other traffic participants. To avoid any damages and malfunctions, do not drop the device from an elevated height. Do not make any changes or repairs to the device and do not attempt to disassemble it. (Particularly not on the battery since the risk of explosion exists.

It will immediately void the warranty. Do not place any heavy objects on the device. Use only the supplied charger. Repairs and service work may be performed only by a qualified service centre or the manufacturer. Scope of delivery The scope of delivery includes: BT Drive Free 411 12-volt DC vehicle charger adapter USB charger cable Operating instructions Installation on the steering wheel Fasten the BT Drive Free 411 to the steering wheel using the Velcro strap.

Firmly pull the Velcro strap together so that the device will not loosen while driving. Attach the BT Drive Free 411 to the inside circle of the steering wheel and select a position so that it does not interfere with steering the vehicle. Warning: The BT Drive Free 411 may not be positioned within the deployment area of an air bag. 5 Overview 1 2 3 4 5 6 7 MF button (illuminated multifunction button) Loudspeaker Decrease volume (A) Increase volume (+) Microphone Charging socket (micro USB port) Velcro strap for fastening to the steering wheel Battery information The device is equipped with an integrated lithium-polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device since it would damage the device. The full performance of a new battery is not achieved until after two or three complete charging-discharging cycles. The battery can be charged and discharged several hundred times, but it loses its capacity over time. A charged battery loses its capacity if it is not used. Charge the battery completely before its first use.

Connect the BT Drive Free 411 with the vehicle charging adapter via the USB cable. Insert the vehicle charging adapter into the cigarette lighter of the vehicle. The BT Drive Free 411 can also be charged with the USB cable connected to the computer. Note: As soon as the charger is connected, the BT Drive Free 411 switches off. During the charging process, the MF button lights red. After the battery is fully charged, the MF button lights blue. The charging process of the battery lasts approx. 3 hours. Disconnect the BT Drive Free 411 from the charger after it has been charged. A completely charged battery supports a talk time of up to 7 hours and a standby time of up to 300 hours.

Afterwards, the MF button lights blue and the device is switched on. Switching off To switch the unit off, press the MF button for approx. afterwards, the device is switched off.

The BT Drive Free 411 must be switched off. Press the MF button for approx. the device is in registration mode. (Note: The PIN code is preprogrammed and cannot be changed. For some cell phones, you have to manually confirm the connection. In this case, repeat the registering. Automatic connection When switching on the BT Drive Free 411, a connection is automatically established with the two most recently connected cell phones.

Establishing a connection via the BT Drive Free 411 To manually establish a connection between the BT Drive Free 411 and the two most recently connected cell phones, press the MF button. The BT Drive Free 411 first connects itself with the most recently connected cell phone. Then it connects itself with the next most recently connected one. Establishing a connection via the cell phone If the cell phone is not one of the two most recently connected cell phones with the BT Drive Free 411, you have to establish the connection via the Bluetooth menu of the cell phone. After successful connection, you can establish another connection with a second cell phone. This allows you to determine the sequence of connections. If two cell phones are connected with the BT Drive Free 411, the cell phone connected first is the first device and the other one the second device. You hear several signal tones. After the signal tone, speak the voice command. Redialling the last number\* Press the MF button twice.

You hear a signal tone and the number dialled last is being redialled. Note: If two cell phones are connected with the BT Drive Free 411, hold the "A" button pressed for 2 seconds to dial the last number of the cell phone connected last. Call origination via cell phone Select the desired number as usual via the cell phone. The call is automatically transferred to the BT Drive Free 411. Answering a call To answer an incoming call, briefly press the MF button. Ending a call Briefly press the MF button to end a call. Rejecting a call\* To reject a call, hold the MF button pressed until you hear a signal tone. Adjusting the volume During a phone call, adjust the volume with the buttons "+" and "A". Muting the microphone To mute the microphone during a call, press the "A" button for 3 seconds. 10 Transferring a call To transfer a call from the BT Drive Free 411 to the cell phone, press the buttons "+" and "A" at the same time. Repeat the step to transfer the call back to the BT Drive Free 411. Note: With some cell phones, the connection is disconnected if you transfer the call to the cell phone. End the active call and answer the incoming call. Continue the active call and reject the incoming call.



[You're reading an excerpt. Click here to read official BLAUPUNKT](#)

[BT DRIVE FREE 411 user guide](#)

<http://yourpdfguides.com/dref/4303289>

*Change between the active call and the one on hold.*

*End the active call and answer the call on hold. Continue the active call and end the call on hold. Press the MF button for 2 seconds. @@Continue the active call and answer Briefly press the "+" button the call on hold. Note: You do not have the option of managing several calls from two connected cell phones at the same time.*

*When you receive a call on one cell phone while a call is active on the other cell phone, the active call is being ended when you answer the incoming call by briefly pressing the MF button. \* The cell phone must support this function. You find the pertinent information in the operating instructions of the cell phone.*

*11 Resetting the BT Drive Free 411 The BT Drive Free 411 can be registered with up to eight cell phones. You can delete the registration list and reset the hands.*



[You're reading an excerpt. Click here to read official BLAUPUNKT](http://yourpdfguides.com/dref/4303289)

[BT DRIVE FREE 411 user guide](http://yourpdfguides.com/dref/4303289)

<http://yourpdfguides.com/dref/4303289>