



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT GTA 400 FLASH. You'll find the answers to all your questions on the BLAUPUNKT GTA 400 FLASH in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BLAUPUNKT GTA 400 FLASH
User guide BLAUPUNKT GTA 400 FLASH
Operating instructions BLAUPUNKT GTA 400 FLASH
Instructions for use BLAUPUNKT GTA 400 FLASH
Instruction manual BLAUPUNKT GTA 400 FLASH

OK

Amplifier

GTA 400 Flash

7 607 792 103

Bedienungs- und Einbauanleitung
Operating and installation instructions
Notice d'emploi et de montage
Istruzioni d'uso e di installazione
Gebruiksaanwijzing en inbouwhandleiding
Bruks- och monteringsanvisning
Instrucciones de manejo e instalación
Instruções de serviço e de montagem



<http://www.blaupunkt.com>

 **BLAUPUNKT**



[You're reading an excerpt. Click here to read official BLAUPUNKT GTA 400 FLASH user guide](http://yourpdfguides.com/dref/3311791)
<http://yourpdfguides.com/dref/3311791>

Manual abstract:

Do not connect the loudspeakers to ground; only use the terminals provided. The cross-section of the positive and negative cable must be at least 6 mm².
@@@ We recommend that you have our product installed professionally. Should you decide to install the amplifier yourself, however, please read through these instructions carefully, and take your time over the installation. Finally, a word about your health: please bear in mind when playing music in your car that sustained sound levels above 100 dB can damage your hearing and may even result in total hearing loss. Modern highperformance systems and high-quality loudspeaker configurations are quite capable of generating noise levels above 130 dB Fit a fuse in the amplifier power line no more than 30 cm from the vehicle battery, in order to protect the battery in the event of a short-circuit between it and the power amplifier. The amplifier's own fuse protects the amplifier itself, but not the car battery. Disconnect the negative terminal of the battery before carrying out installation and connection work. Observe the vehicle manufacturer's safety instructions (regarding airbags, alarm systems, trip computers, vehicle immobilisers). The final stage must be installed professionally for reasons of safety.

The mounting surface must be suitable for the screws provided, and must provide firm support. When drilling holes, take care to avoid damage to vehicle components (battery, cables, fuse boxes). The mounting location must also be dry, and provide sufficient ventilation for cooling of the amplifier.

@@@@@@ We recommend a cable cross-section of not less than 6 mm². @@@@ a lower load will cause the amplifier to overheat or switch off.

This can lead to permanent damage of the unit. @@Level control The Level control enables the input sensitivity of the final stage to be matched to the output voltage of your car radio preamp output. Adjust the input sensitivity in accordance with the manufacturer's specifications when connecting the amplifier to other radios. important: Turning the Level control clockwise increases the input sensitivity of the amplifier, and thereby also the volume. The Level control is however not a volume control; an increase in volume is not achieved in the maximum position, even if this subjectively appears to be the case.

The system merely increases the volume more quickly when the volume is turned up on the radio. If, for example, you wish to drive a pair of subwoofers, connect in accordance with the low-pass diagram (fig. Bass boost You can adjust the bass output of the amplifier using the bass boost control. the settings range covers 0 dB to +18 dB. Operating indicator (POWER / PROTECTION) Green lamp: Power amp on, regular operating condition Red lamp: Power amp has been switched off electronically, due to a fault or failure. This information is subject to change without notice!) As with any audio component, connection of the amplifier and speakers with the correct polarity is essential for good bass reproduction. @@@@ Dessutom måste vänster förstärkarkanal kopplas till vänster högtalare och höger förstärkarkanal till höger högtalare. Level reglering Med hjälp av Level regleringen kan slutstegets ingångskänslighet anpassas till utgångsspänningen för bilradions förförstärkarutgång. .



[You're reading an excerpt. Click here to read official BLAUPUNKT
GTA 400 FLASH user guide
http://yourpdfguides.com/dref/3311791](http://yourpdfguides.com/dref/3311791)