



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT GTA 450. You'll find the answers to all your questions on the BLAUPUNKT GTA 450 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BLAUPUNKT GTA 450
User guide BLAUPUNKT GTA 450
Operating instructions BLAUPUNKT GTA 450
Instructions for use BLAUPUNKT GTA 450
Instruction manual BLAUPUNKT GTA 450



[You're reading an excerpt. Click here to read official BLAUPUNKT GTA 450 user guide](http://yourpdfguides.com/dref/3311710)
<http://yourpdfguides.com/dref/3311710>

Manual abstract:

Proper installation will maximise the overall performance of your audio system. We recommend that you have our product installed professionally. Should you decide to install the amplifier yourself, however, please read through these instructions carefully, and take your time over the installation.

@@@By selecting the GTA 450 you have chosen a product which delivers superlative reproduction quality. Whether you are upgrading an existing system or using the GTA power amplifier in a new system, you are certain to notice immediate performance benefits! The Blaupunkt editors are constantly working on making the operating instructions clearer and easier to understand. However, if you still have any questions on how to operate the equipment, please contact your dealer or the telephone hotline for your country. You will find the hotline telephone numbers printed at the back of this booklet. We provide a manufacturer guarantee for our products bought within the European Union. You can view the guarantee conditions at [www. blaupunkt.](http://www.blaupunkt.com)

De or ask for them directly at: Blaupunkt GmbH Hotline Robert Bosch Str. Fit a fuse in the amplifier power line no more than 30 cm from the vehicle battery, in order to protect the battery in the event of a shortcircuit between it and the power amplifier. The amplifier's own fuse protects the amplifier itself, but not the car battery. Disconnect the negative terminal of the battery before carrying out installation and connection work. Observe the vehicle manufacturer's safety instructions (regarding airbags, alarm systems, trip computers, vehicle immobilisers).

@@@@@Never bridge fuses or replace fuses with a higher current rating. @@@@ important: Turning the Level control clockwise increases the input sensitivity of the amplifier , and thereby also the volume. The Level control is however not a volume control; an increase in volume is not achieved in the maximum position, even if this subjectively appears to be the case. The system merely increases the volume more quickly when the volume is turned up on the radio.) As with any audio component, connection of the amplifier and speakers with the correct polarity is essential for good bass reproduction.

This enables you to use the amplifier for one or more subwoofer(s) or a midrange speaker. In this configuration the amplifier sums the right-hand and left-hand channels, delivering a single channel (mono) output. Note: The amplifier can sum the right- and left-hand signal information only if both the right- and left-hand RCA connections have been made. CAUTION: The amplifier must be presented with a load of 4 Ohms or higher in bridged mode. a lower load will cause the amplifier to overheat or switch off. This can lead to permanent damage of the unit. Bass boost You can adjust the bass output of the amplifier using the bass boost control. the settings range covers 0 dB to +18 dB. @@@@Därför är det viktigt att vid anslutningarna se till att förstärkarens plusledning (+) kopplas till högtalarens plusledning (+); samma sak gäller för minusledningarna (-). Dessutom måste vänster förstärkarkanal kopplas till vänster högtalare och höger förstärkarkanal till höger högtalare.

This information is subject to change without notice! .



**[You're reading an excerpt. Click here to read official BLAUPUNKT
GTA 450 user guide
http://yourpdfguides.com/dref/3311710](http://yourpdfguides.com/dref/3311710)**