



Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT HAMBURG RCM 104. You'll find the answers to all your questions on the BLAUPUNKT HAMBURG RCM 104 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BLAUPUNKT HAMBURG RCM 104
User guide BLAUPUNKT HAMBURG RCM 104
Operating instructions BLAUPUNKT HAMBURG RCM 104
Instructions for use BLAUPUNKT HAMBURG RCM 104
Instruction manual BLAUPUNKT HAMBURG RCM 104

Radio / Cassette

Hamburg RCM 104

Einbauanleitung
Fitting instructions
Instructions de montage
Istruzioni di montaggio
Inbouwinstallatie
Montierungsanleitung
Instrucciones de montaje
Instruções de montagem



HAMBURG

BLAUPUNKT
Bosch Gruppe

8 622 400 283

Sicherheitshinweise

Einbau- und Anschlussvorschriften
Für die Dauer der Montage und des Anschlusses ist der Minuspol der Batterie abzuklemmen.

Hierbei sind die Sicherheitshinweise des Kfz-Herstellers (Airbag, Alarmanlagen, Bordcomputer, Wegfahrsperren) zu beachten.

Beim Bohren von Löchern darauf achten, daß keine Fahrzeugteile (Batterie, Kabel, Sicherungskasten) beschädigt werden.

Der Querschnitt des Pluskabels darf 2,5 mm² nicht unterschreiten. Das Gerät ist mit einer Sicherung, 10 A flik, abgesichert.

Das Seitenteil des Autoradiogehäuses wird im Betrieb sehr heiß.

Achtung: Es ist darauf zu achten, daß keine Kabel am Gehäuse anliegen.



[You're reading an excerpt. Click here to read official BLAUPUNKT HAMBURG RCM 104 user guide](http://yourpdfguides.com/dref/3330707)
<http://yourpdfguides.com/dref/3330707>

Manual abstract:

@@). The positive cable must have a cross-section of at least 2,5 mm². Attention: Pay attention that the cables do not contact with the housing. Connection with QuickOut installed ex factory If your car is fitted with a QuickOut ex factory (at present Opel), the QuickOut ex factory has to be removed. Insert the car radio from the front into the support and push in until the stop springs on the sides engage right and left (distinct click to be heard). @@ using both brackets (see fig. 3), pull the unit out. Note Locked brackets can only be removed after taking out the unit. @@@@ as a result , one of the conductive tracks in the radio would start burning. Note: By means of the support included in the delivery you can mount the set in cars with a DIN car radio cut-outout of 182 x 53 mm, an installation depth of 165 mm and an instrument panel thickness around the fixing clips of 1 - 20 mm, see fig.

1. @@@@ @@@@ Screw on the ground cable. @@@@ @5 mm²) to the battery (do not route the cable near the cable harnesses). Connect the fuse holder to protect the positive cable and connect it to the positive pole of the battery (if necessary, drill a hole into the fire wall and use cable ducts).

@@@@@ note: Try to bend as many fixing strips as possible.

Insert the support into the cut-out and bend the appropriate fixing strips with a screwdriver, see fig. If necessary, also use cables 7 607 647 093 and 7 607 648 000. When using the IR remote control, QuickOut operation is not possible. If you have connected a car telephone, your car radio will be mutet during telephone calls. @@Stick in byglar till vänster och till höger i de befintliga hålen i panelen och tryck in så långt, att ett tydligt knäpp hörs (sidofjädrarna går ur ingrepp).

@@@@.



[You're reading an excerpt. Click here to read official BLAUPUNKT HAMBURG RCM 104 user guide](http://yourpdfguides.com/dref/3330707)
<http://yourpdfguides.com/dref/3330707>