



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BLAUPUNKT MADRID RCM 105. You'll find the answers to all your questions on the BLAUPUNKT MADRID RCM 105 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BLAUPUNKT MADRID RCM 105  
User guide BLAUPUNKT MADRID RCM 105  
Operating instructions BLAUPUNKT MADRID RCM 105  
Instructions for use BLAUPUNKT MADRID RCM 105  
Instruction manual BLAUPUNKT MADRID RCM 105

Radio / Cassette

## Madrid RCM 105

Einbauanleitung  
Fitting instructions  
Instructions de montage  
Istruzioni di montaggio  
Inbouwinstallatie  
Monteeringsinstructie  
Instrucciones de montaje  
Instruções de montagem



MADRID

**BLAUPUNKT**  
Bosch Gruppe

8 622 400 281

### Sicherheitshinweise

**Einbau- und Anschlussvorschriften**  
Für die Dauer der Montage und des Anschlusses ist der Minuspol der Batterie abzuklemmen.

Hierbei sind die Sicherheitshinweise des Kfz-Herstellers (Airbag, Alarmanlagen, Bordcomputer, Wegfahrsperren) zu beachten.

Beim Bohren von Löchern darauf achten, daß keine Fahrzeugteile (Batterie, Kabel, Sicherungskasten) beschädigt werden.

Der Querschnitt des Pluskabels darf 2,5 mm<sup>2</sup> nicht unterschreiten. Das Gerät ist mit einer Sicherung, 10 A flik, abgesichert.

Das Seitenteil des Autoradiogehäuses wird im Betrieb sehr heiß.

Achtung: Es ist darauf zu achten, daß keine Kabel am Gehäuse anliegen.



[You're reading an excerpt. Click here to read official BLAUPUNKT MADRID RCM 105 user guide](http://yourpdfguides.com/dref/3330939)  
<http://yourpdfguides.com/dref/3330939>

**Manual abstract:**

@@ ). The positive cable must have a cross-section of at least 2,5 mm<sup>2</sup>. Attention: Pay attention that the cables do not contact with the housing. Connection with QuickOut installed ex factory If your car is fitted with a QuickOut ex factory (at present Opel), the QuickOut ex factory has to be removed. Insert the car radio from the front into the support and push in until the stop springs on the sides engage right and left (distinct click to be heard). @@ using both brackets (see fig. 3), pull the unit out. Note Locked brackets can only be removed after taking out the unit. @@@@ as a result , one of the conductive tracks in the radio would start burning. Note: By means of the support included in the delivery you can mount the set in cars with a DIN car radio cut-outout of 182 x 53 mm, an installation depth of 165 mm and an instrument panel thickness around the fixing clips of 1 - 20 mm, see fig.

1. @@@@ Screw on the ground cable. @@@@ (5 mm<sup>2</sup>) to the battery (do not route the cable near the cable harnesses). Connect the fuse holder to protect the positive cable and connect it to the positive pole of the battery (if necessary, drill a hole into the fire wall and use cable ducts).

@@@@ note: Try to bend as many fixing strips as possible.

Insert the support into the cut-out and bend the appropriate fixing strips with a screwdriver, see fig. If necessary, also use cables 7 607 647 093 and 7 607 648 000. When using the IR remote control, QuickOut operation is not possible. If you have connected a car telephone, your car radio will be mutet during telephone calls. @@Stick in byglar till vänster och till höger i de befintliga hålen i panelen och tryck in så långt, att ett tydligt knäpp hörs (sidoffjädrarna går ur ingrepp).

@@@@.



[You're reading an excerpt. Click here to read official BLAUPUNKT](#)

[MADRID RCM 105 user guide](#)

<http://yourpdfguides.com/dref/3330939>