




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH HBM13B251B. You'll find the answers to all your questions on the BOSCH HBM13B251B in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSCH HBM13B251B
User guide BOSCH HBM13B251B
Operating instructions BOSCH HBM13B251B
Instructions for use BOSCH HBM13B251B
Instruction manual BOSCH HBM13B251B



[You're reading an excerpt. Click here to read official BOSCH HBM13B251B user guide](http://yourpdfguides.com/dref/4541985)
<http://yourpdfguides.com/dref/4541985>

Manual abstract:

The appliance must be disconnected from the power supply during all installation work. Do not install the oven underneath the work surface. Do not install the oven underneath the work surface. Carry out all cut-out work on the furniture unit and worktop before fitting the appliances. remove shavings. Otherwise, the correct operation of electrical components may be adversely affected. caution during installation. Parts that are accessible during installation may have sharp edges. Wear protective gloves to prevent injury from cuts. appliance in a tall unit - Fig. Check that the appliance door can be opened properly. Note the information on the nameplate for voltage and total power. Power cord: Type H05 V V-F or a higher rating. In the installation, there must be an all-pin isolating switch with at least 3 mm contact gap, or the appliance must be connected using a plug with an earthing contact. This must remain accessible after installation. Contact protection must be ensured by the method of installation. Identify the phase and neutral (zero) conductors in the power socket. The appliance could be damaged if incorrectly connected. To connect the appliance, place it in front of the kitchen unit. The service cable must be long enough. Do not kink or trap the power cable, or route it over sharp edges. 3. Disconnect the appliance from the power supply. Lift the appliance slightly and pull it out completely. For Australia only: The installation height of the oven must be at least 400 mm. Do not install the oven underneath the work surface.



[You're reading an excerpt. Click here to read official BOSCH HBM13B251B user guide](http://yourpdfguides.com/dref/4541985)
<http://yourpdfguides.com/dref/4541985>