




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH PSB 650 RE. You'll find the answers to all your questions on the BOSCH PSB 650 RE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSCH PSB 650 RE
User guide BOSCH PSB 650 RE
Operating instructions BOSCH PSB 650 RE
Instructions for use BOSCH PSB 650 RE
Instruction manual BOSCH PSB 650 RE



Robert Bosch GmbH
Power Tools Division
70745 Leinfelden-Echterdingen
www.bosch-pt.com
2 609 002 371 (2008.01) □ / 125

PSB

530 RA | 600 RE | 650 RE | 650 RA



de Originalbetriebsanleitung
en Original instructions
fr Notice originale
es Manual original
pt Manual original
it Istruzioni originali
nl Oorspronkelijke
gebruiksaanwijzing
da Original brugsanvisning
sv Bruksanvisning i original
no Original driftsinstruks
fi Alkuperäiset ohjeet

el Πρωτότυπο οδηγίων χρήσης
tr Orjinal işletme talimatı



[You're reading an excerpt. Click here to read official BOSCH PSB 650 RE user guide](http://yourpdfguides.com/dref/2287151)
<http://yourpdfguides.com/dref/2287151>

Materials containing asbestos may only be worked by specialists. Use dust extraction whenever possible. Provide for good ventilation of the working place. English \ 21 Cleaning the Extraction Device (see figure A) Attach the locking latch 17 or empty the dust collector 15 before placing down the extraction device. When the extraction force diminishes or when the level indicator 20 is full, the dust collector 15 must be emptied. For this, press on the riffled surface of the release button 14 and take off the dust collector 15. Empty and clean the dust collector 15. Clean the filter element 19 by gently striking or tapping against it.

check the filter element 19 for damage and replace it as required. For this, as an example, pry off the holder of the filter element 19 () and change the filter element 19 including the holder (). When placing on the holder again, make sure that the rubber gasket is inserted. Reattach the dust collector 15 again and lock it by pressing against the smooth surface of the release button 14. Removing the Extraction Device For removal of the extraction device 9, push the release button 18 to the right or left and pull off the extraction device 9 toward the front.

insert a drill bit into the drill chuck and clamp the drill bit , see section "Changing the Tool" , page 21. Rotate the collar for the depth stop 13 upward until it can be moved on the telescopic guide 12. Place the machine, without switching it on, firmly against the surface to be drilled until the drill bit touches the surface. Slide the collar 13 to the calculated scale value and then rotate the collar 13 downward to lock the determined clearance. Adjusting the Drilling Depth (PSB 600 RE/PSB 650 RE) (ency (PSB 600 RE/PSB 650 RE/PSB 650 RA) With the thumbwheel for speed preselection 7, the required speed/impact frequency can be preselected even during operation.

The required speed/impact frequency depends on the material and the working conditions, and can be determined through practical testing. The wires in the cable are coloured according to the following code: Do not connect the blue or brown wire to the earth terminal of the plug. Important: If for any reason the moulded plug is removed from the cable of this power tool, it must be disposed of safely. Apply the power tool to the screw/nut only when it is switched off.

rotating tool inserts can slip off. After longer periods of working at low speed, allow the machine to cool down by running it for approx. Our after-sales service responds to your questions concerning maintenance and repair of your product as well as spare parts. Exploded views and information on spare parts can also be found under: www. bosch-pt. Com Our customer consultants answer your questions concerning best buy, application and adjustment of products and accessories.

Before any work on the machine itself, pull the mains plug. For safe and proper working, always keep the machine and ventilation slots clean. If the machine should fail despite the care taken in manufacturing and testing procedures, repair should be carried out by an after-sales service centre for Bosch power tools. @@@@ Subject to change without notice. @@Risk finns för att buller leder till hörselskada. Darbeli matkap Ürün kodu Giri gücü Ç k gücü Botaki devir say s Devir say s Darbe say s Anma torku Maksimum ç k gücündeki tork Devir say s ön seçimi Sa/sol dönü Mil kilitleme Toz emme Mil boynu çap Ø maks. Türkçe \ 123 Devir say s n ve darbe say s n ayarlanmas Açma/kapama alteri üzerine uygulad n z bast rma kuvvetini 6 azalt p çöaltarak alet çal r durumunda iken de devir say s n ve darbe say s n ayarlayabilirsiniz. Devir say s n ve darbe say s n ön seçimi (PSB 600 RE/PSB 650 RE/PSB 650 RA) Devir say s ön seçim dümesi 7 ile gerekli olan devir say s n ve darbe say s n iletim halinde de önceden seçerek ayarlayabilirsiniz. Gerekli devir say s ile darbe say s ilenen malzemeye çal ma koullar na bal olup, en doru biçimde deneyerek tespit edilebilir. Düşük devir say s ile uzun süre çal t n zda, soutma yapmak için elektrikli el aletini bota en yüksek devir say s ile yakla k 3 dakika kadar çal t r n.



[You're reading an excerpt. Click here to read official BOSCH PSB 650 RE user guide](http://yourpdfguides.com/dref/2287151)
<http://yourpdfguides.com/dref/2287151>