



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH PSR 1200. You'll find the answers to all your questions on the BOSCH PSR 1200 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSCH PSR 1200
User guide BOSCH PSR 1200
Operating instructions BOSCH PSR 1200
Instructions for use BOSCH PSR 1200
Instruction manual BOSCH PSR 1200



[You're reading an excerpt. Click here to read official BOSCH PSR 1200 user guide](http://yourpdfguides.com/dref/2282488)

<http://yourpdfguides.com/dref/2282488>

Manual abstract:

Please observe the order number of your machine. The trade names of the individual machines may vary. Working safely with this machine is possible only when the operating and safety information are read completely and the instructions contained therein are strictly followed. In addition, the general safety notes in the enclosed booklet must be observed. wear safety goggles. For long hair, wear hair protection. Work only with closely fitting clothes. Before each use, check the machine and battery. The rated voltage of the battery must agree with the data on the machine. @@@@Do not strain the machine so heavily that it comes to a standstill.

Not all of the accessories illustrated or described are included as standard delivery. The machine is intended for the screwing in and loosening of screws as well as for drilling in wood, metal, ceramic and plastic. Typically the A-weighted sound pressure level of the product is less than 70 dB (A). The noise level when working can exceed 85 dB (A). S Hold the machine tightly: When driving in screws, high reaction moments can briefly occur.

S Never allow children to use the machine. S Bosch is only able to ensure perfect operation of the machine if the original accessories intended for it are used. Open the drill chuck until the tool can be inserted. insert the tool. Hold the rear collar tight and firmly tighten the front collar by hand, until the "clicking" of the locking action is no longer heard.

this automatically locks the chuck. The locking is released again when the front collar is turned in the opposite direction to remove the tool. S The enclosed operating instructions for the battery charger must be read carefully! S The battery and battery charger are designed to match each other. When charging the battery, use only a Bosch battery charger designed for it with a charging voltage that corresponds with the battery (see type plate). @S Do not open the battery, and protect it from impact. @@@@Do not strain the machine so heavily that it comes to a standstill. To switch off the machine, release the On/Off switch 4. @@@@Do not exert any force. @A long battery service life is achieved in this manner. @However, this is not possible with the On/Off switch 4 actuated.

@The chuck must be tightened with a torque of approx. @@@, small screws, soft materials. @@Select a higher setting when driving out screws, or set to the "Drilling" symbol. S Before any work on the machine itself, remove the battery. For safe and proper working, always keep the machine and the ventilation slots clean. If the machine should fail despite the care taken in manufacturing and testing procedures, repair should be carried out by an after-sales service centre for Bosch power tools. In all correspondence and spare parts orders, please always include the 10-digit order number given on the nameplate of the machine. When releasing the On/Off switch 4 the speed of the drill chuck is reduced to a stop, thus preventing the run-on of the tool. For screwdriving applications, wait until the screw is flush with the material and then release the On/Off switch 4. The screw head does not penetrate into the material then.

These instructions are printed on recycled paper manufactured without chlorine. the plastic components are labelled for categorized recycling. @@@@We declare under our sole responsibility that this product is in conformity with the following standards or standardization documents. Vid kortslutning till följd av metallbrygning finns risk för brand! .



[You're reading an excerpt. Click here to read official BOSCH PSR](http://yourpdfguides.com/dref/2282488)

[1200 user guide](http://yourpdfguides.com/dref/2282488)

<http://yourpdfguides.com/dref/2282488>