



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH WFL1880AU. You'll find the answers to all your questions on the BOSCH WFL1880AU in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSCH WFL1880AU
User guide BOSCH WFL1880AU
Operating instructions BOSCH WFL1880AU
Instructions for use BOSCH WFL1880AU
Instruction manual BOSCH WFL1880AU

Quick-reference instructions
Please read and observe these operating and installation instructions carefully before using the washing machine for the first time.

BOSCH

1 As required

2 As required

At the end of the programme

1 2 3

0202 en
5170 000 189



[You're reading an excerpt. Click here to read official BOSCH WFL1880AU user guide](http://yourpdfguides.com/dref/3652706)
<http://yourpdfguides.com/dref/3652706>

Manual abstract:

*g. cotton or linen 30, 40, 60 °C ,, Cottons+Linens C tt Li 6.5 kg / 14.3 lb Additional functions None Quick Wash Rinse Plus Reduced Ironing Rinse hold None None None None Quick Wash Rinse Plus Reduced Ironing Rinse hold None Quick Wash Rinse Plus Reduced Ironing Rinse hold None Quick Wash Rinse Plus Reduced Ironing Rinse hold Programme duration in min. (approx.) *** 118 48-62 127 123 108 135 138 121 78 37-53 86 81 70 50 33 58 54 46 50 29-32 55 51 47 Additional rinsing cycle Creases are reduced The laundry is left in the final rinsing water abcde 60 °C Cottons+Linens Intensive Stains 60 °C Cottons+Linens + Prewash **90 °C Cottons Stained Intensive Intensive Light to normal Negligible to light Additional rinsing cycle Creases are reduced The laundry is left in the final rinsing water Light to normal Negligible to light Easy care textiles, e.g. @@@@ Maximum spin speed: 800 r.p.m. Spin cycle for spinning hand washed laundry. Water is drained before the spin cycle. Maximum spin speed: 800 r.p.m. @@@** Divide detergent between dispensers I and II. *** The programme duration deviates from the indicated values depending on the water pressure, water hardness, water inlet temperature, ambient temperature, type of washing and amount, detergent, fluctuations in the mains voltage and selected additional options Further information can be found in the operating and installation manual. .*



[You're reading an excerpt. Click here to read official BOSCH WFL1880AU user guide](http://yourpdfguides.com/dref/3652706)
<http://yourpdfguides.com/dref/3652706>