



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN 140. You'll find the answers to all your questions on the BRAUN 140 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRAUN 140
User guide BRAUN 140
Operating instructions BRAUN 140
Instructions for use BRAUN 140
Instruction manual BRAUN 140



www.braun.com/register



[You're reading an excerpt. Click here to read official BRAUN 140 user guide](http://yourpdfguides.com/dref/3271780)
<http://yourpdfguides.com/dref/3271780>

Manual abstract:

@@Do not exchange or tamper with any part of it, otherwise there is risk of electric shock. This appliance is not intended for use by children or persons with reduced physical or mental capabilities, unless they are given supervision by a person responsible for their safety. In general, we recommend that you keep the appliance out of reach of children. To make sure that the shaver is switched off, press the «off» switch (6) before you start charging. When charging for the first time, leave the shaver to charge continuously for 16 hours. This may vary according to your beard growth. Maximum battery capacity will only be reached after several charging/ discharging cycles. 1 2 3 4 5 6 7 8 9 Foil protection cap Shaver foil Cutter block Long hair trimmer (model 150 only) On switch («power») «off» switch Power LED Shaver power socket Special cord set Press the on switch (5) to operate the shaver. Model 150 only: To trim sideburns, moustache or beard, slide the long hair trimmer (4) upwards. @@Always shave before washing your face.

2. At all times, hold the shaver at right angles (90°) to your skin. 3. @@@@The shaver head is suitable for cleaning under running tap water. @@ regular cleaning ensures better shaving performance.

@@You may use liquid soap without abrasive substances. Rinse off all foam and let the shaver run for a few more seconds. @@Then leave the disassembled shaving parts to dry. @@@@In the interest of protecting the environment, please do not dispose of the product in household waste at the end of its useful life. Disposal can take place at a Braun Service Centre or at appropriate collection points provided in your country.

Subject to change without notice. 1 2 3 4 5 6 7 8 9 Capot de protection de la grille Grille de rasage Bloc-couteaux Tondeuse rétractable (seulement sur le modèle 150) Interrupteur marche (« power ») Interrupteur arrêt (« off ») Témoin lumineux d'alimentation électrique Prise d'alimentation secteur du rasoir Cordon d'alimentation Appliance resulting from faults in materials or workmanship, free of charge either by repairing or replacing the complete appliance at our discretion. This guarantee extends to every country where this appliance is supplied by Braun or its appointed distributor. This guarantee does not cover: damage due to improper use, normal wear and tear (e. The guarantee becomes void if repairs are undertaken by unauthorised persons and if original Braun parts are not used. @@@@Within the guarantee period we will eliminate any defects in the .



[You're reading an excerpt. Click here to read official BRAUN 140 user guide](http://yourpdfguides.com/dref/3271780)

<http://yourpdfguides.com/dref/3271780>