



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN 530S-4 SERIES 5. You'll find the answers to all your questions on the BRAUN 530S-4 SERIES 5 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BRAUN 530S-4 SERIES 5**  
**User guide BRAUN 530S-4 SERIES 5**  
**Operating instructions BRAUN 530S-4 SERIES 5**  
**Instructions for use BRAUN 530S-4 SERIES 5**  
**Instruction manual BRAUN 530S-4 SERIES 5**



[You're reading an excerpt. Click here to read official BRAUN 530S-4 SERIES 5 user guide](http://yourpdfguides.com/dref/3192841)  
<http://yourpdfguides.com/dref/3192841>

**Manual abstract:**

@@@This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities, unless they are given supervision by a person responsible for their safety. In general, we recommend that you keep the appliance out of reach of children. Children should be supervised to ensure that they do not play with the appliance. Oil bottle Keep out of reach of children. Using the special cord set (10), connect the shaver to an electrical outlet with the motor switched off and charge it for at least one hour. This may vary according to your beard growth. • If the rechargeable battery has run out of power (discharged), you may also shave by connecting the shaver to an electrical outlet via the special cord set. Model 570: During charging or when using the shaver, the respective battery segment will blink (green). When fully charged, all segments will light up continuously, provided the shaver is switched on or connected to an electrical outlet. (Modell 530: 1 charging segment only) The red low-charge light flashes when the battery is running low.

You should be able to finish your shave. 1 2 3 4 5 6 7 8 9 10 11 Shaver foil Cutter block Foil release buttons Long hair trimmer Comfort setting switch  
• On/off switch Shaver display Replacement light for shaving parts Shaver power socket Special cord set Etui Comfort setting switch  
• Setting the shaver head according to your comfort needs. • The shaver head is semi-fixed for more control. • Always shave before washing your face. 2.

• 3. • switch on the shaver for approx. 5-10 seconds so that the shaved stubbles can fall out. Using a brush, clean the inner area of the shaver head. • then the shaver will automatically reset the display.

• The manual reset can be done at any time. The shaver head is suitable for cleaning under running tap water. • regular cleaning ensures better shaving performance. Rinsing the shaving head under running water after each shave is an easy and fast way to keep it clean: • Switch the shaver on (cordless) and rinse the shaver head under hot running water. You may use liquid soap without abrasive substances. Rinse off all foam and let the shaver run for a few more seconds. • Next, switch off the shaver, press the foil release buttons (3) to remove the shaver foil (1) and cutter block (2). Then leave the disassembled shaving parts to dry. • If you regularly clean the shaver under water, then once a week apply a drop of light machine oil onto the long hair trimmer and shaver foil. In the interest of protecting the environment, please do not dispose of the product in the household waste at the end of its useful life.

Disposal can take place at a Braun Service Centre or at appropriate collection points provided in your country. Subject to change without notice. This guarantee does not cover: damage due to improper use, normal wear and tear (e. The guarantee becomes void if repairs are undertaken by unauthorised persons and if original Braun parts are not used. To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorised Braun Customer Service Centre (address information available online at [www.@@@.@@](http://www.braun.com)).



[You're reading an excerpt. Click here to read official BRAUN 530S-4 SERIES 5 user guide](http://yourpdfguides.com/dref/3192841)

<http://yourpdfguides.com/dref/3192841>