



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN 5414. You'll find the answers to all your questions on the BRAUN 5414 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRAUN 5414
User guide BRAUN 5414
Operating instructions BRAUN 5414
Instructions for use BRAUN 5414
Instruction manual BRAUN 5414

BRAUN

5414
5415
5416



Flex Integral

Type 5476
Type 5477
Type 5478



[You're reading an excerpt. Click here to read official BRAUN 5414 user guide](http://yourpdfguides.com/dref/3273516)

<http://yourpdfguides.com/dref/3273516>

Manual abstract:

@@@ Foil protection cap Triple shaving frame Duo cutter block Pop-out long hair trimmer Switch lock On/off switch Charging light (green) Low-charge light (red) (only 5416/5415) Shaver socket Switch for locking the swivel head («head lock») and for activating the pop-out long hair trimmer («trimmer») Release button For the 3 first chargings: Connect the shaver to the mains and charge it for at least 4 hours (switch position «off»), then shave without the cord until the red low-charge light lights up. (Model 5414: Shave without the cord until the shaver runs distinctly slower.) The full capacity is only reached after several charge/discharge cycles. The green charging light indicates that the shaver is connected to the mains. After the cell unit is fully charged, the green charging light goes off. If later on, the charging light comes on again, this indicates that the shaver is being recharged to maintain its full capacity. Model 5416/5415 only: The red low-charge light lights up when the capacity has dropped below 20 %, provided the shaver is switched on. Off on Shaving with the pivoting head. The pivoting cutting system automatically adjusts to every contour of your face. Shaving with the pivoting head locked (to permit shaving in difficult areas, e.

@@ Push the switch lock up before you shave for the first time. When travelling, push the switch lock to position «lock». @@@@ Stretch your skin and shave against the direction of beard growth. @@@@ 5. @@@@5-001-687) Recharging with this cord takes about 20 hours. This appliance is provided with a nickel-hydride cell unit. This cell does not contain any harmful heavy metals. @@@@ caution! Opening the appliance will definitely destroy it. Subject to change without notice. This product conforms to the EMC Requirements as laid down by the Council Directive 89/336/EEC and to the Low Voltage Regulation (73/23 EEC).

Capot de protection de la grille Triple tête de rasage Double bloc-couteaux Tondeuse escamotable (« trimmer ») Verrou de blocage de mise en marche « lock » Interrupteur marche/arrêt Témoin lumineux vert de charge Témoin lumineux rouge de décharge (5416/5415 uniquement) Prise d'alimentation du rasoir Interrupteur pour bloquer la tête pivotante (« head lock ») et pour activer la tondeuse escamotable (« trimmer ») Bouton d'ouverture de la tête de rasage Kasta däremot inte den uttjänta apparaten i hushållssoporna utan lämna den till en Braun serviceverkstad eller till en återvinningsstation. Denna produkt är anpassad till EMCföreskrifterna 89/336/EEC och till Low Voltage föreskriften (73/23 EEC). 2 Pozycje włącznika off = wyłączony on = włączony Golenie z wykorzystaniem ruchomej głowicy oraz podwójnej folii i zintegrowanego zespołu tnącego head lock Golenie z głowicą zablokowaną w pozycji wychylonej (np. To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorised Braun Customer Service Centre. For UK only: This guarantee in no way affects your rights under statutory law. Within the guarantee period we will eliminate, free of charge, any defects in the appliance resulting from faults in materials or workmanship, either by repairing or replacing the complete appliance as we may choose.

@@@@@.



[You're reading an excerpt. Click here to read official BRAUN 5414 user guide](http://yourpdfguides.com/dref/3273516)
<http://yourpdfguides.com/dref/3273516>