



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN 5570. You'll find the answers to all your questions on the BRAUN 5570 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRAUN 5570
User guide BRAUN 5570
Operating instructions BRAUN 5570
Instructions for use BRAUN 5570
Instruction manual BRAUN 5570



www.braun.com/register

Type 5395



[You're reading an excerpt. Click here to read official BRAUN 5570 user guide](http://yourpdfguides.com/dref/3366738)
<http://yourpdfguides.com/dref/3366738>

Manual abstract:

We hope you thoroughly enjoy using the Braun Silk-épil Xelle. In the following we would like to familiarise you with the appliance and provide some useful information about epilation. Please read the use instructions carefully and thoroughly before using the appliance. braun Silk-épil Xelle Body Epilation has been designed to make the removal of unwanted hair as efficient, gentle and easy as possible. Its proven epilation system removes hair at the root, leaving your skin smooth for weeks. As the hair that regrows is fine and soft, there will be no more stubble. The new epilation head 2 with X'pert-épil system features 40 tweezers that are uniquely arranged to remove more hair in a single stroke, for unprecedented efficiency. The SoftLift® tips integrated in the epilation head make sure that even short hairs (0.5 mm) and flat lying hairs are removed thoroughly at the root. It comes with two different clips: A The massaging rollers clip makes the epilation ultra gentle.

Its pulsating movement stimulates and relaxes the skin to offset the pulling sensation. A reduced number of tweezers and the narrow design, specifically adapted to these body areas, improve the handling and ensure a particularly gentle epilation in these areas. Keep the appliance out of the reach of children. When switched on, the appliance must never come in contact with the hair on your head, eyelashes, ribbons, etc. To prevent any danger of injury as well as to prevent blockage or damage to the appliance.

Before use, check whether your voltage corresponds to the voltage printed on the transformer. Always use the country-specific 12 V transformer plug supplied with this product. general information on epilation Silk-épil is designed to epilate hair on legs, but use tests monitored by dermatologists have revealed that you can also epilate the underarm and the bikini line. All methods of hair removal at the root can lead to in-growing hair and irritation (e.g.

itching, discomfort and reddening of the skin) depending on the condition of the skin and hair. This is a normal reaction and should quickly disappear, but may be stronger when you are removing hair at the root for the first few times or if you have sensitive skin. If, after 36 hours, the skin still shows irritation, we recommend that you contact your physician. In general, the skin reaction and the sensation of pain tend to diminish considerably with the repeated use of Silk-épil. In some cases inflammation of the skin could occur when bacteria penetrate the skin (e.g. Thorough cleaning of the epilation head before each use will minimise the risk of infection. Fine hair which re-grows might not grow up to the skin surface. Before starting, thoroughly clean the epilation heads (2 and 8). For leg epilation, choose epilation head 2. For reduced speed, choose the «soft» setting. 2 Rub your skin to lift short hairs.

Then carefully dab dry with a towel. As skin may be more sensitive directly after epilation, avoid using irritating substances such as deodorants with alcohol. Cleaning the epilation heads 5 After epilating, unplug the appliance and clean the epilation head. First remove the clip used (A or a) and clean it with the brush. 6 To clean the tweezer element, use the cleaning brush dipped into alcohol. Clean the tweezers with the brush from the rear side of the epilator head while turning the barrel manually. 7 Remove the epilation head by pressing the release buttons 3 on the left and right and pull it off.

Give the top of the housing a quick clean with the brush. Place the epilation head and your preferred clip (A or a) back on the housing. 3 Leg epilation (epilation head 2 with 1a or 1b): Epilate your legs from the lower leg in an upward direction.

When epilating behind the knee, keep the leg stretched out straight. 4 Underarm and bikini line epilation (underarm epilation head 8 without attachment): For this specific application, the narrow underarm epilation head has been developed. Thanks to its specific design adapted to the contours of these areas, it provides a gentle and thorough epilation. Please be aware that especially at the beginning these areas are particularly sensitive to pain. with repeated usage the pain sensation will diminish.

For more comfort, ensure that the hair is at the optimum length of 25 mm. This guarantee extends to every country where this appliance is supplied by Braun or its appointed distributor. This guarantee does not cover: damage due to improper use, normal wear or use as well as defects that have a negligible effect on the value or operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorised persons and if original Braun parts are not used. To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorised

Braun Customer Service Centre.

For UK only: This guarantee in no way affects your rights under statutory law. .



[You're reading an excerpt. Click here to read official BRAUN 5570 user guide](#)

<http://yourpdfguides.com/dref/3366738>