



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN 7540. You'll find the answers to all your questions on the BRAUN 7540 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRAUN 7540
User guide BRAUN 7540
Operating instructions BRAUN 7540
Instructions for use BRAUN 7540
Instruction manual BRAUN 7540

BRAUN

7540 



Syncro

Type 5492



[You're reading an excerpt. Click here to read official BRAUN 7540 user guide](http://yourpdfguides.com/dref/3289334)
<http://yourpdfguides.com/dref/3289334>

Manual abstract:

We hope you enjoy your new Braun shaver. Important Only use the power supply cord set provided. 1 2 3 4 5 6 Foil protection cap Shaver foil Cutter block Foil release button Long hair trimmer Switch 7 Charging lights (green) 8 Low-charge light (red) 9 Pilot light 10 Shaver socket First charging: Using the power supply cord set, connect the shaver to the mains with the switch on position «0» and charge it for at least 4 hours (plug might get warm). Once the shaver is completely charged, shave without the cord until fully discharged. @@@@ Shaving with the cord If the rechargeable battery is discharged, you may also shave with the shaver connected to the mains via the power supply cord set. (If the shaver does not run immediately, charge it with the switch on position «0» for approx. We recommend that you shave before washing, as the skin tends to be slightly swollen after washing. Stretch your skin and shave against the direction of beard growth. Replace the shaver foil and cutter block every 1 1/2 years, or when the parts are worn, to ensure optimum shaving performance. The red low-charge light flashes when the battery capacity has dropped below 20%, provided the shaver is switched on. When the rechargeable battery is fully charged, all five charging lights illuminate (20% per light), provided the shaver is connected to the mains or switched on. It automatically takes care of all cleaning and lubrication needs of your shaver. Manual cleaning For easy cleaning after each shave, switch the shaver off. Press the release buttons to lift the shaver foil (do not remove the foil completely). switch on the shaver for approx. 5-10 seconds so that the shaved stubbles can fall out. @@@@ * (Shaver foil and cutter block: part no. @@@@ Subject to change without notice. @@Support mural Fixez le support mural avec l'adhésif sur une surface propre (si nécessaire avec vis et cheville). Den återstående kapaciteten räcker till 2 till 3 rakningar. Denna produkt är anpassad till EMC-föreskrifterna 89/336/EEC och till lågspänningsdirektivet (73/23 EEC). Please ensure you store your sales receipt in a safe place. Within the guarantee period we will repair, free of charge, any defects in the appliance resulting from faults in materials or workmanship, but may, at our discretion, choose to exchange specific parts or replace the complete appliance. This guarantee does not cover: damage arising from improper use (kinks in the shaver foil, breakage), normal wear and defects that have a negligible effect on the value or operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorised persons and if original Braun parts are not used. The guarantee is valid for 12 months from the original date of purchase as per your sales receipt. The guarantee on any repairs or exchanges made under guarantee expires at the end of this period. @@@@ Konsumentköp EHL 91 Gäller vid försäljning till konsument av nya elektriska hushållsapparater och reglerar, i anslutning till Konsumentköplagen, köparens rättigheter om apparaten är felaktig. Köparen skall så snart som möjligt prova apparaten efter mottagandet och inom skälig tid, normalt 14 dagar, reklamera eventuella fel till säljaren eller till av säljaren eller leverantören anvisad verkstad. .



[You're reading an excerpt. Click here to read official BRAUN 7540 user guide](http://yourpdfguides.com/dref/3289334)
<http://yourpdfguides.com/dref/3289334>