



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN 8595. You'll find the answers to all your questions on the BRAUN 8595 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

[User manual BRAUN 8595](#)

[User guide BRAUN 8595](#)

[Operating instructions BRAUN 8595](#)

[Instructions for use BRAUN 8595](#)

[Instruction manual BRAUN 8595](#)

BRAUN

8595

Activator™

www.braun.com

Type 5643
5-643-450/00/II-03/02
D/GB/F/E/P/I/NL/DK/N/S/FIN/TR/GR
Printed in Germany



You're reading an excerpt. Click here to read official BRAUN 8595 user guide
<http://yourpdfguides.com/dref/3290159>

Manual abstract:

It ensures unsurpassed closeness and comfort for you and optimum care for your shaver: *A*· The system recognizes when cleaning of your shaver is required, and automatically recognizes which of the three cleaning programs is appropriate. *A*· While the shaver is connected to the mains, the system automatically takes care of charging and discharging in a way that is optimized for the shaver's battery capacity and life span. Your Activator is provided with a low-voltage adapter. Therefore you must not exchange or manipulate any part of it. Otherwise there is risk of electric shock. @@@@ @@@@ Keep it away from sources of ignition. no smoking. Keep out of reach of children. Low-voltage adapter *«start cleaning»* button Station-to-shaver connecting contacts Station

lift button for cartridge exchange Display for cleaning programs Display for cleaning fluid status Station mains socket Cleaning cartridge Shaver foil protection cap Shaver foil Cutter block Foil release buttons Long hair trimmer Shaver-to-station connecting contacts (shaver backside) Switch Shaver display Info key Pilot light Shaver mains socket If you wish, you may start shaving right away (if the shaver is charged, see section *«Shaver display»*). However, we recommend to follow the procedure described here: *A*· Carefully remove the lid from the cartridge.

Slowly close the housing by pushing it down until it locks. The display for cleaning fluid (6) will show how much cleaning fluid is in the cartridge: a) Cleaning solution sufficiently available b) Up to 7 cleanings left c) New cartridge required Make sure the foil protection cap (9) is removed from the shaver. Insert the shaver head down into the station (the contacts on the back of the shaver (14) will correspond to the contacts in the station (3)). If necessary, the system will now charge the shaver. Also, the cleaning status will be automatically analyzed and one of the four diodes of the cleaning program display (5) will light up: a)

The shaver is clean b) Eco(nomic), i.

e. Short cleaning required c) Normal cleaning required d) Intensive cleaning required If the system has selected one of the three cleaning programs, it will not start until you push down the *«start cleaning»* button (2). This locks the shaver into the station and starts the cleaning process. we recommend cleaning after each shave. While the cleaning is in progress, the respective cleaning program light will flash.

Each cleaning consists of several cycles (where the cleaning fluid is flushed through the shaver head) and a heat drying period. While the shaver is drying, the metal parts of the shaver may be hot. Also, if the shaver is taken out prematurely and is not dry, its electronics could be harmed. When the program is finished, the blue *«clean»* light will shine. @@ Your shaver is now clean, charged and ready for use. @@@@ @@@ hold the shaver at right angles (90°) to the skin. Stretch your skin and shave against the direction of beard growth. @@@@ All charging and cleaning needs are then taken care of. @@@@ Never use water to clean the shaver. remove the shaver foil and tap it out on a flat surface.

@@@@@@ switch on the shaver for approx. 5-10 seconds so that the shaved stubbles can fall out. @@ Self testing / shaver is fully charged (a full charge will give up to 50 minutes of cordless shaving time, depending on your beard growth). To help obtain a new shaver foil and cutter block at your dealer or Braun Service Center, the display shows the part No. 8000. To reset the display, push the info key (17). Change both parts at the same time for a closer shave with less skin irritation. Allow the shaver to remain for some time at room temperature for optimal charging conditions. Intensive cleaning needed *A* return to the Clean&Charge station as soon as possible. To reset the display, push the info key (17).

Press again: key part number for shaver foil and cutter block. This appliance is provided with nickel-hydride rechargeable batteries. To protect the environment, do not dispose of the appliance in the household waste at the end of its useful life. Open the housing as shown, remove and dispose of the batteries at your retail store or at appropriate collection sites according to national or local regulations. The cartridge can be disposed with regular garbage. Subject to change without notice. Within the guarantee period we will eliminate, free of charge, any defects in the appliance resulting from faults in materials or workmanship, either by repairing or replacing the complete appliance as we may choose. @@@@ To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorised Braun Customer Service Centre. For UK only: This guarantee in no way affects your rights under statutory law. .



You're reading an excerpt. Click here to read official BRAUN 8595 user guide

<http://yourpdfguides.com/dref/3290159>