



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN FG 1100. You'll find the answers to all your questions on the BRAUN FG 1100 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRAUN FG 1100
User guide BRAUN FG 1100
Operating instructions BRAUN FG 1100
Instructions for use BRAUN FG 1100
Instruction manual BRAUN FG 1100



www.braun.com/register



[You're reading an excerpt. Click here to read official BRAUN FG 1100 user guide](http://yourpdfguides.com/dref/3291093)
<http://yourpdfguides.com/dref/3291093>

Manual abstract:

We hope you will enjoy using the appliance. Please read the use instructions carefully and thoroughly before using it. Important Keep the appliance out of the reach of children. For hygienic reasons, do not share this appliance with other persons. do not use the appliance on irritated or inflamed skin. Never use the appliance with a damaged cutting head. Note: If the appliance is not used for long periods of time, do not leave the battery inserted (danger of leakage). Take an expired battery out of the appliance immediately. Used batteries should not be disposed of with the household waste. @@@@ For optimum results, pull the skin taut with one hand while using.

Turn the appliance off before changing the cutting heads. To remove the cutting head, rotate it counter-clockwise 90°, then lift it (b). To attach another one, insert it into the opening, then rotate 90° clockwise until it clicks into place. The precision cutting head (2) is perfect for detailing of eyebrows and removal of stray hairs on all body areas. The bikini zone cutting head (3) is ideally suited for use in the bikini area to cut precise lines or contours like the bikini line. 1 2 3 3a 3b 4 5 6 Protective cap Precision cutting head Bikini zone cutting head Bikini zone trimming comb, 5 mm Bikini zone trimming comb, 8 mm On/off switch «I/O» Battery compartment cover Brush This appliance operates with one AAA 1. Frequent use of the bikini zone cutting head (3) will reduce the operation time. Make sure the appliance is turned off. To attach a trimming comb, slide the pointed side over the cutting element, then press the round side onto the bikini zone cutting head so that it snaps into place. Guide the appliance with the trimming comb flat against the skin (d).

Subject to change without notice. Please do not dispose of this product in the household waste at the end of its useful life. Disposal can take place at a Braun Service Centre or at appropriate collection points provided in your country. Always turn off the appliance before cleaning.

@@@@@ This warranty does not cover: A. Damage arising from improper use or operation on incorrect voltages. Normal wear due to moving parts. Appliances that are outside the warranty period or are not faulty. This appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.

If the appliance is supplied from a cord extension set or electrical portable outlet device these should be positioned so they are not subject to splashing or ingress of moisture. To the extent permitted by the laws of the Commonwealth of Australia and New Zealand and applicable laws of a State or Territory of Australia, and subject to the second paragraph of this warranty above, this warranty is given in exchange for any other rights you may have against Procter & Gamble Australia Pty. Ltd. Or its distributors or manufacturer, whether at law, in tort (including negligence), in equity or under statute. Please retain proof of purchase of this appliance. If you have any questions in relation to this warranty, please call our Consumer Service line (see below for numbers). This warranty applies in all States and Territories of Australia and in New Zealand and is in addition to any mandatory statutory obligations imposed on Procter & Gamble Australia Pty. Ltd. , its distributors and its manufacturer. This express warranty does not purport to exclude, restrict or modify any such mandatory statutory obligations.

@@@@@ for service or replacement parts refer to the authorised Service Agents listed overleaf. Local Service Agents may change from time to time in that event please contact the Consumer Service free call number below for updated local service agent details. .



[You're reading an excerpt. Click here to read official BRAUN FG 1100 user guide](http://yourpdfguides.com/dref/3291093)
<http://yourpdfguides.com/dref/3291093>