



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 10E900 TO 10E999. You'll find the answers to all your questions on the BRIGGS & STRATTON 10E900 TO 10E999 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 10E900 TO 10E999
User guide BRIGGS & STRATTON 10E900 TO 10E999
Operating instructions BRIGGS & STRATTON 10E900 TO 10E999
Instructions for use BRIGGS & STRATTON 10E900 TO 10E999
Instruction manual BRIGGS & STRATTON 10E900 TO 10E999



FORM MS-9039-07/10/2008
REPLACES FORM MS-9039-06/2002/08
FILE IN SECT. 2 OF SERVICE MANUAL
10E900

Illustrated Parts List

Model Series

10E900

TYPE NUMBERS
0015 through 0862.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing/Shrouds	7
Brake	6
Camshaft	3
Carburetor	4
Controls	5
Crankcase Cover/Sump	3
Crankshaft	3
Cylinder	2
Cylinder Head	2
Exhaust System	6
Flywheel	7
Fuel Supply	4
Gasket Set - Engine	2
Gasket Set - Valve	2
Governor Spring	5
Ignition	5
Lubrication	2
Operator's Manual	2
Piston/Rings/Connecting Rod	3
Rewind Starter	7
Warning Label	2



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 10E900 TO 10E999 user guide](http://yourpdfguides.com/dref/3640330)

<http://yourpdfguides.com/dref/3640330>

Manual abstract:

2 OF SERVICE MANUAL 10E900 Illustrated Parts List Model Series 10E900 TYPE NUMBERS 0015 through 0862. TABLE OF CONTENTS Air Cleaner . . .

.

.

.

. 5 Blower Housing/Shrouds

. 7 Brake

.

.

. 6 Camshaft

.

.

. 3 Carburetor

.

. 4 Controls

.

.

. 5 Crankcase Cover/Sump

. 3 Crankshaft

.

.

. 3 Cylinder

.

.

. 2 Cylinder Head

.

. 2 Exhaust System

.

. 6 Flywheel

.

.

. 7 Fuel Supply

.

.

. 4 Gasket Set - Engine

.

. 2 Gasket Set - Valve

. 2 Governor Spring

.

. 5 Ignition

.

.

. 5 Lubrication

. 2 Operator's Manual

. 2 Piston/Rings/Connecting Rod .

. 3 Rewind Starter

. 7 Warning Label . . .

. 2 PRINTED IN U.

S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. @@@@ Parts shown without corresponding text may not be used on your specific engine. 5039-3 Assemblies include all parts shown in frames. 3 07/10/2008 10E900 90 976 163 97 633 130 529 913 365 106 393 617 612 394 390 724 180 957 190 670 190A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 5039-4 Assemblies include all parts shown in frames. 4 07/10/2008 10E900 202 202A 209 222E 222 222B 222D 621 188 333 222G 334 851 24 333B 851A 362 635 265 265A 265B 267 356 227 505 562 615 404 268 269 271 270 534 536 616 643 535A 535 163 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5039-5 Assemblies include all parts shown in frames. @@@@ 7 07/10/2008 10E900 REF. NO. 1 2 3 4 5 7 8 9 10 11 12 PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION REF. NO. 27 28 PART NO.

@0113, 0118. ----- Note ----- 691472 Crankshaft Used on Type No(s). 0015, 0100, 0111, 0112, 0116, 0117, 0120, 0121, 0207, 0459, 0462, 0550, 0772, 0826, 0862. 692989 Crankshaft Used on Type No(s). 0018, 0119. K391483S Seal-Oil (PTO Side) 692551 Screw (Crankcase Cover/Sump) 23 795549 Flywheel 24 222698S Key-Flywheel 25 790908 Piston Assembly (Standard) (Used After Code Date 04111400). ----- Note ----- 699657 Piston Assembly (Standard) (Used After Code Date 03080300 and Before Code Date 04111500). 790908 Piston Assembly (Standard) (Used Before Code Date 03080400). 792532 Piston Assembly (.020" Oversize) (Used After Code Date 04111400).

790909 Ring Set (Standard) (Used After Code Date 04111400). @498680 Ring Set (Standard) (Used Before Code Date 03080400).

@@@@@693446 Manifold-Intake (Used Before Code Date 03080400). K699649 Gasket-Intake (Used After Code Date 03080300). 270345S Gasket-Manifold (Used Before Code Date 03080400). @@@@8 07/10/2008 10E900 REF. NO. 65 73 74 78 81 90 97 106 130 163 180 188 190 190A 202 PART NO. DESCRIPTION REF. NO.

209 PART NO. DESCRIPTION REF. NO. PART NO. @Used on Type No(s).

0015, 0018, 0111. 697797 Spring- Governor (Gold) (Used Before Code Date 02091600). Used on Type No(s). 0207. 698727 Spring- Governor (Gray) (Used Before Code Date 02091600).

Used on Type No(s). 0100, 0112. Bracket-Control Used on Type No(s). 0459, 0462, 0550, 0772, 0826, 0862. @Used on Type No(s). 0207. Bracket-Control Used on Type No(s). 0100, 0111, 0112, 0113, 0116, 0117, 0119, 0120. ----- Note ----- 699577 Bracket- Control Used on Type No(s). 0118.

Bracket-Control (Used Before Code Date 02091600). Used on Type No(s). 0207. Bracket-Control Used on Type No(s). 0015, 0018. Bracket-Control Used on Type No(s). 0121. @697407 Link-Mechanical Governor (Used Before Code Date 03022000). 698726 Spring-Governor (Pink) Used on Type No(s). 0116, 0117, 0118, 0459, 0462, 0550, 0772, 0826, 0862.

@Used on Type No(s). 0113. 697801 Spring- Governor (Red) (Used After Code Date 02020700 and Before Code Date 02091600). Used on Type No(s). 0113.

697440 Spring- Governor (Brown) Used on Type No(s). 0113. (Used Before Code Date 02020800). 698719 Spring- Governor (Light Blue) Used on Type No(s). 0119, 0120, 0121.

698719 Spring- Governor (Light Blue) (Used After Code Date 02091500). Used on Type No(s). 0015, 0018, 0100, 0111, 0112, 0207. 222 698725 202A 222B 697410 222D 697796 222E 222G 227 699326 794780 697402 K Engine Gasket Set-Refernce 358 Valve Gasket Set-Reference 1095 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 5039-9 Assemblies include all parts shown in frames. 9 07/10/2008 10E900 REF. NO. 236 PART NO. DESCRIPTION REF.

NO. 304 PART NO. DESCRIPTION REF. NO. 346 PART NO. DESCRIPTION 691867 Link-Lockout Used on Type No(s). 0015, 0018. 692179 Clamp-Casing Used on Type No(s). 0118. 690798 Clamp-Casing Used on Type No(s).

0015, 0018, 0100, 0111, 0112, 0113, 0116, 0117, 0119, 0120. 691024 Clamp-Casing Used on Type No(s). 0121. 691044 Screw (Casing Clamp) 691025 Casing-Control Wire (72" Long) (Cut To Required Length) 691026 Wire-Control (78" Long) (Cut To Required Length) 691027 Nut (Control Wire Casing) 691028 Lever-Control 691002 Screw (Dipstick Tube) 692307 Muffler (Super Lo Tone) Used on Type No(s). @394569S Muffler (Round Lo Tone) Used on Type No(s).

0100, 0207, 0459, 0462. 697411 Housing-Blower (Compliance Engines) Used on Type No(s). @@@@0118, 0121. @690345 Screw (Cylinder Shield) (Used Before Code Date 04071400). @0772, 0826, 0862.

691061 Screw (Magneto Armature) 802592S Plug-Spark Used on Type No(s). 0015, 0018, 0100, 0111, 0112, 0119, 0207, 0772, 0826, 0862. ----- Note ----- 697451 Plug-Spark Used on Type No(s). 0113, 0116, 0117, 0118, 0120, 0121, 0459, 0462, 0550. 690661 Screw (Spark Arrester) Used on Type No(s). 0826.

692390 Wire-Stop 794209 Gasket Set-Engine 793351 Shield-Spark Plug Used on Type No(s). 0772, 0826, 0862. 19069 Puller-Flywheel 790029 Screw (Carburetor) 89838S Wrench-Spark Plug 691839 Spring-Choke Diaphragm 691837 Screen-Carburetor 795083 Diaphragm-Carburetor (Used After Code Date 07080800). ----- Note ----- 495770 Diaphragm- Carburetor (Used Before Code Date 07080900).

@@@@@10 07/10/2008 10E900 REF. NO. 536 562 592 597 608 PART NO. DESCRIPTION REF. NO. 745 PART NO. DESCRIPTION REF. NO. 869
PART NO. @0015, 0018, 0100, 0111, 0112, 0113, 0116, 0117, 0118, 0119, 0120, 0121, 0207, 0459, 0462, 0550, 0772, 0826, 0862.
496046S Tube-Pick Up 691413 Screw (Muffler) (Super Lo Tone) 690340 Retainer-Governor Shaft 697405 Crank-Governor 270344S Seal.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 10E900 TO 10E999 user guide](http://yourpdfguides.com/dref/3640330)

<http://yourpdfguides.com/dref/3640330>