



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 121600 TO 121699. You'll find the answers to all your questions on the BRIGGS & STRATTON 121600 TO 121699 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual BRIGGS & STRATTON 121600 TO 121699**
- User guide BRIGGS & STRATTON 121600 TO 121699**
- Operating instructions BRIGGS & STRATTON 121600 TO 121699**
- Instructions for use BRIGGS & STRATTON 121600 TO 121699**
- Instruction manual BRIGGS & STRATTON 121600 TO 121699**



FORM MS-2143-07/21/2008
REPLACES FORM MS-2143-06/27/2008
FILE IN SECT. 2 OF SERVICE MANUAL

121600

Illustrated Parts List

Model Series

121600

TYPE NUMBERS
0015 through 0668.

TABLE OF CONTENTS

Air Cleaner	6
Blower Housing/Shrouds	7
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Engine Sump	2
Exhaust System	6
Flywheel	7
Flywheel Brake	5
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets Sets	8
Lubrication	2
Piston Group	2
Rewind Starter	7



PRINTED IN U.S.A.

COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 121600 TO 121699 user guide](http://yourpdfguides.com/dref/3640228)

<http://yourpdfguides.com/dref/3640228>

Manual abstract:

2 OF SERVICE MANUAL 121600 Illustrated Parts List Model Series 121600 TYPE NUMBERS 0015 through 0668. TABLE OF CONTENTS Air Cleaner

.
.
.

. 6 Blower Housing/Shrouds

. 7 Camshaft . .
.
.
.

. . . . 2 Carburetor

.
.
. 4 Controls .

.
.
.
. 5 Crankshaft

.
.
.
. 2 Cylinder

.
.
. 2 Cylinder Head . .
.

.
.
. 3 Electric Starter
.
.

. 7 Engine Sump

.
.
. 2 Exhaust System

.
. 6 Flywheel .
.
.

. 7 Flywheel Brake
.
.

. . 5 Fuel Supply

.
.
. 4 Governor Spring

.
.
. 5 Ignition
.

.
. 5 Kits/Gaskets Sets . .
.
.

. 8 Lubrication

.
.
. 2 Piston Group

.
.
. 2 Rewind Starter
.

. 7 PRINTED IN U.

S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 121600 1058 OPERATOR'S MANUAL 1330 REPAIR MANUAL 1319 WARNING LABEL 1019 LABEL KIT 2 3 847 525

842 529 523 11A 1 REQUIRED when replacing parts with warning labels affixed.

584 684 585 306 718 524 287 9 28 27 29 25 27 16 307 32 32A 374 24 10 8 741 146 26 1102 1102A 4 12 4A 12 357 46 43 46A 374 4B 12 17 15A 20 20A 715 721 1027 1055 101 83 743 15 20 22 15 20 737 15 1024 965 943 1028 988 750 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 2143-2 Assemblies include all parts shown in frames. 2 07/21/2008 121600 5 883 51B 122 51A 51 619 886 7 993

1022 1034 718 33 40 34 40 868 45 36 238 1029 192 830 13 635A 635 383 35 1026 337 1023 1022 914 Illustrations cover a range of engines. @@@@Parts shown without corresponding text may not be used on your specific engine.

2143-4 Assemblies include all parts shown in frames. 4 07/21/2008 121600 222C 621 222E 222G 621 227 562 505 122 51 122 51 51B 222J 51A 51A 51 616 51B 51A 615 404 122 51B 843 188 122 51 209A 211 202 51B 472 51A 267 265A 265 268 269 270 271 604A 564A 935 745 1160 236 923 334 333 621 922

923B 922A 923A 621 922A 851 789 1119 474 990 356 356A 356B 910 341 493 532 347 578 356C 356D 789B 789C 789A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 2143-5 Assemblies include all parts shown in frames.

@@@@@@@@@ 07/21/2008 121600 121 CARBURETOR OVERHAUL KIT 51B 134 3 51B 358 ENGINE GASKET SET 842 51A 51 868 883 122 163 9 12 20 20A 585 163A 524 1022 993 51A 51 104 127 127A 137 163 163A 276 633 633A 7 122 977 CARBURETOR GASKET SET 51 137 7 51A 51B 163 163A 276

122 633 633A 51B 51A 1095 VALVE GASKET SET 883 51 993 122 868 1022 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 2143-8 Assemblies include all parts shown in frames. 8 07/21/2008 121600 REF. NO. 1 PART NO.

DESCRIPTION REF. NO. 5 PART NO. DESCRIPTION REF. NO. 16 PART NO. DESCRIPTION 790363 Cylinder Assembly (Used After Code Date 04040400). ----- Note ----- 499678 Cylinder- Assembly (Used Before Code Date 04040500). 790363 Cylinder Assembly (Used After Code Date 04040400). Used on Type No(s).

0324, 0333, 0343, 0365, 0372, 0373, 0382, 0518. 697639 Cylinder Assembly (Used Before Code Date 04040500). Used on Type No(s). 0324, 0333, 0343, 0365, 0372, 0373. 399269 Kit-Bushing/Seal (Magneto Side) K299819S Seal-Oil (Magneto Side) 493279 Sump-Engine ----- Note ----- 498983 Sump-Engine Used on Type No(s).

0030, 0045, 0142, 0188, 0189, 0235, 0313, 0386, 0545. 696294 Sump-Engine Used on Type No(s). 0288, 0295, 0323, 0325, 0329, 0345, 0347. 696340 Sump-Engine Used on Type No(s). 0359.

@@0270. 795501 Head-Cylinder (Used After Code Date 05110100). @@@@693291 Crankshaft Used on Type No(s). @@691458 Crankshaft Used on Type No(s). 0150,0153,0256,0319. 692716 Crankshaft Used on Type No(s). 0174,0201,0202,0215, 0220,0264,0272,0311, 0314,0360. 692803 Crankshaft Used on Type No(s). 0045,0188,0235,0545. 692823 Crankshaft Used on Type No(s).

0016,0022,0193,0194, 0227,0240,0241,0301, 0522,0622. 692824 Crankshaft Used on Type No(s). 0142. 694491 Crankshaft Used on Type No(s). 0026,0374,0375,0526. 695860 Crankshaft Used on Type No(s). 0281, 0393. 696607 Crankshaft Used on Type No(s). 0291, 0293. 790156 Crankshaft Used on Type No(s).

@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. @@9 07/21/2008 121600 REF. NO. 17 20 20A 22 23 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. 27 28 29 32 32A PART NO.

691866 499423 499424 691664 695759 DESCRIPTION Lock-Piston Pin Pin-Piston Rod-Connecting Screw (Connecting Rod) Screw (Connecting Rod) (Used After Code Date 00042200). Valve-Exhaust Valve-Intake Spring-Valve (Intake) Spring-Valve (Exhaust) Guard-Flywheel Retainer-Valve Slinger-Governor/Oil ----- Note ----- 691486 Slinger- Governor/Oil Used on Type No(s). 0030, 0045, 0142, 0188, 0189, 0235, 0545. Tappet-Valve 692517 Bearing-Ball K399781

Seal-Oil (PTO Side) K691952 Seal-Oil (PTO Side) (Auxiliary PTO) 691092 Screw (Crankcase Cover/Sump) 697610 Flywheel ----- Note ----- 692693 Flywheel Used on Type No(s). 0016,0030,0061,0117, 0119,0120,0129,0135, 0142,0149,0152,0160, 0172,0174,0183,0186, 0187,0189,0193,0194,

0197,0198,0200,0201, 0202,0206,0207,0209, 0211,0217,0218,0220, 0222,0242,0253,0254, 0260,0261,0262,0266, 0275,0281,0289,0293, 0296,0298,0302,0303, 0313,0314,0316,0317, 0318,0327,0330,0334, 0335,0348,0350,0354, 0357,0369,0379,0383, 0384,0386,0387,0388,

0389,0391,0395,0490, 0505,0561,0562. 692987 Flywheel Used on Type No(s). 0045,0188,0235, 0545. 697271 Flywheel Used on Type No(s). 0288,0295,0323,0325, 0329,0345,0347. 697637 Flywheel Used on Type No(s).

0147,0324,0333,0343, 0351,0365,0372,0373, 0382,0438. 699488 Flywheel Used on Type No(s). 0393. 24 222698S Key-Flywheel 25 795429 Piston Assembly (Standard) (Used After Code Date 07090300). ----- Note ----- 792004 Piston Assembly (Standard) (Used Before Code Date 07090400).

795430 Piston Assembly (.020" Oversize) (Used After Code Date 07090300). 791325 Piston Assembly (.020" Oversize) (Used Before Code Date 07090400). 26 795431 Ring Set (Standard) (Used After Code Date 07090300).

----- Note ----- 791969 Ring Set (Standard) (Used After Code Date 05030700 and Before Code Date 07090400). 499631 Ring Set (Standard) (Used Before Code Date 05030800). 795432 Ring Set (.020" Oversize) (Used After Code Date 07090300).

[You're reading an excerpt. Click here to read official BRIGGS &](#)



[STRATTON 121600 TO 121699 user guide](http://yourpdfguides.com/dref/3640228)
<http://yourpdfguides.com/dref/3640228>

791324 Ring Set (.020" Oversize) (Used After Code Date 05030700 and Before Code Date 07090400). 499427 Ring Set (.020" Oversize) (Used Before Code Date 05030800). 33 34 35 36 37 40 43 499642 499641 691304 691304 694086 692194 691997 45 690977 K Included in Engine Gasket Set-Ref. No.

358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines.

@@10 07/21/2008 121600 REF. NO. 46 PART NO. DESCRIPTION REF. NO.

83 PART NO. DESCRIPTION REF. NO. 117 PART NO. DESCRIPTION 694039 Camshaft (Used After Code Date 99030700).

----- Note ----- 694035 Camshaft (Used Before Code Date 99030800). ----- Note ----- 694040 Camshaft (Used After Code Date 99030700). Used on Type No(s). 0270. 46A 694038 Camshaft (Clockwise) (Used After Code Date 99030700). @@694037 Camshaft (Counterclockwise) (Used After Code Date 99030700). 694033 Camshaft (Counterclockwise) (Used Before Code Date 99030800). @@0147, 0150, 0153, 0158, 0343, 0371. 690527 Shaft-Auxiliary Drive Used on Type No(s). 0122, 0241.

@@@692677 Jet-Main (Standard) (Used Before Code Date 99030800). 694250 Jet-Main (Standard) (Used After Code Date 02050500). @@497466 Jet-Main (High Altitude) (Used After Code Date 03110600). @@@@691851 Spring- Governor Used on Type No(s). @@@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref.

No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines.

@@13 07/21/2008 121600 REF. NO. 222C PART NO. DESCRIPTION REF. NO.

222G PART NO. DESCRIPTION REF. NO. 227 236 238 240 259 265 265A 267 268 PART NO. DESCRIPTION 792397 Bracket-Control (Used After Code Date 05110100). @@792398 Bracket- Control (Used After Code Date 05110100). Used on Type No(s). @@692617 Bracket- Control (Used Before Code Date 05110200). Used on Type No(s). @@@@792401 Bracket- Control (Used After Code Date 05110100).

Used on Type No(s). 0147, 0152, 0207, 0262, 0298, 0303, 0317, 0318, 0343. 692616 Bracket- Control (Used Before Code Date 05110200). Used on Type No(s). 0147, 0152, 0207, 0262, 0298, 0303, 0317, 0318, 0343. 792400 Bracket- Control (Used After Code Date 05110100). Used on Type No(s). @@692722 Bracket- Control (Used Before Code Date 05110200). Used on Type No(s). @@792404 Bracket-Control (Used After Code Date 05110100).

@@@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. @@14 07/21/2008 121600 REF. NO. 304 PART NO. DESCRIPTION REF. NO. 305 306 307 309 PART NO. DESCRIPTION REF. NO. 374 383 404 425A 443B PART NO.

@@@695976 Housing- Blower Used on Type No(s). @@697270 Housing- Blower Used on Type No(s). 0288,0295,0323,0325, 0329,0345,0347. 695976 Housing- Blower (Used After Code Date 06081300). Used on Type No(s). 0322,0374. 499677 Housing- Blower (Used Before Code Date 06081400). Used on Type No(s). 0322,0374. 691108 Screw (Blower Housing) 691232 Shield-Cylinder 690345 Screw (Cylinder Shield) 695550676C 676D 677 684 689 692 697 715 718 721 727 737 742 743 608 613 613A 615 616 619 621 633 633A 635 635A 651 670 745 750 783 783A 784 785 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. @@16 07/21/2008 121600 REF. NO. 789 PART NO. DESCRIPTION REF. NO. 801 802 PART NO. DESCRIPTION REF. NO. 886 910 914 921A 922 922A 923 923A PART NO.

DESCRIPTION 696547 Harness-Wiring (Used After Code Date 00040600). @@696546 Harness- Wiring Used on Type No(s). 0298, 0303, 0311, 0314, 0324, 0343, 0351, 0365, 0372, 0373, 0562. 696546 Harness-Wiring (Used After Code Date 00040600). @@696545 Harness- Wiring Used on Type No(s). 0129, 0302, 0330, 0333, 0334, 0382. 695553 Harness-Wiring (Used After Code Date 00040300). Used on Type No(s). 0260. ----- Note ----- 694497 Harness-Wiring (Used Before Code Date 00040400).

Used on Type No(s). 0260. 694498 Harness-Wiring Used on Type No(s). 0129, 0302, 0330, 0333, 0334, 0382. 690782 Cap-Drive 695267 Cap-End (Used After Code Date 00040600).

----- Note ----- 695975 Cap-End (Used Before Code Date 00040700). 695266 Housing-Starter (Used After Code Date 00040600). ----- Note ----- 695975 Housing- Starter (Used Before Code Date 00040700). 694544 Stud-Rocker Arm 691466 Guard-Muffler (Super Lo Tone) 692984 Guard Muffler (Quiet Lo Tone) 695593 Guard Muffler (Square Lo Tone) 691147 Screw (Muffler Guard) 697551 Screw (Muffler Guard) 692198 Screw (Muffler Guard) K691031 Seal-O Ring (Dipstick Tube) 691884 Sleeve-Lever 692047 Dipstick/Tube Assembly 493880S Terminal-Spark Plug 695268 Adaptor-Wire ----- Note ----- 696842 Adaptor-Wire Used on Type No(s). 0389, 0562, 0660, 0662.

K692044 Seal-Valve K691893 Gasket-Exhaust 696268 Gasket Kit-Cylinder Head/Plate 691094 Stud (Alternator) 691108 Screw (Rocker Cover) 699633 Cover-Blower Housing 691831 Spring-Brake 692135 Spring-Brake 691994 Brake 695891 Brake ----- Note ----- 695891 Brake (Used Before Code Date 08050100). Used on Type No(s). 0112, 0127, 0332, 0346, 0358, 0370, 0374, 0392, 0397, 0467, 0529, 0555, 0668. 796136 Brake (Used After Code Date 08043000). Used on Type No(s). 0112, 0127, 0332, 0346, 0358, 0370, 0374, 0392, 0397, 0467, 0529, 0555, 0668. 795403 Cover-Linkage (Used After Code Date 07072200). @@@@No.358. D Included in Carburetor Overhaul Kit-Ref.

No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. @@17 07/21/2008 121600 REF. NO.

930A 935 937 943 946 957 957B 958 965 966B PART NO. @@0288, 0295, 0323, 0325, 0329, 0345, 0347. @@NO. PART NO. DESCRIPTION REF. NO. 1095 1102 PART NO. DESCRIPTION 993 K694088 Gasket-Cylinder Head Plate 994 692957 Arrestor-Spark 994A 398067 Arrestor-Spark 1005 691346 Fan-Flywheel 1009 696255 Screw (Starter Motor) 1019 499691 Kit-Label ----- Note ----- 790231 Kit-Label (Touch N Mow) 1022 K691890 Gasket-Rocker Cover 1023 499624 Cover-Rocker 1024 692508 Pump-Oil 1026 692045 Rod-Push 1027 692513 Filter-Oil 1028 692516 Adapter-Oil Filter 1029 691230 Arm-Rocker 1034 691343 Guide-Push Rod 1036 Label-Emissions (Available From A Briggs & Statton Authorized Dealer) 1055 692623 Tube-Oil Pump 1058 277102 Operator's Manual ----- Note ----- 276347 Operator's Manual (Touch N Mow) 1059 692311 Kit-Screw/Washer ----- Note ----- 696293 Kit-Screw/Washer (Touch N Mow) 792386 Gasket Set-Valve 691255 Pilot-Guide Used on Type No(s). 0045, 0189, 0235, 0313, 0545. 691266 Pilot-Guide Used on Type No(s).

0030, 0142, 0188. 692979 Screw (Alternator) ----- Note ----- 691183 Screw (Alternator) Used on Type No(s). 0324, 0333, 0343, 0351, 0365, 0372, 0373. 690345 Screw (Interlock Switch) 498144 Pulley/Spring Assembly (Pulley) 498144 Pulley/Spring Assembly (Spring) 695959 Starter-Mechanical 794467 Label-



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 121600 TO 121699 user guide](http://yourpdfguides.com/dref/3640228)
<http://yourpdfguides.com/dref/3640228>

No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref.

No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 2143-18 Assemblies include all parts shown in frames. 18 07/21/2008 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 121600 TO 121699 user guide](http://yourpdfguides.com/dref/3640228)

<http://yourpdfguides.com/dref/3640228>