



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 122702. You'll find the answers to all your questions on the BRIGGS & STRATTON 122702 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BRIGGS & STRATTON 122702**  
**User guide BRIGGS & STRATTON 122702**  
**Operating instructions BRIGGS & STRATTON 122702**  
**Instructions for use BRIGGS & STRATTON 122702**  
**Instruction manual BRIGGS & STRATTON 122702**

FORM MS5838-994  
REPLACES FORM MS5838-1993  
FILE IN SECT 2 OF SERVICE MANUAL  
**122700 to 122799**

## **Illustrated Parts List** **Model Series** **122700 to 122799**

**TYPE NUMBERS**  
0101 through 0108,  
0115 through 0213,  
3101 through 3108,  
3115 through 3155,  
3180 through 3185,  
3188 through 3183.

**TYPE NUMBERS**  
3188 through 3200,  
3207 through 3209,  
3212 through 3224,  
3300 through 3335,  
4000 through 4011,  
7002 through 7018.

### **TO FIND** **THE CORRECT NUMBER OF THE PART YOU NEED:** **FOLLOW THE INSTRUCTIONS BELOW**

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT ©



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 122702 user guide](http://yourpdfguides.com/dref/3639663)  
<http://yourpdfguides.com/dref/3639663>

**Manual abstract:**

@@@The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." B.

C. D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note." E.

If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply. F. PRINTED IN U.S.

A. COPYRIGHT BRIGGS & STRATTON © 122700 to 122799 572 11 307 3 54 625 52 9A 869 525 1 3 284 2 523 524 524 842 383 306 7 337 635 REF. NO. 1 2 3 5 7 8 9 9A 10 11 13 52 54 284 306 307 337 383 523 PART NO. 493260 293708 K299819 213861 K272200 494489 K272481 K272238 94222 231685 94547 K272199 94526 94511 224324 94515 847 523A 871 9 8 10 REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. REF. NO. 635 842 847 PART NO. DESCRIPTION 5 13 DESCRIPTION 870 307 1019 LABEL KIT 1058 OWNER'S MANUAL REF.

NO. PART NO. DESCRIPTION Note 493950 CapOil Fill (Used Before Code Date 92072700). CapOil Fill (Used After Code Date 89121300). Note 493459 CapOil Fill (Used Before Code Date 89121400). SealFiller Tube TubeOil Fill (Used After Code Date 92072600). Note 493952 TubeOil Fill (Used Before Code Date 92072700). BaffleCylinder ManifoldIntake Cylinder Bushing SealOil HeadCylinder GasketCylinder Head Breather Assembly GasketBreather GasketBreather ScrewBreather Mtg. TubeBreather ScrewCylinder Hd. GasketIntake Elbow ScrewInt.

Elbow Mtg. ScrewHex. Head ShieldCylinder ScrewHex. Head PlugSpark See Last Pages. 89838 WrenchSpark Plug 495264 CapOil Fill (Used After Code Date 92072600).

523A 493950 869 870 871 524 525 K280393 495265 572 625 224328 492717 1019 1058 66538 BootSpark Plug K280966 SealCap 495263 TubeOil Fill (Used After Code Date 92072600). Note 493459 TubeOil Fill (Used Before Code Date 92072700). 213512 SeatValve (Intake) 213513 SeatValve (Exhaust) 262001 BushingGuide (Exhaust) Note 63709 BushingGuide (Intake) 494256 Label Kit 272262 Owner's Manual K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No.

493762. z Included in Carburetor Gasket SetPart No. 490937. 58382 Assemblies include all parts shown in frames. 2 94 122700 to 122799 562 24 29 27 32 741 27 35 28 26 25 34 40 35 33 40 377 357 45 616 16 227 592 615 230 REF. NO. 16 24 25 PART NO. DESCRIPTION REF. NO. PART NO.

DESCRIPTION 493390 Ring Set (.030" O.S.) LockPiston Pin PinPiston (Standard) 298908 PinPiston (.005" O.S.) RodConnecting 490743 Rod Connecting (.020" Undersize) ScrewConnecting Rod ValveExhaust ValveIntake SpringValve RetainerValve REF. NO. 45 227 230 357 377 PART NO.

262204 492349 67072 91539 93065 DESCRIPTION TappetValve Lever AssemblyGov. WasherGov. Crank KeyDrive Pulley KeyWoodruff (For 7/8" Dia. Crankshaft) Note 94329 KeyWoodruff (For 25 mm. Crankshaft) BoltGovernor Lever NutHex.

Fastener CrankGovernor GearTiming 26 Crankshaft See Last Pages. 222698 KeyFlywheel 493262 Piston Assy. (Standard) 493385 Piston Assy. (.010" O.S.) 493386 Piston Assy. (.020" O.S.) 493387 Piston Assy. (.030" O.S.) 493261 Ring Set (Standard) 493388 Ring Set (.010" O.S.) 493389 Ring Set (.020" O.S.) 27 28 26026 298909 29 490566 32 33 34 35 40 94699 262651 262652 262224 93312 562 592 615 616 741 92613 231082 94474 262578 262598 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No.

490937. 58383 Assemblies include all parts shown in frames. 3 94 122700 to 122799 69B 46A 46 69B 15 15A 15 15A 12 263 12 721 720 83 83A 87 REF. NO. PART NO.

DESCRIPTION 47 22 18A 20 15B REF. NO. 12 15 15A 15B PART NO. DESCRIPTION 18 REF. NO.

20 PART NO. 22 DESCRIPTION 231909 ShaftDrive Used on Type No(s). 3320. GearDrive Note 231279 GearDrive Used on Type No(s). 0131, 0139, 0165, 0173, 0174, 0188, 0203, 0204, 3124, 3132, 3134, 3144, 3160, 3165, 3170, 3172, 3174, 3175, 3190, 3191, 3194, 3195, 3208, 3311, 3320. SealOil ScrewHex. Head PinRoll StopShaft 18 18A 20 22 46 46A K272198 GasketCrankcase 94239 PlugOil Drain 94613 PlugOil Drain (Hex. Socket) 94470 PlugPipe (Hex. Socket, 1/1627 NPTF) 493279 SumpEngine 493365 SumpEngine Used on Model Series 122782,122787. K399781 SealOil 94220 ScrewHex.

Head Note 94612 ScrewHex. Head One Used in Hole Nearest Breather. 492828 GearCam GearCam 47 69B 83 See Last Pages. 493737 SlingerOil (Used After Code Date 90030450 and 90031800). Note 492524 SlingerOil (Used Before Code Date 90030550 and 90031900). 68938 WasherThrust 231671 ShaftDrive Note 231711 ShaftDrive Used on Type No(s). 3170, 3191, 3195. 231748 ShaftDrive Used on Type No(s). 0165, 0173, 0174, 0205, 3130, 3132, 3160. 83A 231278 87 263 720 721 391484 94602 93474 224249 K Included in Gasket SetSee Ref.

358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937.

58384 Assemblies include all parts shown in frames. 4 94 122700 to 122799 209 271 269 201 618 467 843 188A 270 268 575 620A 202 620 98A 619 354 REF.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 122702 user guide](http://yourpdfguides.com/dref/3639663)  
<http://yourpdfguides.com/dref/3639663>

NO. 98A 188A 201 202 209 268 PART NO. 493280 94644 262579 262782 353 520 985 621 PART NO.  
 REF. NO. 618 PART NO. 670A DESCRIPTION REF. NO. 269 DESCRIPTION DESCRIPTION ScrewSpeed Adj. ScrewHex. Head Link Link SpringGovernor  
 See Last Pages. 66986 CasingWire (48" Long) Note If Longer Casing is Needed, Specify Length in Inches; if Shorter Casing is Needed, Cut to Length. 270  
 271 353 354 467 520 575 26099 WireControl (54" Long) Note If Longer Wire is Needed, Specify Length in Inches; if Shorter Wire is Needed, Cut to Length.

63426 LocknutCasing 290568 LeverControl 92791 WasherLock 90576 NutHex. 280857 Knob 93722 Terminal 396291 SwitchStarting Include(s): 392832 Key  
 Set 619 620 620A 621 670A 843 985 262749 SpringReturn (Used After Code Date 90060300). Note 260870 Spring Return (Used Before Code Date  
 90060400). 94620 ScrewHex. Hd. BracketControl See Last Pages. 494112 BracketControl 396847 SwitchStop K493823 Spacer (Includes 2) 272616 Sleeve-  
 Lever 398525 Insulator K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762.  
 z Included in Carburetor Gasket SetPart No. 490937. 58385 Assemblies include all parts shown in frames. 5 94 122700 to 122799 141 131 134 124 634 104  
 133 125 634 108 137 98 130 95 118 127 617 116 955 116 975 REF. NO.  
 PART NO. DESCRIPTION REF. NO. @@NO. @Mtg.  
 494216 Carburetor SEE NEXT PAGE FOR ADDITIONAL CARBURETOR. @@Used on Type No(s). @@No. M 26). @@0180, 0188, 0205, 3108, 3179,  
 3194, 3218. 493640 BowlFloat K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart  
 No.

@@@NO. PART NO. DESCRIPTION REF. NO. @@@@Mtg. @@358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket  
 SetPart No. @@@@Head PrimerCarburetor ScrewHex.  
 Head Grommet Grommet SwitchStop SpringBrake REF. NO. 923 935 942 966 922 258 163A PART NO. 493442 398758 493442 496116 REF. NO.  
 966A PART NO. 923 971A REF. NO. 163 163A 236 258 387 423 529 529A 621 922 PART NO. K272653 K272296 262461 94512 496115 93758 281299  
 280943 396847 262640 DESCRIPTION Brake SwitchInterlock BracketBrake BaseAir Cleaner (Primer Style) (Used After Code Date 93080100).  
 81 676E 613A 988 346 346A 832 346 676D 346 676 676A 346 676B REF. NO. 613A 676 676A 676B 676C 676D PART NO. @@NO. 676E 832 832A 883  
 988 994 PART NO. 494485 494224 494224 K272253 223828 494486 REF. NO. @@@@Head 94602 ScrewHex. @358. D Included in Carburetor KitPart  
 No.

493762. z Included in Carburetor Gasket SetPart No. @@@@NO. 65A 258 305A 333 334 356 PART NO. 94058 94512 94510 802574 93381 398808  
 DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. @@ScrewHex.  
 @@0163, 0188, 7015, 7016, 7018. 494714 WireStop Used on Type No(s). 3182. @@@@493380 HarnessWiring Used on Engines With Band Brake. Note  
 493648 Harness Wiring Used on Type No(s).

3154. 949A 949B 949C 221798 TerminalCable 281136 GuardFinger (Snap-In Style For 1-1/2 Quart Tanks) 280946 GuardFinger (Screwed in Style For 1-1/2  
 Quart Tanks) 281187 GuardFinger (Snap-In Style For 1 Quart Tanks) Use(s): 94639 ScrewMtg. 280980 GuardFinger (Screwed in Style For 1 Quart Tanks)  
 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No.  
 493762. z Included in Carburetor Gasket SetPart No. 490937. 583813 Assemblies include all parts shown in frames. 13 94 122700 to 122799 938 937 544  
 510 309 782 784 74 548 785 513 783 803 801 310 802 22A REF. NO. 22A 74 309 310 510 513 544 548 782 PART NO. 94268 93490 492336 94553 494147  
 394815 492921 492919 281127 DESCRIPTION ScrewStarter Mtg. ScrewSem MotorStarter BoltThru DriveStarter ClutchDrive ArmatureStarter Washer Set  
 GearStarter (Used After Code Date 90063000). REF.

NO. PART NO. DESCRIPTION Note 494146 PinionStarter (Includes Spline) (Used Before Code Date 90070100). GearStarter CoverGear GasketCover Cap-  
 Drive CapEnd HousingStarter REF. NO. 937 PART NO. DESCRIPTION 783 784 785 801 802 803 261606 224262 272201 492335 492922 492920 938  
 281125 SplineStarter (Used After Code Date 90063000). Note 494146 SplineStarter (Includes Pinion) (Used Before Code Date 90070100). 93941 Retainer-  
 Lock K Included in Gasket SetSee Ref. 358.  
 D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 583814 Assemblies include all parts shown in frames.  
 14 94 122700 to 122799 163A 670A 9A 9 883 842 358 GASKET SET 118 104 137 116 634 977 CARBURETOR GASKET SET REF. NO. PART NO. REF. NO.  
 134 PART NO. 163 7 12 3 20 52 524 134 127 617 116 617 137 634 121 CARBURETOR KIT DESCRIPTION REF. NO. PART NO. DESCRIPTION  
 DESCRIPTION 3 K299819 7 K272200 9 K272481 9A K272238 12 K272198 20 K399781 52 K272199 104 D231371 116 Dz 118 121 127 SealOil Gasket-  
 Cylinder Hd. GasketBreather GasketBreather GasketCrankcase SealOil GasketIntake Elbow PinFloat Hinge GasketSealing (Sold in Kit Only) D493765  
 Valve KitNeedle 493762 Carburetor Kit D PlugWelch (Sold in Kit Only) D398188 ValveNeedle (Includes Seat) 137 Dz GasketFloat Bowl (Sold in Kit Only)  
 163 K272653 GasketAir Cleaner 163A K272296 GasketAir Cleaner 358 496117 Gasket Set (Used After Code Date 93080100). Note 493263 Gasket Set  
 (Used Before Code Date 93080200). 524 K280393 SealFiller Tube 617 Dz270344 SealFuel Intake Tube 634 Dz WasherShaft (Sold in Kit Only) 670A  
 K493823 Spacer (Includes 2) (Sold in Kit Only) 842 K280966 SealO-Ring 883 K272253 GasketExhaust 977 490937 Gasket Set Carburetor K Included in  
 Gasket SetSee Ref. 358. D Included in Carburetor KitPart No.

493762. z Included in Carburetor Gasket SetPart No. 490937. 583815 Assemblies include all parts shown in frames. 15 94 122700 to 122799 REF. NO. 16  
 PART NO. DESCRIPTION REF. NO. PART NO.  
 DESCRIPTION REF. NO. PART NO. DESCRIPTION 262657 SpringGov. Used on Type No(s).  
 0206, 3135, 3136, 3141, 3143, 3151, 3163, 3164, 3178, 3179, 3182 3183, 3193, 3224, 3321, 3322. 262658 SpringGov. Used on Type No(s). 0173, 0184, 3127,  
 3170, 3216. 262659 SpringGov.  
 Used on Type No(s). 0126, 0147, 3106, 3118, 3131, 3137, 3138, 3160, 3168, 3175, 3181, 3194, 3198, 3199, 3200, 3207, 3208, 3209, 3212, 3215, 3218, 3221,  
 3310, 3311, 3320, 3324, 3328, 3331, 4005.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 122702 user guide](http://yourpdfguides.com/dref/3639663)  
<http://yourpdfguides.com/dref/3639663>

262661 SpringGov. Used on Type No(s). 0101, 0102, 0108, 0142, 0182, 3101, 3102, 3108, 3133, 3139, 3140, 3142, 3144, 3162, 3171, 3187, 3188, 3192, 3227, 3300, 3327, 4001, 4009, 7002. 262664 SpringGov. Used on Type No(s). 0125, 0134, 0151, 0155, 0162, 0163, 0166, 0169, 0170, 0190, 0191, 0192, 0193, 0194, 0196, 0197, 0199, 0200, 0201, 0202, 0208, 0212, 0213, 3122. 262665 SpringGov. Used on Type No(s).

0133, 0143, 0144, 0145, 0153, 0154, 0156, 0165, 0168, 0174. 493282 Crankshaft Note For Timing Gear Key. Order Part No. 94388. 493362 Crankshaft Used on Type No(s). 0119, 0120, 0173, 0174, 0175, 0184, 0185, 0188, 0190, 0199, 0200, 0205, 0213, 3117, 3136, 3137, 3142, 3144, 3146, 3148, 3149, 3154, 3155, 3160, 3161, 3174, 3175, 3181, 3190, 3191, 3193, 3194, 3195, 3196, 3198, 3200, 3208, 3209, 3212, 3213, 3215, 3216, 3218, 3223, 3310, 3311, 3312, 3320, 3324, 3331, 4005, 4007, 4008, 4009, 7015. 493363 Crankshaft Used on Type No(s). 0121, 0122, 3120, 3145, 3147, 3153, 3180, 3199, 3214, 3217, 3219, 3313, 3321, 3322, 3332, 3335, 7002, 7016. 493433 Crankshaft Used on Type No(s). 3131, 3207.

493464 Crankshaft Used on Type No(s). 0126, 3221. 493566 Crankshaft Used on Type No(s). 0176, 0181. 493946 Crankshaft Used on Type No(s). @@493947 Crankshaft Used on Type No(s). @@494546 Crankshaft Used on Type No(s). 0142, 0182, 0206, 3171, 3187, 3188, 3192. 493739 GearCam (Used After Code Date 90030450 and 90031800). 492668 GearCam (Used Before Code Date 90030550 and 90031900). @@492669 GearCam (Used Before Code Date 90030550 and 90031900). Used on Type No(s). @@262660 SpringGovernor Note 262654 SpringGov. Used on Type No(s). 0146. 262655 SpringGov. Used on Type No(s). 0183, 4007. 262656 SpringGov. Used on Type No(s).

0185, 3116, 3145, 3217. 46A 209 K Included in Gasket SetPart No. 493263. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 583816 Assemblies include all parts shown in frames. 16 94 122700 to 122799 REF. NO.

PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION 318201, 319502, 319801, 320001, 320801, 321201, 321302, 321402, 322101, 322401, 331001, 331201, 332001, 332401, 332801, 333502, 701601, 318301, 319601, 319901, 320701, 320901, 321301, 321401, 321901, 322301, 330001, 331101, 331302, 332101, 332701, 333101, 701501, 701801. 262666 SpringGov. Used on Type No(s).

0115, 0116, 0117, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0130, 0135, 0136, 0137, 0138, 0141, 0148, 0149, 0157, 0158, 0167, 0176, 0178, 0180, 0181, 0203, 0204, 3128. 262667 SpringGov. Used on Type No(s). 0152, 0160, 0161, 3172, . 262678 SpringGov. Used on Type No(s). 0129, 0131, 0132, 0139, 0140, 0165, 0179. 298809 PlugSpark (With Gasket) (1-1/2" High, 38 mm.) Note 293918 PlugSpark (Resistor Type) (1-1/2" High, 38 mm.) 492167 PlugSpark (1-7/8" High, 48 mm.

) 802592 PlugSpark (Resistor Type) (1-7/8" High, 48 mm.) 495975 BracketControl (Remote Control) (Used After Code Date 93080100). 493894 Bracket Control (Remote Control) (Used Before Code Date 93080200 and After Code Date 90030450 and 90031800). 492978 Bracket Control (Remote Control) (Used Before Code Date 90030550 and 90031900). Note 495976 Bracket Control (Man. Friction Control) (Used After Code Date 93080100). 493895 Bracket Control (Man. Friction Control) (Used Before Code Date 93080200 and After Code Date 90030450 and 90031800). 493635 Bracket Control (Man. Friction Control) (Used Before Code Date 90030550 and 90031900).

Used on Type No(s). 0129, 0130, 0131, 0146, 0158, 0163, 0176, 0181, 0183, 3190, 4005, 4006, 4007, 7015, 7016, 7018. 494528 TankFuel (1-1/2 Quart, Black) (Used After Code Date 90092300). 494340 TankFuel (1-1/2 Quart, Black) (Used Before Code Date 90092400). Note 494351 TankFuel (1 Quart, Black) (Used After Code Date 90092300).

494534 TankFuel (1 Quart, Black) (Used Before Code Date 90092400). Used on Type No(s). 013601, 016801, 019001, 019101, 019201, 019301, 019401, 020001, 020101, 020801, 021201, 021301, 020301, 310601, 312201, 314601, 314701, 314801, 315101, 316001, 316201, 316301, 316401, 316501, 317201, 317501, 317801, 318101, 337 972 620 494353 TankFuel (1-1/2 Quart, Yellow) Used on Type No(s). 319102. 494355 TankFuel (1-1/2 Quart, Gray) Used on Type No(s).

013101, 321501. 494356 TankFuel (1-1/2 Quart, Red) Used on Type No(s). 013204, 016901, 314903. 494357 TankFuel (1 Quart, Red) Used on Type No(s). 017501, 314803. 494358 TankFuel (1.3 Quart, Black) Used on Type No(s). 014701, 018101, 020601, 311801, 313401, 314501, 317101, 318701, 318801. 494359 TankFuel (1 Quart, Yellow) Used on Type No(s). 314602, 314702.

495065 TankFuel (1-1/2 Quart, Black with Dry Primer Hole) Used on Type No(s). 010801, 018801, 020501, 310801, 317901, 317902, 319401, 321801. K Included in Gasket SetPart No. 493263. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 583817 Assemblies include all parts shown in frames. 17 94 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 122702 user guide](http://yourpdfguides.com/dref/3639663)  
<http://yourpdfguides.com/dref/3639663>