



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 122802. You'll find the answers to all your questions on the BRIGGS & STRATTON 122802 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 122802
User guide BRIGGS & STRATTON 122802
Operating instructions BRIGGS & STRATTON 122802
Instructions for use BRIGGS & STRATTON 122802
Instruction manual BRIGGS & STRATTON 122802

FORM MS-2598-994
REPLACES FORM MS-2598-993
FILE IN SECTION OF SERVICE MANUAL
122800 to 122899

Illustrated Parts List Model Series 122800 to 122899

TYPE NUMBERS
0220, 0235,
0430 through 0435,
3201 through 3214,
3401 through 3422.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical List where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT ©



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 122802 user guide](http://yourpdfguides.com/dref/3640324)
<http://yourpdfguides.com/dref/3640324>

Manual abstract:

2 OF SERVICE MANUAL 122800 to 122899 Illustrated Parts List Model Series 122800 to 122899 TYPE NUMBERS 0220, 0235, 0430 through 0435, 3201 through 3214, 3401 through 3422. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. @@The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. @@After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed.

THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." B. C. D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types.

@@@@@NO. 1 2 3 5 7 8 9 9A 10 11 13 52 54 230 PART NO. 493260 293708 K299819 213861 K272200 494489 K272481 K272238 94650 231685 94547 K272199 94526 67072 5 13 DESCRIPTION Cylinder Assembly Bushing SealOil HeadCylinder GasketCylinder Head Breather Assembly Gasket-Breather GasketBreather ScrewHex. Head TubeBreather ScrewCylinder Hd. GasketIntake Elbow ScrewHex.

Head WasherThrust REF. NO. 870 1019 LABEL KIT 1058 OWNER'S MANUAL PART NO. DESCRIPTION 10 REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. PART NO. DESCRIPTION REF. NO. 635 869 870 871 227 307 337 383 562 572 592 615 616 625 492349 Lever AssemblyGov. 94515 ScrewHex.

Head 492167 PlugSpark (17/8" High, 48 mm) Note 802592 PlugSpark (Resistor Type) (17/8" High, 48 mm) 89838 WrenchSpark Plug 92613 BoltGovernor Lever 224328 BaffleCylinder 231082 NutHex. 94474 Fastener 262578 CrankGovernor 492717 ManifoldIntake 1019 1058 66538 BootSpark Plug 213512 SeatValve (Intake) 213513 SeatValve (Exhaust) 262001 GuideExhaust Valve Note 63709 GuideIntake Valve 494256 Label Kit 272262 Owner's Manual K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@@NO. 16 PART NO. DESCRIPTION REF. NO.

PART NO. DESCRIPTION REF. NO. @@94388. 493362 Crankshaft Used on Type No(s).

0220, 0431, 0435, 3211, 3409, 3413, 3414. 493363 Crankshaft Used on Type No(s). 0235, 3213, 3411. 493947 Crankshaft Used on Type No(s). 3412. 496078 Crankshaft Used on Type No(s). 3416. 24 25 26 496809 Crankshaft Used on Type No(s). 3214. 222698 KeyFlywheel 493262 Piston Assy. (Standard) 493385 Piston Assy. (.010" O.S.) 493386 Piston Assy.

(.020" O.S.) 493387 Piston Assy. @@@@358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@3 94 122800 to 122899 46 523 524 15 12 47 284 525 18 20 22 842 847 REF. NO.

12 15 18 20 22 PART NO. K272198 94613 493279 K399781 94220 DESCRIPTION REF. NO. 523 PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION 46 47 284 GasketCrankcase PlugOil Drain SumpEngine SealOil ScrewHex. Head Note 94612 ScrewHex. Head One Used in Hole Nearest Breather.

492828 GearCam 493737 SlingerOil 94511 ScrewHex. Hd. 524 525 495264 CapOil Fill (Used After Code Date 92072600). Note 493950 CapOil Fill (Used Before Code Date 92072700). K280393 SealFill Tube 495265 TubeOil Fill (Used After Code Date 92072600). 842 847 Note 493952 TubeOil Fill (Used Before Code Date 92072700). K280966 SealCap 495263 Tube Assy.Oil (Used After Code Date 92072600). @358. D Included in Carburetor KitPart No.

493762. z Included in Carburetor Gasket SetPart No. @@@@NO. 98A 188A 201 209 PART NO. 493280 94644 262579 262659 REF. NO. PART NO. REF. NO. PART NO.

DESCRIPTION ScrewSpeed Adj. ScrewHex. @@Used on Type No(s). 3212. 262660 SpringGov.

Used on Type No(s). 0235, 3409, 3411, 3416. 262661 SpringGov. Used on Type No(s). 3201, 3208,, 3412.

262662 SpringGov. Used on Type No(s). 3214, 3413, 3414. 262664 SpringGov. Used on Type No(s). @@LocknutCasing LeverControl ScrewHex. Hd.

@@@@@Used on Type No(s). 0431. 262667 SpringGov.

Used on Type No(s). 3422. @@@@358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@@NO. PART NO. DESCRIPTION REF. NO.

@@@@NO. @@494216 Carburetor Note 493627 Carburetor (For Primer) (Used Before Code Date 93080200). Used on Type No(s). 3208, 3211, 3213, 3408, 3409, 3411, 3412, 3413. 223470 493267 398187 D398188 137 Dz 141 494218 617 Dz270344 634 Dz 975 493763 ScrewBowl Mtg.

OR 494870 ScrewBowl Mtg. (High Altitude) Note 496063 ScrewBowl Mtg. OR 494870 ScrewBowl Mtg. (High Altitude) (Used Before Code Date 93080200). Used on Type No(s).

3208, 3211, 3213, 3408, 3409, 3411, 3412, 3413. 493640 BowlFloat K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@@NO. PART NO. REF. NO.

127 130 131 133 134 D 223470 493267 398187 D398188 PART NO. REF. NO. @@Mtg. @358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@@NO. 163 163A 265 265A 267 387 529 529A 606 PART NO.

K272653 K272296 213146 221535 94694 496115 281299 280943 224815 DESCRIPTION GasketAir Cleaner GasketAir Cleaner ClampCasing ClampCasing ScrewClamp Mtg. PrimerCarburetor Grommet Grommet StrapBracket 967 966A REF. NO. 966 PART NO. DESCRIPTION REF.

NO. 967 968 968A 969 969A 971 971A 971B PART NO. 491588 281340 281069 94120 94173 94121 94749 94269 DESCRIPTION FilterAir CoverAir Cleaner CoverAir Cleaner ScrewAir Cleaner ScrewAir Cleaner ScrewAir Cleaner ScrewHex. Head ScrewHex. Head 966A 496116 BaseAir Cleaner (Primer Style) (Used After Code Date 93080100).

494670 BaseAir Cleaner (Metal) (Used Before Code Date 93080200) K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@@NO. 55 56 57 58 59 PART NO. REF. NO. 60 69 69A 456 459 461 515 PART NO.

[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 122802 user guide](#)



<http://yourpdfguides.com/dref/3640324>

393152 280973 224322 224321 492833 262626 262625 REF. NO. @@Hd. 92987 NutHex. 223294 Stopt No. 493762. z Included in Carburetor Gasket Set-
Part No. @@@@NO. PART NO. REF.

NO. 134 PART NO. 137 617 634 121 CARBURETOR KIT REF. NO. PART NO.

DESCRIPTION DESCRIPTION DESCRIPTION Note 493263 Gasket Set (Used Before Code Date 93080200). SealFill Tube SealFuel Intake Tube Washer-
Shaft (Sold in Kit Only) Spacer (Includes 2) Seal GasketExhaust Pipe Gasket SetCarb. 3 K299819 7 K272200 9 K272481 9A K272238 12 K272198 20
K399781 52 K272199 104 D231371 116 Dz 118 121 127 SealOil GasketCylinder Hd. GasketBreather GasketBreather GasketCrankcase SealOil Gasket-
Intake Elbow PinFloat Hinge GasketSealing (Sold in Kit Only) D493765 Valve KitNeedle 493762 Carburetor Kit D PlugWelch (Sold in Kit Only) D398188
ValveNeedle (Includes Seat) 137 Dz GasketFloat Bowl (Sold in Kit Only) 163 K272653 GasketAir Cleaner 163A K272296 GasketAir Cleaner 358 496117
Gasket Set (Used After Code Date 93080100). 524 K280393 617 Dz270344 634 Dz 670A 842 883 977 K493823 K280966 K272253 490937 K Included in
Gasket SetSee Ref.

358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 256914 Assemblies include all parts shown in
frames. 14 94 .



[You're reading an excerpt. Click here to read official BRIGGS &
STRATTON 122802 user guide
http://yourpdfguides.com/dref/3640324](http://yourpdfguides.com/dref/3640324)