



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 124000 TO 124999. You'll find the answers to all your questions on the BRIGGS & STRATTON 124000 TO 124999 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual BRIGGS & STRATTON 124000 TO 124999**
- User guide BRIGGS & STRATTON 124000 TO 124999**
- Operating instructions BRIGGS & STRATTON 124000 TO 124999**
- Instructions for use BRIGGS & STRATTON 124000 TO 124999**
- Instruction manual BRIGGS & STRATTON 124000 TO 124999**



FORM MS-3249-06/09/2008
REPLACES FORM MS-3249-04/15/2008
FILE IN SECT. 2 OF SERVICE MANUAL
124000

Illustrated Parts List Model Series 124000

TYPE NUMBERS
0101, 0267.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Exhaust System	5
Flywheel	5
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets - Carburetor	4
Kits/Gaskets - Engine	2
Kits/Gaskets - Valves	3
Lubrication	2
Piston Group	2
Rewind Starter	5



PRINTED IN U.S.A.
COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124000 TO 124999 user guide](http://yourpdfguides.com/dref/3640298)
<http://yourpdfguides.com/dref/3640298>

Manual abstract:

.....
.....
.....
... 5 Blower Housing

.....
.... 5 Camshaft .
.....
.....

.....
. 2 Carburetor

.....
..... 4 Controls

.....
.....
.....

.... 5 Crankcase Cover

.....
.....
... 2 Crankshaft

.....
.....
... 2 Cylinder ..

.....
.....
. 2 Cylinder Head

.....
..... 3 Exhaust System ..

.....
.....
..... 5 Flywheel ..

.....
.....
.....

..... 5 Fuel Supply

.....
.....
.... 4 Governor Spring .

.....
.....

..... 5 Ignition .

.....
.....
.....

..... 5 Kits/Gaskets - Carburetor ...

.....
... 4 Kits/Gaskets - Engine ..

.....
.....

... 2 Kits/Gaskets - Valves

.....
... 3 Lubrication ..

.....

.....
.. 2 Piston Group ...

.....
..... 2 Rewind Starter

.....
..... 5 PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 124000 1319 WARNING LABEL 1058 OPERATOR'S MANUAL 1330 REPAIR MANUAL 1019 LABEL KIT REQUIRED when replacing parts with warning labels affixed. 847 523 18A 12 17 1 616 615 287 552 842 415 2 3 524 20 21 306 307 286 718 15 15A 22 742 746 219 220 1305 364 1052 799 25 26 46 16 27 146 741 332 27 32A 358 ENGINE GASKET SET 3 20 29 28 30 32 24 12 163A 1022 868 883 883A 993 7 51 Illustrations cover a range of engines. @2 06/09/2008 124000 383 337 635A 45 1026 5 34 40 35 868 238 122 51 192 1029 36 33 40 238 155 1022 619 830 13 1034 993 7 1095 VALVE GASKET SET 51 868 7 1022 1023 914 914A 993 1022 914B Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3249-3 Assemblies include all parts shown in frames. 3 06/09/2008 124000 125 NOTE: This Illustration Represents Several Carburetors. Parts Shown May Not Be Included In All Kits. @@@@5 06/09/2008 124000 REF.

NO. 1 2 PART NO. DESCRIPTION REF. NO. 26 PART NO.

DESCRIPTION REF. NO. 55 PART NO. DESCRIPTION REF. NO. 699505 Cylinder Assembly 399269 Kit-Bushing/Seal (Magneto Side) 3 K299819S Seal-Oil (Magneto Side) 5 699486 Head-Cylinder 7 K698210 Gasket-Cylinder Head 11A 693647 Tube-Breather (High Mount Air Cleaner) 12 K699485 Gasket-Crankcase 13 699482 Screw (Cylinder Head) 15 691686 Plug-Oil Drain (Square Head) 15A 691682 Plug-Oil Drain (Flush) 16 699449 Crankshaft Used on Type No(s). 0267.

----- Note ----- 699443 Crankshaft Used on Type No(s). 0101. 17 692517 Bearing-Ball 18A 699672 Cover-Crankcase 20 K692550 Seal-Oil (PTO Side) 21 281658S Cap-Oil Fill 22 699478 Screw (Crankcase Cover/ Sump) 23 699488 Flywheel 24 222698S Key-Flywheel 25 792004 Piston Assembly (Standard) ----- Note ----- 791325 Piston Assembly (.020" Oversize) 791969 Ring Set (Standard) (Used After Code Date 05030800). ----- Note ----- 499631 Ring Set (Standard) (Used Before Code Date 05030900). @@@@@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. @6 06/09/2008 124000 REF. NO. 78 PART NO. DESCRIPTION REF.

NO. 192 209 209A 219 220 222 222D 227 PART NO. @@Bracket-Control (Used After Code Date 06051400). @NO. 332 333 334 337 347 356A 356B 356C 358 363 364 365 383 415 427 445A 455 456 459 467 504 505 523 524 552 562 597 601 PART NO.

DESCRIPTION 699205 Screw (Flywheel Guard) 95 691636 Screw (Throttle Valve) 97 690024 Shaft-Throttle 98 398185 Kit-Idle Speed (Carburetor) 104 D691242 Pin-Float Hinge 108 692567 Valve-Choke 109A 693628 Shaft-Choke 117 698344 Jet-Main (Standard) 118 694176 Jet-Main (High Altitude) 121 792006 Kit-Carburetor Overhaul 122 KD693749 Spacer-Carburetor 125 698475 Carburetor 127 D691739 Plug-Welch 130 691181 Valve-Throttle 133 398187 Float-Carburetor 134 D398188 Kit-Needle/Seat 137 D:693981 Gasket-Float Bowl 146 690979 Key-Timing 155 K698214 Plate-Cylinder Head 163AKDz792870 Gasket-Air Cleaner (High Mount) 186 692317 Connector-Hose 187 791766 Line-Fuel (Cut to Required Length) 187B 791874 Line-Fuel (Molded) 187C 791866 Line-Fuel (Molded) 188 699479 Screw (Control Bracket) 190 699220 Screw (Fuel Tank) 792723 Nut (Flywheel) 695711 Armature-Magneto 699477 Screw (Magneto Armature) 491055S Plug-Spark 697854 Switch-Rocker 692390 Wire-Stop 692602 Wire-Stop 695630 Wire-Stop 791797 Gasket Set-Engine 19203 Puller-Flywheel 695693 Terminal-Oil Plug 699484 Screw (Carburetor) 19374S Wrench-Spark Plug 693463 Plug 694255 Nut (Control Bracket) 697029 Filter-Air Cleaner Cartridge (High Mount) 692591 Cup-Flywheel 692299 Plate-Pawl Friction 281505S Pawl-Ratchet 691668 Knob-Air Cleaner 694254 Washer Set-Friction 691251 Nut (Governor Control Lever) 693618 Dipstick 281370S Seal-Dipstick Tube 692346 Bushing-Governor Crank 691119 Bolt (Governor Control Lever) 691696 Screw (Pawl Friction Plate) 791850 Clamp-Hose 238 691300 240 394358S 265 691024 267 699492 268 269 270 276 281 286 287 300A 304 305 306 307 691025 691026 691027 D271716 793122 698611 699629 699231 699598 699480 693610 699483 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No.

121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3249-7 Assemblies include all parts shown in frames. 7 06/09/2008 124000 REF.

NO. 608 PART NO. DESCRIPTION REF. NO. @@@@NO. 957 958 961 PART NO. DESCRIPTION 795930 Starter-Rewind (Used After Code Date 08030200). @@@@(Rewind Starter Parts Used With 5MM Diameter Starter Rope) 699480 Screw (Muffler) 697812 Screw (Muffler) 692576 Retainer-Governor Shaft 692547 Crank-Governor 699480 Screw (Cylinder Head Plate) 692310 Switch-Stop 693408 Spring/Link-Mechanical Governor Dz693867 Seal-Choke/Throttle Shaft Dz691321 Seal-Choke/Throttle Shaft 692927 Boot-Spark Plug 699206 Screw (Control Panel) 694257 Spacer 691855 Spring-Friction 792647 Cap-Fuel Tank 698180 Valve-Fuel Shut Off 698304 Screw (Air Cleaner Bracket) 967A 273356S Filter-Pre Cleaner (High Mount) 968A 693460 Cover-Air Cleaner (High Mount) 971A 690349 Screw (Air Cleaner Base) 971B 699629 Screw (Air Cleaner Base) 972 694260 Tank-Fuel 975 493640 Bowl-Float 977 792007 Gasket Set-Carburetor 993 694088 Gasket-Cylinder Head Plate 1005 692592 Fan-Flywheel 1005A 794273 Fan-Flywheel 1019 694852 Kit-Label 1022 K691890 Gasket-Rocker Cover 1023 499924 Cover-Rocker Arm 1026 790287 Rod-Push 1029 691230 Arm-Rocker 1034 691343 Guide-Push Rod 1036 Label-Emissions (Available From An Authorized Briggs & Stratton Service Dealer) 1052 790141 Sensor-Oil 1058 277040 Operator's Manual 1070 699201 Screw (Flywheel Fan) 1095 791798 Gasket Set-Valve 613A 613B 615 616 619 621 632 633 633A 635A 663 668 689 851 493880S 863 699229 864 699232 868 K692044 875 697030 883 883A 914 914A 914B K691893 K692237 699480 692557 697551 K Included in Engine Gasket Set-Ref.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124000 TO 124999 user guide](http://yourpdfguides.com/dref/3640298)
<http://yourpdfguides.com/dref/3640298>

No.358.

D Included in Carburetor Overhaul Kit-Ref. No. 121. Included in Carburetor Gasket Set-Ref. No.

977. Included in Valve Gasket Set-Ref. No 1095. z Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3249-8 Assemblies include all parts shown in frames. 8 06/09/2008 124000 REF. NO. 1210 PART NO. DESCRIPTION REF. NO. 1211 PART NO. DESCRIPTION REF. NO. 1305 1319 1330 PART NO.

@@@@@ (Rewind Starter Parts Used With 5MM Diameter Starter Rope) 791849 Pulley/Spring Assembly (Spring) (Us.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124000 TO 124999 user guide](http://yourpdfguides.com/dref/3640298)
<http://yourpdfguides.com/dref/3640298>