



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 124300 TO 124399. You'll find the answers to all your questions on the BRIGGS & STRATTON 124300 TO 124399 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual BRIGGS & STRATTON 124300 TO 124399**
- User guide BRIGGS & STRATTON 124300 TO 124399**
- Operating instructions BRIGGS & STRATTON 124300 TO 124399**
- Instructions for use BRIGGS & STRATTON 124300 TO 124399**
- Instruction manual BRIGGS & STRATTON 124300 TO 124399**



FORM MS-5732-06/10/2008
REPLACES FORM MS-5732-04/15/2008
FILE IN SECT. 2 OF SERVICE MANUAL

124300

Illustrated Parts List

Model Series

124300

TYPE NUMBERS
0033 through 0178.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Gear Reduction	6
Ignition	5
Kits/Gaskets - Carburetor	4
Kits/Gaskets - Engine	2
Kits/Gaskets - Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124300 TO 124399 user guide](http://yourpdfguides.com/dref/3640328)

<http://yourpdfguides.com/dref/3640328>

Manual abstract:

2 OF SERVICE MANUAL 124300 Illustrated Parts List Model Series 124300 TYPE NUMBERS 0033 through 0178. TABLE OF CONTENTS Air Cleaner

.
.
.
. 5 Blower Housing

.
.
. 6 Camshaft
.

.
. 2 Carburetor
.
.

. 4 Controls
.
.

. 5 Crankcase Cover
.
. 2 Crankshaft

.
.
.
. 2 Cylinder

.
.
. 2 Cylinder Head
.

.
. 3 Exhaust System
.
.

. 5 Flywheel
.
. 6 Fuel Supply

.
.
. 4 Governor Spring

.
. 5 Gear Reduction
.
.

. 6 Ignition
.
.

. 5 Kits/Gaskets - Carburetor
. 4 Kits/Gaskets - Engine
.
. 2 Kits/Gaskets - Valve

Rocker 1034 691343 Guide-Push Rod 1036 Label-Emissions (Available From An Authorized Briggs & Stratton Sevice Dealer) 1052 790141 Sensor-Oil 1058 277040 Operator's Manual 1070 699201 Screw (Flywheel Fan) 1095 791798 Gasket Set-Valve 791849 Pulley/Spring Assembly (Pulley) (Used After Code Date 08030200).



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124300 TO 124399 user guide](http://yourpdfguides.com/dref/3640328)
<http://yourpdfguides.com/dref/3640328>

----- Note ----- 498144 Pulley/Spring Assembly (Pulley) (Used Before Code Date 08030300). @@@@ (Rewind Starter Parts Used With 5MM Diameter Starter Rope) 699691 Screw (Oil Sensor Module) 794467 Label-Warning 272147 Repair Manual 699887 Filter-Filler Neck 792917 Filter-Filler Neck 790334 Sprocket-Gear Reduction 790335 Chain-Gear Reduction 790336 Shaft-Output Gear Reduction 690936 Screw (Gear Reduction Sprocket) 790338 Washer (Gear Reduction Sprocket) 1368 1211 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. Included in Carburetor Gasket Set-Ref. No. 977.
Included in Valve Gasket Set-Ref. No 1095. z Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 5732-11 Assemblies include all parts shown in frames. 11 06/10/2008 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124300 TO 124399 user guide](http://yourpdfguides.com/dref/3640328)
<http://yourpdfguides.com/dref/3640328>