



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 124702. You'll find the answers to all your questions on the BRIGGS & STRATTON 124702 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BRIGGS & STRATTON 124702**  
**User guide BRIGGS & STRATTON 124702**  
**Operating instructions BRIGGS & STRATTON 124702**  
**Instructions for use BRIGGS & STRATTON 124702**  
**Instruction manual BRIGGS & STRATTON 124702**



0 24847 09277 4

FORM MS-5839-994  
REPLACES FORM MS-5839-10783  
FIELD SUBJECT: 2007 SERVICE MANUAL  
**124700 to 124799**

## Illustrated Parts List Model Series 124700 to 124799

TYPE NUMBERS  
0101, 0102, 0106,  
0108, 0109,  
0115 through 0224,  
0415, 0418, 0467, 0468,  
0601 through 0833,  
3101 through 3108,  
3110 through 3163,  
3167 through 3181.

TYPE NUMBERS  
3184 through 3263,  
3601 through 3611,  
4000 through 4006,  
5000 through 5008,  
7015 through 7019,  
7024, 7025, 7026,  
7050, 7051, 7055,  
7060, 7069, 7090.

### TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- Refer to the Illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT BY BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124702 user guide](http://yourpdfguides.com/dref/3639623)  
<http://yourpdfguides.com/dref/3639623>

**Manual abstract:**

The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types.

If your Type number is listed under "Note," order the part referred to at the "Note." If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply. PRINTED IN U.S.

A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. B. C.

D. E. F. 124700 to 124799 572 11 307 3 54 9A 625 52 869 525 1 3 284 2 523 524 842 383 306 7 337 635 REF. NO. 1 2 3 5 7 8 9 9A 10 11 13 52 54 284 306 307 337 PART NO. 493260 293708 K299819 213861 K272200 494489 K272481 K272238 94650 231685 94547 K272199 94526 94511 224324 94515 298809 847 871 9 8 10 REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. PART NO. DESCRIPTION TubeOil Fill See Last Pages.

BaffleCylinder ManifoldIntake BootSpark Plug SealCap TubeOil Fill (Used After Code Date 92072600). Note 493459 TubeOil Filler (Used Before Code Date 92072700). SeatValve (Intake) Seat Valve (Exhaust) BushingGuide Note 63709 BushingGuide Label Kit Owner's Manual 5 13 DESCRIPTION REF. NO. 870 307 1019 LABEL KIT 1058 OWNER'S MANUAL PART NO. DESCRIPTION REF. NO. 525 572 625 635 842 847 Cylinder Assembly Bushing SealOil HeadCylinder GasketCylinder Head Breather Assembly GasketBreather GasketBreather ScrewHex. Hd. TubeBreather ScrewCylinder Hd.

GasketIntake Elbow ScrewHex. Head ScrewHex. Head ShieldCylinder ScrewHex. Head PlugSpark (With Gasket) (1-1/2" High, 38 mm) 383 523 524 Note 293918 PlugSpark (Resistor Type) (1-1/2" High, 38 mm) 492167 PlugSpark (1-7/8" High, 48 mm) 802592 PlugSpark (Resistor Type) (1-7/8" High, 48 mm) 89838 WrenchSpark Plug 495264 CapOil Fill (Used After Code Date 92072600). Note 493950 CapOil Fill (Used Before Code Date 92072700 and After Code Date 89121300).

493459 CapOil Fill (Used Before Code Date 89121400). K280393 SealFill Tube 224328 492717 66538 K280966 495263 869 870 871 213512 213513 262001 1019 1058 494256 272262 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762.

z Included in Carburetor Gasket SetPart No. 490937. 58392 Assemblies include all parts shown in frames. 2 94 124700 to 124799 562 24 29 27 32 741 27 35 28 26 25 34 40 35 33 40 377 357 45 616 16 227 592 615 230 REF. NO. 16 24 25 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 493390 Ring Set (.

030" O.S.) LockPiston Pin PinPiston (Standard) 298908 PinPiston (.005" O.S.) RodConnecting 490743 Rod Connecting (.020" Undersize) ScrewConnecting Rod ValveExhaust ValveIntake SpringValve RetainerValve REF. NO. 45 227 230 357 377 PART NO. 262204 492349 67072 91539 94329 DESCRIPTION TappetValve Lever AssemblyGov.

WasherGov. Crank KeyDrive Pulley KeyWoodruff (For 25 mm Crankshaft) Note 93065 Key Crankshaft (For 7/8" Dia. Crankshaft) BoltGovernor Lever Nut-Hex. Fastener CrankGovernor GearTiming 26 Crankshaft See Last Pages. 222698 KeyFlywheel 493262 Piston Assy.

(Standard) 493385 Piston Assy. (.010" O.S.) 493386 Piston Assy.

(.020" O.S.) 493387 Piston Assy. (.030" O.S.) 493261 Ring Set (Standard) 493388 Ring Set (.010" O.S.

) 493389 Ring Set (.020" O.S.) 27 28 26026 298909 29 490566 32 33 34 35 40 94699 262651 262652 262224 93312 562 592 615 616 741 92613 231082 94474 262578 262598 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 58393 Assemblies include all parts shown in frames.

3 94 124700 to 124799 69B 46A 46 69B 15 15A 263 12 721 720 83 83A 18A REF. NO. 12 15 15A 15B 18 PART NO. 47 15 15A 12 20 15B 22 REF. NO.

46 46A 47 PART NO. 87 18 REF. NO. PART NO. 20 22 DESCRIPTION DESCRIPTION DESCRIPTION 231748 ShaftDrive Used on Type No(s).

0125, 0138, 0147, 0148, 0159, 0164, 0672, 3155, 3159, 3193, 3195, 3209, 3215, 7050, 7051. 231758 ShaftDrive Used on Type No(s). 0164. 231909 Shaft-Drive Used on Type No(s). 3233, 3234. GearDrive See Last Pages. SealOil ScrewSelfTap PinRoll StopShaft 18A 20 22 K272198 GasketCrankcase 94239 PlugOil Drain 94613 PlugOil Drain (Hex. Socket) 94470 PlugPipe (1/1627 NPTF) 493279 SumpEngine Note 497318 SumpEngine Used on Type No(s). 3261, 3262. 493365 SumpEngine K399781 SealOil 94220 ScrewHex.

Head Note 94612 ScrewHex. Head One Used in Hole Nearest Breather. 69B 83 492830 GearCam GearCam See Last Pages. 493737 SlingerOil (Used After Code Date 90030456 and 90031800). Note 492524 SlingerOil (Used Before Code Date 90030556 and 90031900). 68938 WasherThrust 231671 ShaftDrive Note 231711 ShaftDrive Used on Type No(s). 0192, 0667, 3110, 3172, 3177, 3222. 83A 87 263 720 721 391484 94602 93474 224249 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124702 user guide](http://yourpdfguides.com/dref/3639623)  
<http://yourpdfguides.com/dref/3639623>

493762. z Included in Carburetor Gasket SetPart No. 490937. 58394 Assemblies include all parts shown in frames. 4 94 124700 to 124799 271 209 269 270 268 605 843 467 447 620 201 618 353 620A 202 354 575 98A 621 619 REF.

NO. 98A 188A 201 202 209 268 PART NO. 493280 94644 262579 262782 DESCRIPTION REF. NO. PART NO.

DESCRIPTION Note If Longer Wire is Needed, Specify Length in Inches; if Shorter Wire is Needed, Cut to Required Length. LocknutCasing LeverControl WasherLock NutHex. ScrewHex. Hd. Knob Terminal SwitchStarting Include(s): 392832 Key Set REF. NO. 605 618 PART NO. DESCRIPTION 188A 985 520 670A 269 ScrewSpeed Adj. ScrewHex. Head Link Link SpringGovernor See Last Pages.

66986 CasingWire (48" Long) Note If Longer Casing is Needed, Specify Length in Inches; if Shorter Casing is Needed, Cut to Required Length. 26099 Wire-Control (54" Long) 270 271 353 354 447 467 520 575 63426 290568 92791 90576 93801 280857 93722 396291 619 620 620A 621 670A 843 985 224509 BracketSupport 262749 Spring (Used After Code Date 90060300). Note 260870 SpringReturn (Used Before Code Date 90060400). 94620 ScrewHex. Head BracketControl See Last Pages. 494112 BracketControl 396847 SwitchStop K493823 Spacer (Includes 2) 272616 SleeveLever 398525 Insulator K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No.

490937. 58395 Assemblies include all parts shown in frames. 5 94 124700 to 124799 141 131 134 124 634 634 104 133 125 108 137 98 130 95 118 127 617 116 955 116 975 REF. NO. PART NO.

DESCRIPTION REF. NO. PART NO. DESCRIPTION 3194, 3196, 3197, 3199, 3202, 3204, 3205, 3206, 3209, 3213, 3215, 3217, 3218, 3220, 3221, 3222, 3227, 3259. PlugWelch (Sold in Kit Only) ValveThrottle ShaftThrottle FloatCarburetor ValveNeedle (Includes Seat) GasketFloat Bowl (Sold in Kit Only) ShaftChoke SealFuel Intake Tube WasherShaft (Sold in Kit Only) ScrewFuel Bowl (Std.

) OR REF. NO. PART NO. DESCRIPTION 95 94098 98 398185 104 D231371 108 223471 116 zD 118 124 125 ScrewRound Head ScrewIdle Adjustment PinFloat Hinge ValveChoke GasketSealing (Sold in Kit Only) D493765 Valve KitNeedle 94525 ScrewCarb. Mtg. 494217 Carburetor SEE NEXT PAGE FOR ADDITIONAL CARBURETOR. Note 493627 Carburetor (Primer) (Used Before Code Date 93080200). Used on Type No(s). 0108, 0163, 0214, 0220, 3106, 3108, 3121, 3137, 3148, 3153, 3156, 3158, 3186, 3188, 3189, 3190, 3192, 3193, 127 130 131 133 134 D 223470 493267 398187 D398188 137 zD 141 494218 617 zD270344 634 zD 955 493869 975 493763 ScrewFuel Bowl (High Altitude) Note 493637 ScrewFuel Bowl (Std.) OR 494870 ScrewFuel Bowl (High Altitude) Used on Type No(s).

0108, 0163, 0214, 0220, 3106, 3108, 3121, 3137, 3148, 3153, 3156, 3158, 3186, 3188, 3189, 3190, 3192, 3193, 3194, 3196, 3197, 3199, 3202, 3204, 3205, 3206, 3209, 3213, 3215, 3217, 3218, 3220, 3221, 3222, 3227, 3259. 493640 BowlFloat K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 58396 Assemblies include all parts shown in frames. 6 94 124700 to 124799 131 134 124 634 104 133 125A 137 98 130 116 617 116 955A 975 118 127 95 REF. NO.

PART NO. DESCRIPTION REF. NO. 125A PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION 95 94098 98 398185 104 D231371 116 Dz 118 124 ScrewRound Head ScrewIdle Adjustment PinFloat Hinge GasketSealing (Sold in Kit Only) D493765 Valve KitNeedle 94525 ScrewCarb. Mtg. 127 130 131 133 134 496114 Carburetor (For Primer) (Used After Code Date 93080100).

D PlugWelch (Sold in Kit Only) 223470 ValveThrottle 493267 ShaftThrottle 398187 FloatCarburetor D398188 ValveNeedle (Includes Seat) GasketFloat Bowl (Sold in Kit Only) 617 Dz270344 SealFuel Intake Tube 634 Dz WasherShaft (Sold in Kit Only) 955A 493637 ScrewFuel Bowl OR 496063 ScrewFuel Bowl (For High Altitude) 975 493640 BowlFloat 137 Dz K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. 490937. 58397 Assemblies include all parts shown in frames. 7 94 124700 to 124799 969 968 606 971A 971 991 967 968A 969 971 236 942 163 387 922 621 529 966 423 258 923 991 967 971B REF. NO. 1Hex.

@@Head Used on Type No(s). 0201, 0208, 0467, 0623, 0625, 0656, 0657, 7015, 7019. ScrewHex Head WasherLock PrimerCarburetor REF. NO.

@@@358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @@@@NO. @@NO.

676E 832 832A 883 988 994 PART NO. @@NO. 613A 676 676A 676B 676C 676D DESCRIPTION PART NO. @@@@Hd. 94602 ScrewHex.

Hd. 94231 ScrewMuffler Mtg. K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No.

493762. z Included in Carburetor Gasket SetPart No. @@@@NO. 65 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. @@@@3119, 3132.

94512 ScrewHex. @@@@3251. 398708 WireStop Used on Type No(s). @496381 WireStop (Used After Code Date 93100300). @@@@358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No. @13 94 124700 to 124799 938 937 544 510 309 782 784 74 548 785 513 783 803 801 310 802 22A REF. NO.

22A 74 309 310 510 513 544 548 782 PART NO. 94268 93490 494233 94553 494147 394815 492921 492919 281127 DESCRIPTION ScrewHex. Head ScrewSem MotorStarter BoltThru DriveStarter ClutchDrive ArmatureStarter Washer Set GearStarter (Used After Code Date 90063000). REF. NO. PART NO. DESCRIPTION Note 494146 PinionStarter (Includes Spline) (Used Before Code Date 90070100). GearStarter CoverGear GasketCover Cap-Drive CapEnd HousingStarter REF. NO. 937 PART NO.

DESCRIPTION 783 784 785 801 802 803 261606 224262 272201 492335 492922 492920 938 281125 SplineStarter (Used After Code Date 90063000). Note 494146 SplineStarter (Includes Pinion) (Used Before Code Date 90070100). 93941 RetainerLock K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762. z Included in Carburetor Gasket SetPart No.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124702 user guide](http://yourpdfguides.com/dref/3639623)  
<http://yourpdfguides.com/dref/3639623>

490937. 583914 Assemblies include all parts shown in frames. 14 94 124700 to 124799 163A 670A 163 7 9A 12 842 358 GASKET SET 3 9 883 20 52 524  
118 104 137 116 634 977 CARBURETOR GASKET SET REF.

NO. PART NO. REF. NO. 121 127 PART NO. 134 127 617 116 617 137 634 121 CARBURETOR KIT DESCRIPTION REF. NO. PART NO. DESCRIPTION  
Note 493263 Gasket Set (Used Before Code Date 93080200). SealFill Tube SealFuel Intake Tube WasherShaft (Sold in Kit Only) Spacer (Includes 2) Seal  
GasketExhaust Gasket Set Carburetor DESCRIPTION 3 K299819 7 K272200 9 K272481 9A K272238 12 K272198 20 K399781 52 K272199 104 D231371  
116 Dz 118 SealOil GasketCylinder Hd.

GasketBreather GasketBreather GasketCrankcase SealOil GasketIntake Elbow PinFloat Hinge GasketSealing (Sold in Kit Only) D493765 Valve KitNeedle  
493762 Carburetor Kit D PlugWelch (Sold in Kit Only) 134 D398188 ValveInlet (Includes Seat) 137 Dz GasketBowl (Sold in Kit Only) 163 K272653 Gasket-  
Air Cleaner 163A K272296 GasketAir Cleaner 358 496117 Gasket Set (Used After Code Date 93080100). 524 K280393 617 Dz270344 634 Dz 670A 842 883  
977 K493823 K280966 K272253 490937 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 493762.

z Included in Carburetor Gasket SetPart No. 490937. 583915 Assemblies include all parts shown in frames. 15 94 124700 to 124799 REF. NO.  
16 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 0185, 0186, 0191, 0208, 0209, 0210, 0221, 0418, 0467, 0468, 0621, 0632, 0637, 0645,  
0649, 0652, 0661, 0663, 0665, 0671, 0673, 0680, 0683, 3119, 3138, 3148, 3159, 3160, 3175, 3191, 3195, 3202, 3205, 3209, 3220, 3224, 3225, 3227, 3230,  
3235, 3237, 3252, 3253, 4003, 5003, 7016. 493428 Crankshaft Used on Type No(s). 0136, 0137. 493432 Crankshaft Used on Type No(s). 0207. 493433  
Crankshaft Used on Type No(s).

3110, 3167, 3169, 3174, 3192, 3201, 3203, 7024, 7080. 493438 Crankshaft Used on Type No(s). 0669, 7017. 493464 Crankshaft Used on Type No(s). 0127,  
0214, 3219. 493566 Crankshaft Used on Type No(s). 0201, 0616, 0623, 0624, 0625, 0656, 0657, 3208, 3211. 493946 Crankshaft Used on Type No(s). 0119,  
0122, 0123, 0131, 0132, 0133, 0134, 0135, 0141, 0146, 0158, 0159, 0170, 0171, 0174, 0175, 0184, 0192, 0195, 0196, 0197, 0614, 0622, 0627, 0628, 0629,  
0631, 0633, 0634, 0636, 0638, 0639, 0640, 0641, 0644, 0648, 0667, 0672, 0676, 0677, 0678, 3117, 3126, 3136, 3150, REF. NO.

PART NO. DESCRIPTION 493282 Crankshaft Note For Timing Gear Key. Order Part No. 94388. 493362 Crankshaft Used on Type No(s).  
0115, 0120, 0121, 0124, 0128, 0129, 0142, 0143, 0145, 0147, 0148, 0149, 0150, 0151, 0152, 0157, 0163, 0164, 0165, 0166, 0167, 0169, 0178, 0179, 0187,  
0188, 0193, 0194, 0200, 0203, 0204, 0213, 0215, 0220, 0223, 0224, 0415, 0618, 0630, 0643, 0654, 0655, 0658, 0659, 0660, 0664, 0668, 0675, 0681, 3106,  
3111, 3112, 3116, 3118, 3120, 3121, 3123, 3124, 3125, 3127, 3128, 3132, 3133, 3137, 3139, 3140, 3142, 3143, 3144, 3145, 3152, 3154, 3155, 3156, 3157,  
3158, 3163, 3170, 3172, 3177, 3178, 3184, 3186, 3188, 3189, 3193, 3194, 3196, 3197, 3199, 3200, 3204, 3206, 3207, 3210, 3212, 3213, 3215, 3217, 3218,  
3221, 3222, 3226, 3233, 3234, 3239, 3241, 3243, 3245, 3259, 3260, 3263, 4004, 4005, 4006, 5004, 5008, 7015, 7019, 7050, 7051, 7060, 7090. 493363  
Crankshaft Used on Type No(s). 0116, 0125, 0138, 0139, 0153, 0154, 0155, 0156, 0160, 0161, 0162, 0168, 0176, 0177, 0181, 3179, 3181, 3179, 3181, 3603, 3610, 3611,  
4000, 5000, 7026. 493947 Crankshaft Used on Type No(s). 0126, 0205, 0674, 3129, 3151, 3153, 3180, 3191, 3250, 7018.

494404 Crankshaft Used on Type No(s). 3149. 494546 Crankshaft Used on Type No(s). 0189, 3115, 3185, 3238. 494984 Crankshaft Used on Type No(s).  
3257. 493740 GearCam (Clockwise) (Used After Code Date 90030456 and 90031800). 492670 GearCam (Clockwise) (Used Before Code Date 90030556 and  
90031900). Note 493738 GearCam (Counterclockwise) (Used After Code Date 90030456 and 90031800). 492671 GearCam (Used Before Code Date  
90030556 and 90031900).

Used on Type No(s). 0135, 0147, 0148, 0150, 0159, 0178, 0179, 0192, 0194, 0629, 0648, 0654, 0655, 0658, 0659, 0667, 0672, 0675, 3110, 3128, 3130, 3131,  
3144, 3155, 3159, 3172, 3174, 3177, 3189, 3193, 3197, 3199, 3207, 3222, 3233, 3234, 3241, 3259, 7051, 7055, 7080. 46A K Included in Gasket SetSee Ref.

358. D Included in Carburetor KitPart No. 492932. z Included in Carburetor Gasket SetPart No. 490937. 583916 Assemblies include all parts shown in  
frames. 16 94 124700 to 124799 REF.

NO. 83A PART NO. DESCRIPTION REF. NO. PART NO.

DESCRIPTION 3219, 3227, 3230, 3233, 3234, 3241, 3250, 7051, 7080. 262660 SpringGov. Used on Type No(s). 0125, 0151, 0152, 0163, 0167, 3111, 3116,  
3118, 3119, 3120, 3121, 3123, 3124, 3130, 3131, 3132, 3133, 3134, 3137, 3138, 3139, 3148, 3153, 3155, 3156, 3158, 3159, 3160, 3163, 3170, 3172, 3175,  
3177, 3178, 3180, 3186, 3191, 3195, 3196, 3200, 3201, 3202, 3204, 3205, 3207, 3209, 3215, 3218, 3220, 3221, 3222, 3226, 3239, 3243, 3252, 3253, 3257,  
3260, 4000, 4001, 4003, 4004, 4006, 5000, 5001, 5003, 5004, 5006, 5008, 7015, 7016, 7017, 7018, 7024, 7025, 7026, 7050, 7055, 7060. 262661 SpringGov.  
Used on Type No(s). 0101, 0102, 0108, 0136, 0137, 0186, 0189, 0601, 3101, 3102, 3108, 3115, 3127, 3128, 3129, 3140, 3185, 3188, 3189, 3190, 3214, 3238,  
3259, 3263. 262662 SpringGov. Used on Type No(s). 3149, 3154, 3178, 3194, 3213. 262664 SpringGov. Used on Type No(s). 0128, 0129, 0132, REF. NO.

PART NO.

DESCRIPTION 0142, 0143, 0146, 0155, 0192, 0193, 0200, 0205, 0206, 0207, 0209, 0615, 0620, 0632, 0664, 0665, 0667, 0674, 3112, 3145, 3210. 262665  
SpringGov. Used on Type No(s). 0134, 0138, 0139, 0144, 0145, 0147, 0148, 0156, 0162, 0178, 0179, 0181, 0185, 0191, 0194, 0201, 0203, 0208, 0210, 0221,  
0467, 0616, 0621, 0622, 0623, 0624, 0625, 0637, 0638, 0639, 0640, 0653, 0656, 0657, 0658, 0659, 0671, 0673, 0677, 3203, 3208, 3211, 3224, 3225, 3604,  
7019. 262666 SpringGov. Used on Type No(s). 0106, 0109, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0150, 0158, 0160, 0161, 0168, 0176, 0177, 0184,  
0186, 0187, 0188, 0204, 0415, 0418, 0468, 0613, 0614, 0617, 0618, 0619, 0627, 0630, 0642, 0644, 0645, 0650, 0652, 0654, 0655, 0661, 0663, 0666, 0676,  
0678, 0680, 0681, 3107, 3603. 262667 SpringGov. Used on Type No(s). 0153, 0154, 0165, 0169, 0649, 0660, 0668, 0670.

231278 GearDrive Note 231279 GearDrive (Counterclockwise) Used on Type No(s). 0135, 0147, 0148, 0150, 0159, 0178, 0179, 0192, 0194, 0629, 0648,  
0654, 0655, 0658, 0659, 0667, 0672, 0675, 3110, 3128, 3130, 3131, 3144, 3155, 3159, 3172, 3174, 3177, 3189, 3193, 3197, 3199, 3207, 3222, 3233, 3234,  
3241, 3259, 7051, 7055, 7080.



[You're reading an excerpt. Click here to read official BRIGGS &  
STRATTON 124702 user guide  
http://yourpdfguides.com/dref/3639623](http://yourpdfguides.com/dref/3639623)



262656 SpringGovernor Note 262654 SpringGov. Used on Type No(s). 0164, 0166, 0220, 0669, 3261, 3262.  
 262655 SpringGov. Used on Type No(s). 0198, 0223, 0224, 3125, 4005. 262657 SpringGov. Used on Type No(s).  
 0122, 0141, 0174, 0175, 3113, 3114, 3126, 3136, 3142, 3146, 3147, 3150, 3152, 3157, 3184, 3217, 3235, 3237, 3245, 3251, 7090. 262658 SpringGov. Used  
 on Type No(s). 0123, 0126, 3110, 3143, 3144, 3174, 3151, 3212. 262659 SpringGov. Used on Type No(s). 0127, 0196, 0214, 3106, 3117, 3126, 3167, 3169,  
 3192, 3193, 3197, 3199, 3201, 3203, 3206, 209 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart No. 492932.

z Included in Carburetor Gasket SetPart No. 490937. 583917 Assemblies include all parts shown in frames. 17 94 124700 to 124799 REF. NO. PART NO.  
 DESCRIPTION REF. NO. PART NO. DESCRIPTION (Used Before Code Date 90030556 or 90031900).  
 Used on Type No(s). 0149, 0155, 0157, 0163, 0180, 0198, 0207, 0223, 0224, 0611, 0616, 0624, 0627, 0628, 0629, 0634, 0641, 3121, 3137, 3148, 3153, 3156,  
 3158, 3186, 3194, 3196, 3202, 3239, 3260, 4005, 7055. 495976 BracketCarb. (Man. Friction Control) (Used After Code Date 93080100).  
 493895 Bracket Control (Man. Friction Control) (Used Before Code Date 93080200 and After Code Date 91072800). 493894 Bracket Control (Remote  
 Control) (Used Before Code Date 91072900). Used on Type No(s). @@@@3120, 3133, 3226.  
 494544 HarnessWire Used on Type No(s). 3114, 3117, 3147, 3179. @@@494340 TankFuel REF. NO. PART NO. DESCRIPTION (Black, 1-1/2 Quart) (Used  
 Before Code Date 90092400). @@@494534 TankFuel (1 Quart, Black) (Used Before Code Date 90092400). Used on Type No(s). 016801, 061301, 064501,  
 064901, 066601, 066602. 494353 TankFuel (1-1/2 Quart, Yellow) (Used After Code Date 93080100).

496762 TankFuel (Used Before Code Date 93080200). Used on Type No(s). 310603, 322003. 494353 TankFuel (1-1/2 Quart, Yellow) Used on Type No(s).  
 310603, 311802, 312002, 312003, 313301, 315401, 316003, 317003, 317502, 317702. 494354 TankFuel (Special, Red) Used on Type No(s). 016301, 312101,  
 313701, 314801, 315301, 315801, 315802, 318601, 319601, 320201, 323901. 494355 TankFuel (1-1/2 Quart, Gray) Used on Type No(s). 062901, 064801,  
 320601, 320602. 494356 TankFuel (1-1/2 Quart, Red) Used on Type No(s).  
 016701, 062001, 065301, 315403, 360401. 262678 SpringGov. Used on Type No(s). 0131, 0133, 0135, 0159, 0170, 0171, 0180, 0182, 0183, 0190, 0195,  
 0197, 0611, 0612, 0626, 0628, 0629, 0631, 0633, 0634, 0636, 0641, 0643, 0647, 0648, 0672, 0675, 0683, 3106, 3181, 3610, 3611. 495265 TubeOil Fill (Used  
 After Code Date 92072600).

Note 493952 TubeOil Fill (Used Before Code Date 92072700 and After Code Date 89121300). 493459 TubeOil Fill (Used Before Code Date 89121400).  
 495975 BracketControl (Remote Control) (Used After Code Date 93080100). 493894 Bracket Control (Used Before Code Date 93080200 and After Code  
 Date 90030456 or 90031800). 492978 Bracket Control (Used Before Code Date 90030556 or 90031900).  
 Note 495976 Bracket Control (Man. Friction Control) (Used After Code Date 93080100). 493895 Bracket Control (Used Before Code Date 93080200 and  
 After Code Date 90030456 or 90031800). 493635 Bracket Control 525 620 789A 972 K Included in Gasket SetSee Ref. 358. D Included in Carburetor KitPart  
 No. 492932. z Included in Carburetor Gasket SetPart No. 490937. 583918 Assemblies include all parts shown in frames.

18 94 124700 to 124799 REF. NO. PART NO. DESCRIPTION 494358 TankFuel (Black, Special) Used on Type No(s). 012301, 013701, 018901, 020101,  
 020801, 022101, 046701, 061601, 062301, 062501, 065601, 065701, 311301, 311302, 311303, 311501, 311502, 311701, 312601, 318501, 320801, 321101,  
 322401, 322501, 325101, 701501, 701901, 709001. 494359 TankFuel (1 Quart, Yellow) Used on Type No(s). 311901, 313201. 494360 TankFuel (1-1/2  
 Quart, Tan) Used on Type No(s). REF. NO.  
 PART NO. DESCRIPTION 012702, 316702, 316902. 494558 TankFuel (Special, Red) Used on Type No(s). 315601. 495065 TankFuel Used on Type No(s).  
 021401, 310601, 318801, 318901, 319001, 319201, 319301, 319401, 319701, 319901, 320401, 320501, 320901, 321301. 495508 Tank Fuel (11/2 Qt., Gray)  
 Used on Type No(s). 320601, 320602. 495509 TankFuel (11/2 Qt.  
 , Black) Used on Type No(s). 010901, 013101, 013102, 013103, REF. NO. PART NO. DESCRIPTION 013104, 014201, 017401, 017501, 019301, 019401,  
 019501, 019701, 020001, 020301, 020401, 020901, 021001, 041501, 041801, 046801, 314701, 321001. 281025 PlateTrim Note 281172 PlateTrim Used on  
 Type No(s). 0174, 0175, 3146, 3147. 281202 PlateTrim Used on Type No(s). 0106, 0109, 0131, 0142, 0190, 0191, 0192, 0193, 0194, 0195, 0197, 0200, 0203,  
 0204, 0209, 0210, 3107, 3210, 0415, 0418, 0468. 1040 K Included in Gasket SetSee Ref.

358. D Included in Carburetor KitPart No. 492932. z Included in Carburetor Gasket SetPart No. 490937. 583919 Assemblies include all parts shown in  
 frames. 19 94 .



**[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 124702 user guide](http://yourpdfguides.com/dref/3639623)**  
<http://yourpdfguides.com/dref/3639623>