



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 126T00 TO 126T99. You'll find the answers to all your questions on the BRIGGS & STRATTON 126T00 TO 126T99 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 126T00 TO 126T99  
User guide BRIGGS & STRATTON 126T00 TO 126T99  
Operating instructions BRIGGS & STRATTON 126T00 TO 126T99  
Instructions for use BRIGGS & STRATTON 126T00 TO 126T99  
Instruction manual BRIGGS & STRATTON 126T00 TO 126T99



FORM MS-3728-07142008  
REPLACES FORM MS-3728-06212008  
FILE IN SECT. 2 OF SERVICE MANUAL

126T00

## Illustrated Parts List

### Model Series

### 126T00

TYPE NUMBERS  
0004 through 4830.

#### TABLE OF CONTENTS

Air Cleaner .....	4
Blower Housing/Shrouds .....	6
Camshaft .....	2
Carburetor .....	3
Controls .....	5
Crankshaft .....	2
Cylinder .....	2
Electric Starter .....	7
Electrical .....	5
Engine Sump .....	2
Exhaust System .....	4
Flywheel .....	7
Flywheel Brake .....	5
Fuel Supply .....	3
Governor Spring .....	5
Ignition .....	5
Kits/Gaskets .....	2 & 3
Lubrication .....	2
Piston Group .....	2
Rewind Starter .....	7
Valves .....	2



PRINTED IN U.S.A.  
COPYRIGHT BY BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 126T00 TO 126T99 user guide](http://yourpdfguides.com/dref/3639809)

<http://yourpdfguides.com/dref/3639809>

**Manual abstract:**

2 OF SERVICE MANUAL 126T00 Illustrated Parts List Model Series 126T00 TYPE NUMBERS 0004 through 4830. TABLE OF CONTENTS Air Cleaner . . .

.....  
.....  
.....  
..... 4 Blower Housing/Shrouds . . . . .  
..... 6 Camshaft . . . . .  
.....  
.....  
.....  
..... 2 Carburetor . . . . .  
.....  
.....  
.....  
3 Controls . . . . .  
.....  
.....  
..... 5 Crankshaft . . . . .  
.....  
.....  
.....  
..... 2 Cylinder . . . . .  
.....  
.....  
.....  
..... 2 Electric Starter . . . . .  
.....  
.....  
..... 7 Electrical . . . . .  
.....  
.....  
.....  
5 Engine Sump . . . . .  
.....  
.....  
..... 2 Exhaust System . . . . .  
.....  
.....  
..... 4 Flywheel . . . . .  
.....  
.....  
.....  
7 Flywheel Brake . . . . .  
.....  
.....  
..... 5 Fuel Supply . . . . .  
.....  
.....  
..... 3 Governor Spring . . . . .  
.....  
.....  
..... 5 Ignition . . . . .  
.....  
.....  
.....  
..... 5 Kits/Gaskets . . . . .

.....  
.....  
.. 2 & 3 Lubrication ...  
.....

.....  
.. 2 Piston Group ....  
.....

..... 2 Rewind Starter .....

.....  
.....  
..... 7 Valves .....

.....  
.....  
.....

..... 2 PRINTED IN U.S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

126T00 1319 WARNING LABEL 1058 OPERATOR'S MANUAL 1330 REPAIR MANUAL 1019 LABEL KIT REQUIRED when replacing parts with warning labels affixed. 1 584 8 9 2 3 718 10 306 306A 307 50A 7 51A 585 684 11 54 13 5 869 870 871 33 40 36 40 35 45 337 635 383 34 25 27 45 16 24 847 523 842 868 287 28 29 32A 146 741 26 525 27 358 ENGINE GASKET SET 32 3 7 20 51 51A 163 524 46 4 43 1095 VALVE GASKET SET 9 12 524 9 585 12 617 668

842 883 7 883 22 15 20 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-2 Assemblies include all parts shown in frames. 2 07/14/2008 126T00 125 365 163 97 365 125A 163 692 108 127 130 134 130A 95 617 109A 633A 133 104 975 137 109 217 118 276 276 117 276 633 118A 276 117A 276 276 134 130 95 130A 617 633 97 633 127 133 104 975 137 PRIMER SYSTEM CHOKE SYSTEM 121 CARBURETOR OVERHAUL KIT 125B 109B 97 104 127 134 137 163 276 617 633 633A 633A 633 163 231 977 CARBURETOR GASKET SET 108A 137 127 130 617 972B 957B 163 134 276 617 633 633A 133 104 975 137 190 118B 276 117B 276 276 1059 187 601 187A 601 958 601A AUTOCHOKE SYSTEM

670 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-3 Assemblies include all parts shown in frames. 3 07/14/2008 126T00 425A 966B 163 976 967A 445A 443A 529 968B 300 883 300A 676 676C 677 81 613 832 836 832A 836 994 81 613A 677 676D 677 676E 677 994B 346 832B 836B 836 346 291 832E 836C 1387 883 1386 1388 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-4 Assemblies include all parts shown in frames.

4 07/14/2008 126T00 222 621 98A 668 843 843A 668 668 222A 621 222C 621 222D 222E 668 188 227 562 209B 202 505 615 404 268 271 269 270 267 265A 265 265B 209A 356 333A 851A 616 356B 334 635A 333 627 627A 347 497 497 356D 356G 356H 356J 851 892 578 789B 578A 990 500 664 935 1160 1119 236 745 923B 474 621 923 621 922 922A 910 923A 922A Illustrations cover a range of engines. @@@@ Parts shown without corresponding text may not be used on your specific engine. 3728-7 Assemblies include all parts shown in frames. 7 07/14/2008 126T00 REF. NO.

1 2 PART NO. DESCRIPTION REF. NO. 16 PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION 691455 Crankshaft Used on Type No(s). 0006, 0018, 0523. 694849 Crankshaft Used on Type No(s). 0005, 0114, 0131, 0179, 0188, 2013. 695242 Crankshaft Used on Type No(s). 0026. 696009 Crankshaft Used on Type No(s). 0031, 0115, 0139, 0181, 0182, 0183, 0184, 0204, 0206, 0216, 0219, 0220, 0224, 0231, 0233, 0236, 0240, 0241, 0329, 0678, 0933, 1840, 1841.

791061 Crankshaft Used on Type No(s). 0030, 0116, 0209, 0225, 0227, 0230, 0234, 0237. 694478 Crankshaft Used on Type No(s). 0521, 0538. 691454 Crankshaft Used on Type No(s). 1706. 694079 Crankshaft Used on Type No(s). 1701. 795499 Crankshaft Used on Type No(s). 0222, 0256.

697322 Cylinder Assembly 399269 Kit-Bushing/Seal (Magneto Side) 3 K299819S Seal-Oil (Magneto Side) 4 493279 Sump-Engine ----- Note ----- 498983 Sump-Engine Used on Type No(s). 0006, 0007, 0122. 5 691160 Head-Cylinder 7 K692249 Gasket-Cylinder Head 8 695250 Breather Assembly 9 K696125 Gasket-Breather 10 691125 Screw (Breather Assembly) 11 691781 Tube-Breather 12 K692232 Gasket-Crankcase 13 690912 Screw (Cylinder Head) 15 691680 Plug-Oil Drain (Square Socket) 691450 Crankshaft ----- Note ----- 691451 Crankshaft Used on Type No(s). 0004, 0010, 0011, 0015, 0050, 0060, 0121, 0135, 0138, 0148, 0153, 0158, 0159, 0169, 0172, 0173, 0199, 0243, 0329, 0454, 0475, 0479, 0487, 0491, 0555, 0615, 0660, 0826, 1064, 1172, 1724, 1728, 1729, 1750, 1767, 1791, 1802, 1807, 1817, 1820, 1822, 1824, 1833, 1963, 2003, 2004, 2011, 2016, 2021, 2022, 2034, 2041, 2091, 2388. 691452

Crankshaft Used on Type No(s).

0007, 0016, 0122, 0147, 0150, 0151, 0154, 0163, 0164, 0168, 0242, 0568, 0680, 0878, 1727, 1733, 1734, 1737, 1738, 1739, 1740, 1748, 1749, 1794, 1801, 1803, 1804, 1805, 1808, 1810, 1814, 1816, 1818, 1821, 1823, 1825, 1826, 1827, 1829, 1830, 1831, 1832, 1835, 1837, 1839, 1844, 1845, 1846, 1847, 1849, 1852, 1853, 1904, 1914, 1917, 1926, 1941, 1958, 1965, 1966, 1992, 1995, 2006, 2008, 2010, 2112, 2014, 2015, 2017, 2023, 2027, 2035, 2148, 2149, 2304, 4135, 4825, 4830. K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref.

No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-8 Assemblies include all parts shown in frames.

8 07/14/2008 126T00 REF. NO. PART NO. DESCRIPTION REF. NO. 26 PART NO. DESCRIPTION REF. NO. 58 PART NO. DESCRIPTION 20 K399781S Seal-Oil (PTO Side) 22 691092 Screw (Crankcase Cover/ Sump) 23A 691987 Flywheel ----- Note ----- 691992 Flywheel Used on Type No(s). 0004, 0005, 0006, 0007, 0010, 0030, 0050, 0114, 0116, 0122, 0131, 0164, 0169, 0179, 0188, 0209, 0222, 0225, 0227, 0230, 0234, 0237, 0256, 0523, 0826, 0933, 1064, 1137, 1802, 1807, 1822, 1849, 2013, 2016. 24 222698S Key-Flywheel 25 795429 Piston Assembly (Standard) (Used After Code Date 07090300). ----- Note ----- 791097 Piston Assembly (Standard) (Used Before Code Date 07090400). 795430 Piston Assembly (.020" Oversize) (Used After Code Date 07090300).

791326 Piston Assembly (.020" Oversize) (Used After Code Date 07090300).



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 126T00 TO 126T99 user guide](http://yourpdfguides.com/dref/3639809)  
<http://yourpdfguides.com/dref/3639809>

020" Oversize) (Used Before Code Date 07090400). 795431 Ring Set (Standard) (Used After Code Date 07090300). ----- Note ----- 791098 Ring Set (Standard) (Used Before Code Date 07090400). 795432 Ring Set (.

020" Oversize) (Used After Code Date 07090300). 791324 Ring Set (.020" Oversize) (Used Before Code Date 07090400). 691866 Lock-Piston Pin 499423 Pin-Piston (Standard) 499424 Rod-Connecting (Standard) 691664 Screw (Connecting Rod) 695759 Screw (Connecting Rod) 262651S Valve-Exhaust 262652S Valve-Intake 691270 Spring-Valve (Intake) 691270 Spring-Valve (Exhaust) 694086 Guard-Flywheel 692194 Retainer-Valve 691997 Slinger-Governor/Oil 690548 Tappet-Valve 691449 Camshaft 794305 Manifold-Intake K272199S Gasket-Intake K794306 Gasket-Intake 691650 Screw (Intake Manifold) 691421 Housing-Rewind Starter 697316 Rope-Starter (Cut To Required Length) ----- Note ----- 791362 Rope-Starter Used on Type No(s). 0132, 0133, 0143, 0144, 0165, 0166, 0175, 0181, 0234. 281434S Grip-Starter Rope 690837 Screw (Rewind Starter) 691108 Screw (Flywheel Guard) 691740 Lock-Muffler Screw 691636 Screw (Throttle Valve) 493267 Shaft-Throttle (Metal) ----- Note ----- 696565 Shaft-Throttle (Plastic) 795881 Shaft-Throttle Used on Type No(s). 0007, 0122. @@@@ @@@@No.358. D Included in Carburetor Overhaul Kit-Ref.

No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. @@9 07/14/2008 126T00 REF. NO.

117 PART NO. DESCRIPTION REF. NO. 118 PART NO. DESCRIPTION REF.

NO. 125 PART NO. @@Used on Type No(s). 0154, 0680, 0761, 1749, 1837, 1850, 1917, 2035, 3761. 494870 Jet-Main (Standard) (Used Before Code Date 07020700).

Used on Type No(s). 0761, 3761. @@0007, 0122. 691428 Jet-Main (Standard) (Used After Code Date 07020600). @@@@0154, 0680, 0761, 1749, 1837, 1850, 1917, 2035, 3761. @@0007, 0122. 695042 Jet-Main (High Altitude) (Used After Code Date 07020600). @@@@Used on Type No(s). 0154, 0680, 0761, 1749, 1837, 1850, 1917, 2035, 3761. 790821 Carburetor (Primer System) (Used Before Code Date 07020700).

Used on Type No(s). 0761, 3761. @@1746, 1801, 1802, 1803, 1804, 1805. 795882 Carburetor Used on Type No(s). 0007, 0122. 794304 Carburetor (Autochoke System) (Used After Code Date 07020600). @No.358. D Included in Carburetor Overhaul Kit-Ref. No.

121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref.

No 1095. Illustrations cover a range of engines. @@10 07/14/2008 126T00 REF. NO. PART NO.

DESCRIPTION Plug-Welch Valve-Throttle Valve-Throttle Float-Carburetor Kit-Nee, 1808, 1823, 1825, 1827, 1831, 1845, 1847, 1849, 1851, 1963, 1965, 2011, 2015, 2016, 2017, 2021, 2022, 2034, 2041, 3709, 3849, 4135, 4825. 792677 Muffler Used on Type No(s). 0329, 1003, 1844. 496106S Muffler Used on Type No(s). 0187, 0251. 790830 Muffler Used on Type No(s). 4830. @No.358. D Included in Carburetor Overhaul Kit-Ref.

No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. @@12 07/14/2008 126T00 REF. NO.

304 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 790826 Housing- Blower Used on Type No(s).

@@REF. NO. PART NO. DESCRIPTION 790983 Housing- Blower Used on Type No(s). @@791291 Housing- Blower Used on Type No(s).

@@791135 Housing- Blower Used on Type No(s). 0329. @@@@493294 Housing- Blower Used on Type No(s). 0004, 0005, 0006, 0007, 0010, 0050, 0116, 0122, 0131, 0169, 0179, 0187, 0188, 0209, 0242, 0521, 0523, 0538, 0826, 0878, 1064, 1137, 1729, 1802, 1822, 1839, 1926, 1941, 2013, 2014, 2027, 3139, 3140. K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-13 Assemblies include all parts shown in frames. 13 07/14/2008 126T00 REF. NO.

305 306 306A 307 309 309A 310 332 333 PART NO. DESCRIPTION REF. NO. 334 337 PART NO. DESCRIPTION REF.

NO. 523 524 525 529 544 545 562 PART NO. 499621 K692296 495265 691923 690786 492919 92613 DESCRIPTION Dipstick Seal-Dipstick Tube Tube-Dipstick Grommet Armature-Starter Washer Set Bolt (Governor Control Lever) Screw (Debris Guard Screen) Screw (Control Cover) Screw (Control Cover) Wire-Assembly Wire-Assembly Cover-Breather Passage Gasket-Breather Passage Nut (Rewind Starter) Screw (Pawl Friction Plate) Clamp-Hose Clamp-Hose Cover-Control Cover-Control Cover-Control Cover-Control Starter-Rewind ----- Note ----- 791363 Starter- Rewind Used on Type No(s). 0132, 0133, 0143, 0144, 0165, 0166, 0175, 0181, 0234, 0479, 0487, 0491. 691108 Screw (Blower Housing) 690450 Shield-Cylinder 790836 Shield-Cylinder 690345 Screw (Cylinder Shield) 695550 Motor-Starter (Used Before Code Date 07052900).

795092 Motor-Starter (Used After Code Date 07052800). 692327 Bolt (Starter Motor) 690662 Nut (Flywheel) 802574 Armature-Magneto ----- Note ----- 790817 Armature- Magneto Used on Type No(s). 0224, 0487, 0761, 1045, 1817, 2034, 3761. 793353 Armature-Magneto ----- Note ----- 793354 Armature-Magneto Used on Type No(s). 0121, 0150, 0151, 0154, 0158, 0159, 0163, 0164, 0168, 0172, 0680, 0875, 0893, 0909, 1111, 1164, 1706, 1739, 1748, 1749, 1750, 1807, 1808, 1816, 1823, 1824, 1825, 1826, 1827, 1829, 1831, 1835, 1837, 1844, 1845, 1846, 1847, 1849, 1850, 1853, 1917, 1963, 1965, 2011, 2015, 2016, 2017, 2021, 2035, 2041, 4825, 4830. 691061 Screw (Magneto Armature) 802592S Plug-Spark (Resistor) ----- Note ----- 697451 Plug-Spark (EMS) 690661 Screw (Spark Arrester) 691396 Switch-Rocker 692390 Wire-Stop 693010 Wire-Stop 496381 Wire-Stop 695283 Wire-Stop 690791 Wire-Stop 691423 Wire-Stop 794307 Gasket Set-Engine 19069 Flywheel Puller 691688 Screw (Carburetor) 89838S Wrench-Spark Plug 690272 Washer (Governor Crank) 690670 Screw (Air Cleaner Cover) 692523 Screw (Air Cleaner Primer Base) 491588S Filter-Air Cleaner Cartridge 791960 Cup-Flywheel 692299 Plate-Pawl Friction 281505S Plate-Ratchet 691991 Alternator 690664 Screw (Stop Switch Bracket) 691086 Washer (Key Switch) 691251 Nut (Governor Control Lever) 795093 Drive-Starter 692358 Clutch-Drive 346 347 356 356B 356D 356G 356H 356J 358 363 365 383 404 425A 443A 563 564B 564 578 578A 584 585 592 597 601 601A 604 604B 604C 604D 608 691138 698589 690664 398153 696031 697734 K691879 690800 691696 791850 691038 691757 790703 792418 793770 497680 333A 445A 455 456 459 474 497 500 505 510 513 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No.

121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-14 Assemblies include all parts shown in frames. 14 07/14/2008 126T00 REF.

NO. 613 PART NO. DESCRIPTION REF. NO. 615 PART NO.

DESCRIPTION REF. NO. 741 PART NO.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 126T00 TO 126T99 user guide](#)



DESCRIPTION 691340 Screw (Muffler) ----- Note ----- 790833 Screw (Muffler) Used on Type No(s). 0030, 0031, 0114, 0121, 0132, 0133, 0140, 0143, 0144, 0150, 0151, 0158, 0159, 0161, 0164, 0165, 0166, 0168, 0172, 0173, 0175, 0177, 0180, 0181, 0183, 0200, 0216, 0219, 0220, 0222, 0224, 0225, 0227, 0230, 0231, 0233, 0234, 0236, 0237, 0240, 0241, 0245, 0247, 0248, 0251, 0256, 0378, 0454, 0475, 0487, 0491, 0548, 0555, 0615, 0625, 0660, 0662, 0675, 0677, 0678, 0709, 0849, 0867, 0875, 0880, 0893, 0932, 0933, 0985, 0992, 1003, 1006, 1024, 1044, 1045, 1047, 1055, 1133, 1163, 1164, 1184, 1706, 1738, 1807, 1808, 1823, 1825, 1827, 1831, 1845, 1847, 1849, 1851, 1963, 1965, 2011, 2015, 2016, 2017, 2021, 2022, 2034, 2041, 3709, 3849, 4135, 4825, 4830. 792678 Screw (Muffler) Used on Type No(s). 0329, 1003, 1844. 691653 Screw (Muffler) 690340 Retainer-Governor Shaft 616 698801 Crank-Governor 617KDz270344 Seal-O Ring (Intake Manifold) 621 692310 Switch-Stop 627 792565 Bracket-Stop Switch 627A 793211 Bracket-Stop Switch 633 Dz691321 Seal-Choke/Throttle Shaft 633A Dz693867 Seal-Choke/Throttle Shaft 635 66538S Boot-Spark Plug 635A 793351 Boot-Spark Plug 651 691660 Screw (Starter Gear Cover) 664 691087 Nut (Key Switch) 668 K493823 Spacer 670 692294 Spacer-Fuel Tank 676 396548 Deflector-Muffler 676C 493871 Deflector-Muffler 676D 497682 Deflector-Muffler 676E 393760 Deflector-Muffler 677 690661 Screw (Muffler Deflector) 684 690345 Screw (Breather Passage Cover) 689 691855 Spring-Friction 692 690572 Spring-Detent 697 691127 Screw (Drive Cap) 703 696309 Clip 718 690959 Pin-Locating 795755 Gear-Timing (Plastic) ----- Note ----- 794388 Gear-Timing (Use Without Woodruff Key) (Used After Code Date 07093000). 790345 Gear-Timing (Use Without Woodruff Key) (Used Before Code Date 07100100). 691830 Gear-Timing (Uses Woodruff Key) 93941 Retainer-E Ring 691648 Screw (Brake) 691918 Gear-Pinion 691269 Gear-Pinion 795095 Cover-Starter Gear 692352 Gasket-Starter Cover 792685 Harness-Wiring 690782 Cap-Drive 695267 Cap-End 695266 Housing-Starter 499034 Guard-Muffler 691424 Guard-Muffler 497683 Guard-Muffler 793568 Guard-Muffler 690664 Screw (Muffler Guard) 691147 Screw (Muffler Guard) 790745 Screw (Muffler Guard) K691031 Seal-O Ring (Dipstick Tube) 691884 Sleeve-Lever (Speed Control) 691895 Sleeve-Lever (Choke) 692047 Dipstick/Tube Assembly 742 745 783 783A 784 785 789B 801 802 803 832 832A 832B 832E 836 836B 836C 842 843 843A 847 613A K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-15 Assemblies include all parts shown in frames. 15 07/14/2008 126T00 REF. NO. PART NO. DESCRIPTION REF. NO. 923 923A 923 923A PART NO. 691994 695891 691994 695891 DESCRIPTION REF. NO. 925 PART NO. @@ Used on Type No(s). @@796136 Brake (Used After Code Date 08043000). Used on Type No(s). @@795403 Cover-Linkage (Used After Code Date 07072200). @@691919 Guard-Rewind 499421 Switch-Interlock 691325 Spline-Starter 691738 Stop-Rope 696306 Guard-Debris Screen 699985 Cap-Fuel Tank (Plastic) 698183 Valve-Fuel Shut Off (Plastic) 792040 Base-Air Cleaner Primer ----- Note ----- 795259 Base-Air Cleaner Primer Used on Type No(s). 1064. 493537S Filter-Pre Cleaner 692298 Cover-Air Cleaner 690700 Screw (Blower Housing Cover) 691138 Screw (Blower Housing Cover) 691669 Screw (Air Cleaner Primer Bracket) 699374 Tank-Fuel (Plastic) 493640 Bowl-Float 694395 Primer-Carburetor 498261 Gasket Set-Carburetor 691959 Key Set 930 935 937 946 949 957B 958 966B 967A 968B 969 923B 969A 970 972B 975 976 977 990 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. Included in Carburetor Gasket Set-Ref.

No. 977. Included in Valve Gasket Set-Ref. No 1095. z Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-16 Assemblies include all parts shown in frames. 16 07/14/2008 126T00 REF. NO. 994 994B 997 1005 1019 1036 PART NO. 398067 792245 696310 691346 694881 DESCRIPTION REF. NO. 1095 1119 1160 1210 1211 PART NO. DESCRIPTION REF. NO. 1319 1330 1386 1387 1388 PART NO. DESCRIPTION Arrestor-Spark Arrestor-Spark Shield-Debris Fan-Flywheel Kit-Label Label-Emissions (Available From A Briggs & Statton Authorized Dealer) 277039 Operator's Manual 692311 Kit-Screw/Washer 498528 Gasket Set-Valve 692979 Screw (Alternator) 690345 Screw (Interlock Switch) 498144 Pulley/Spring Assembly (Pulley) 498144 Pulley/Spring Assembly (Spring) 794467 Label-Warning 270962 Manual-Repair 790848 Vane-Air (Autochoke System) 790849 Spring-Air Vane 790850 Screw (Air Vane) 1058 1059 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref.

No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3728-17 Assemblies include all parts shown in frames.

17 07/14/2008 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 126T00 TO 126T99 user guide](http://yourpdfguides.com/dref/3639809)  
<http://yourpdfguides.com/dref/3639809>