



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 129700 TO 129799. You'll find the answers to all your questions on the BRIGGS & STRATTON 129700 TO 129799 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 129700 TO 129799
User guide BRIGGS & STRATTON 129700 TO 129799
Operating instructions BRIGGS & STRATTON 129700 TO 129799
Instructions for use BRIGGS & STRATTON 129700 TO 129799
Instruction manual BRIGGS & STRATTON 129700 TO 129799



FORM MS-0485-06/27/2008
REPLACES FORM MS-0485-06/06/2008
FILE IN SECT. 2 OF SERVICE MANUAL

129700

Illustrated Parts List

Model Series

129700

TYPE NUMBERS
0108 through 1777.

TABLE OF CONTENTS

Alternator	7
Air Cleaner	4
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	3
Controls	5
Crankshaft	2
Cylinder	2
Electric Starter	7
Electrical	7
Engine Sump	2
Exhaust System	4
Flywheel	6
Flywheel Brake	7
Fuel Supply	5
Governor Spring	5
Ignition	7
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewind Starter	6
Valves	2



PRINTED IN U.S.A.

COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 129700 TO 129799 user guide](http://yourpdfguides.com/dref/3640267)
<http://yourpdfguides.com/dref/3640267>

Manual abstract:

2 OF SERVICE MANUAL 129700 Illustrated Parts List Model Series 129700 TYPE NUMBERS 0108 through 1777. TABLE OF CONTENTS Alternator

.
.
.
. 7 Air Cleaner

.
.
.
. 4 Blower Housing/Shrouds

. 6 Camshaft
.
.
.

2 Carburetor
.
.
. 3 Controls

.
.
.
. 5 Crankshaft

.
.
. 2 Cylinder
.

.
.
.
2 Electric Starter

. 7 Electrical
.
.
.

. 7 Engine Sump
.
.
. 2 Exhaust System

.
.
. 4 Flywheel
.

.
. 6 Flywheel Brake
.
.

. 7 Fuel Supply
.
.
. 5 Governor Spring

.
.
. 5 Ignition
.

.....
 .. 7 Kits/Gaskets ...

 . 2 & 3 Lubrication

 2 Piston Group

 2 Rewind Starter

 6 Valves

 2 PRINTED IN U.

S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 129700 1319 WARNING LABEL 1058 OPERATOR'S MANUAL 1330 REPAIR MANUAL 1019 LABEL KIT REQUIRED when replacing parts with warning labels affixed. 1 2 3 718 584 10 8 9 11 50 54 585 684 306 51 307 7 869 870 871 36 33 35 868 34 40 45 847 523 13 5 40 45 287 842 337 635 383 25 27 24 1095 VALVE GASKET SET 9 7 28 26 29 32A 883 27 32 146 741 16 525 374 524 46 46A 715 43 374 743 22 4A 12 12 83 721 101 358 ENGINE GASKET SET 3 7 20 20A 51 163 524 9 585 4 357 12 617 668 842 883 15A 15 20 15 20 20A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0485-2 Assemblies include all parts shown in frames. 2 06/27/2008 129700 125 365 133 104 975 137 130A 98 94 276 118 276 117 276 127 130 95 617 134 633 163 97 PRIMER SYSTEM 125A 109 217 633 365 133 217 975 137 104 134 97 163 108 127 633 98 94 127A 130 95 130A 617 276 118A 276 117A 276 CHOKE SYSTEM 121 CARBURETOR OVERHAUL KIT 94 134 276 617 104 127 127A 163 163 137 633 977 CARBURETOR GASKET SET 137 276 617 633 Illustrations cover a range of engines. @@@@Parts shown without corresponding text may not be used on your specific engine.

0485-4 Assemblies include all parts shown in frames. 4 06/27/2008 129700 972 957A 930 1059 1040 190 670 958 957A 601A 187 601 187A 601 187B 601 240 601 843 222 621 98A 222A 188 227 562 621 505 668 668 202 615 404 616 268 271 269 270 267 265 209 209A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0485-5 Assemblies include all parts shown in frames. @@@@Parts shown without corresponding text may not be used on your specific engine. 0485-7 Assemblies include all parts shown in frames. 7 06/27/2008 129700 REF.

NO. 1 2 PART NO. DESCRIPTION REF. NO. 20A 22 23A PART NO.

DESCRIPTION 697324 Cylinder Assembly 399269 Kit-Bushing/Seal (Magneto Side) 3 K299819S Seal-Oil (Magneto Side) 4 493279 Sump-Engine 4A 493365 Sump-Engine (Auxiliary PTO) 5 691160 Head-Cylinder 7 K692249 Gasket-Cylinder Head (Used After Code Date 94063000). ----- Note ----- K272200S Gasket- Cylinder Head (Used Before Code Date 94070100). @@@@691450 Crankshaft (Used After Code Date 97011200). Used on Type No(s). @@@@694440 Crankshaft (Used Before Code Date 97011300).

Used on Type No(s). @@@@691452 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0628, 0643, 0650, 0651, 0666, 0673, 0674, 0675, 1773. 694059 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0128, 0150, 0628, 0643, 0650, 0651, 0666, 0673, 0674, 0675. @@@@222698S Key-Flywheel 795429 Piston Assembly (Standard) (Used After Code Date 07090300). ----- Note ----- 791096 Piston Assembly (Used After Code Date 04031400 and Before Code Date 07090400). 494058 Piston Assembly (Standard) (Used Before Code Date 97011300).

795430 Piston Assembly (.020" Oversize) (Used After Code Date 07090300). 791325 Piston Assembly (.020" Oversize) (Used After Code Date 04102100 and Before Code Date 07040400). 494060 Piston Assembly (.020" Oversize) (Used Before Code Date 97011300). 24 25 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977.

Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0485-8 Assemblies include all parts shown in frames.

8 06/27/2008 129700 REF. NO. 26 PART NO. DESCRIPTION REF. NO. 27 PART NO. DESCRIPTION REF. NO. 40 43 45 46 PART NO. 692194 691997 690548 691449 DESCRIPTION Retainer-Valve Slinger-Governor/Oil Tappet-Valve Camshaft (Used After Code Date 96062900).

----- Note ----- 492830 Camshaft (Used Before Code Date 96060300). Camshaft (Counterclockwise) (Used After Code Date 96062900). Manifold-Intake Gasket-Intake Screw (Intake Manifold) Housing-Rewind Starter Housing-Rewind Starter Spring-Rewind Starter Rope-Starter (Cut To Required Length) Insert-Grip Grip-Starter Rope (Pistol Grip) Grip-Starter Rope (2 Piece) Screw (Rewind Starter) Screen-Rotating Screen-Rotating Screw (Flywheel Guard) Lock-Muffler Screw Shaft-Auxiliary Drive ----- Note ----- 690522 Shaft-Auxiliary Drive Used on Type No(s). 0626, 0638, 0640, 1738. 795431 Ring Set (Standard) (Used After Code Date 07090300). ----- Note ----- 791098 Ring Set (Standard) (Used After Code Date 04031400 and Before Code Date 07090400). @@@@493261 Ring Set (Standard) (Used Before Code Date 97011300). @@@@691866 Lock-Piston Pin (Used After Code Date 97011200). @@@@499423 Pin-Piston (Standard) (Used After Code Date 97011200). @@@@499424 Rod-Connecting (Standard) (Used After Code Date 97011200).

@@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. @ 9 06/27/2008 129700 REF. NO. 94 95 97 PART NO. DESCRIPTION REF. NO. 118 PART NO. DESCRIPTION
REF. NO. 125 PART NO.

@----- Note ----- 494870 Jet-Main (Standard) (Used After Code Date 95102900 and Before Code Date 96060300). @493637 Jet-Main (Standard)
(Used Before Code Date 94070400). 498976 Jet-Main (Standard) (Used After Code Date 96060200). @497315 Jet-Main (High Altitude) (Used After Code
Date 02092900). @@@@496063 Jet-Main (High Altitude) (Used Before Code Date 94070400). 498977 Jet-Main (High Altitude) (Used After Code Date
96060200). @498260 Kit-Carburetor Overhaul 698444 Carburetor (Primer System) (Used After Code Date 96060200).



[You're reading an excerpt. Click here to read official BRIGGS &
STRATTON 129700 TO 129799 user guide
http://yourpdfguides.com/dref/3640267](http://yourpdfguides.com/dref/3640267)

----- Note ----- 498170 Carburetor (Primer System) (Used After Code Date 94070300 and Before Code Date 96060300). 496114 Carburetor (Primer System) (Used Before Code Date 94070400). 498964 Carburetor (Choke System) (Used After Code Date 96060200).

----- Note ----- 497353 Carburetor (Choke System) (Used Before Code Date 96060300). 497501 Carburetor (Choke System) Used on Type No(s). 0110, 0111, 0113, 0114, 0115, 0119, 0120, 0123, 0124, 0128, 0133, 0134, 0137. @@No.358.

D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No.

977. @@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref.

No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0485-12 Assemblies include all parts shown in frames. 12 06/27/2008 129700 REF. NO. 635 651 664 668 670 676 676B 677 678 684 689 689A 697 715 718 721 741 PART NO.

DESCRIPTION REF. NO. 742 743 745 783 783A 784 785 789 789A 801 802 PART NO.

DESCRIPTION REF. NO. 868 869 PART NO. DESCRIPTION 66538S Boot-Spark Plug 691660 Screw (Starter Gear Cover) 691087 Nut (Key Switch) K493823 Spacer 692294 Spacer-Fuel Tank 396548 Deflector-Muffler (Single Louver) 397931 Deflector-Muffler (Direct Out) (3/4" Diameter) 690661 Screw (Muffler Deflector) 224278 Spacer-Rewind 690345 Screw (Breather Passage Cover) 691855 Spring-Friction 262625 Spring-Friction 692127 Screw (Drive Cap) 691147 Screw (Shaft Stop) 690959 Pin-Locating 690449 Stop-Shaft 795755 Gear-Timing (Plastic) ----- Note ----- 794388 Gear-Timing (Use Without Woodruff Key) (Used After Code Date 07093000). 790345 Gear-Timing (Use Without Woodruff Key) (Used Before Code Date 07100100).

@@----- Note ----- 695975 Cap-End (Used Before Code Date 00040700). 695266 Housing-Starter (Used After Code .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 129700 TO 129799 user guide](http://yourpdfguides.com/dref/3640267)

<http://yourpdfguides.com/dref/3640267>