



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 12C802. You'll find the answers to all your questions on the BRIGGS & STRATTON 12C802 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 12C802
User guide BRIGGS & STRATTON 12C802
Operating instructions BRIGGS & STRATTON 12C802
Instructions for use BRIGGS & STRATTON 12C802
Instruction manual BRIGGS & STRATTON 12C802

FORM MS-0027-499
REPLACES FORM MS-0027-399
FILE IN SEC 2 OF SERVICE MANUAL
12C800 to 12C899

Illustrated Parts List

Model Series

12C800 to 12C899

TYPE NUMBERS
0800, 0833, 0834,
0835, 0808, 0815,
0816, 0817, 0830,
0831, 1108, 1115,
1117, 1120, 1700,
1908, 2308, 2320.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- Refer to the Illustrations and compare the original part with Illustration. The number next to the Illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12C802 user guide](http://yourpdfguides.com/dref/3639827)
<http://yourpdfguides.com/dref/3639827>

Manual abstract:

2 OF SERVICE MANUAL 12C800 to 12C899 Illustrated Parts List Model Series 12C800 to 12C899 TYPE NUMBERS 0600, 0633, 0634, 0635, 0808, 0815, 0816, 0817, 0830, 0831, 1108, 1116, 1117, 1120, 1700, 1908, 2308, 2320. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames.

All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. @@@@COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved.

@@@NO. 1 2 PART NO. DESCRIPTION REF. NO. 177 287 306 307 337 383 523 525 584 585 635 684 525 8 871 9 1081 337 635 870 1058 OWNER'S MANUAL PART NO.

DESCRIPTION REF. NO. 847 869 870 871 REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. PART NO. DESCRIPTION 494062 Cylinder Assembly 399269 Bushing/Seal Kit (Magneto Side) 3 K299819 Oil Seal (Magneto Side) 5 691160 Cylinder Head 7 K692249 Cylinder Head Gasket 8 495786 Breather Assembly 9 K272481 Breather Gasket 10 94650 Screw (Breather Assembly) 11 691781 Breather Tube 13 690912 Screw (Cylinder Head) 50 497465 Intake Manifold 51 K272199 Intake Gasket 54 691650 Screw (Intake Manifold) K691031 ORing Seal (Dipstick) 690940 Screw (Dipstick Tube) 690450 Cylinder Shield 690345 Screw (Cylinder Shield) 802592 Sparkplug 89838 Sparkplug Wrench 495264 Dipstick 495265 Dipstick Tube 692342 Breather Passage Cover K691879 Breather Passage Gasket 66538 Sparkplug Boot 690345 Screw (Breather Passage Cover) 1019 1058 1081 692017 Dipstick/Tube Assembly 691155 Valve Seat (Intake) 690380 Valve Seat (Exhaust) 262001 Guide Bushing (Exhaust Valve) Note 63709 Guide Bushing (Intake Valve) 494256 Label Kit 273693 Owner's Manual Emission Engines Note 272262 Owner's Manual NonEmission Engines K692296 O-Ring Seal (Dipstick Tube) K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref. 121. z Included in Carburetor Gasket SetSee Ref.

977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 05372 Assemblies include all parts shown in frame. 2 69 12C800 to 12C899 25 27 28 27 29 32 26 REF. NO. 25 PART NO. DESCRIPTION REF. NO. 26 PART NO.

DESCRIPTION REF. NO. 27 PART NO. DESCRIPTION 499433 Piston Assembly (Standard) (Used After Code Date 97011200). Note 494058 Piston Assy. (Standard) (Used Before Code Date 97011300). 499434 Piston Assy. (.010 O.S.

) (Used After Code Date 97011200). 494059 Piston Assy. (.010 O.S.) (Used Before Code Date 97011300). 499435 Piston Assy. (.020 O.S.

) (Used After Code Date 97011200). 494060 Piston Assy. (.020 O.S.) (Used Before Code Date 97011300). 499436 Piston Assy. (.030 O.S.

) (Used After Code Date 97011200). 494061 Piston Assy. (.030 O.S.

) (Used Before Code Date 97011300). 499425 Ring Set (Standard) (Used After Code Date 97011200). Note 493261 Ring Set (Standard) (Used Before Code Date 97011300). 499426 Ring Set (.010 O.

S.) (Used After Code Date 97011200). 493388 Ring Set (.010 O.S.) (Used Before Code Date 97011300). 499427 Ring Set (.020 O.S.) (Used After Code Date 97011200).

493389 Ring Set (.020 O.S.) (Used Before Code Date 97011300). 499428 Ring Set (.030 O.S.) (Used After Code Date 97011200). 493390 Ring Set (.030 O.S.) (Used Before Code Date 97011300). 28 29 32 K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref.

121. 691866 Piston Pin Lock (Used After Code Date 97011200). Note 691588 Piston Pin Lock (Used Before Code Date 97011300). 499423 Piston Pin (Standard) (Used After Code Date 97011200). Note 298909 Piston Pin (Standard) (Used Before Code Date 97011300).

298908 Piston Pin (.005 O.S.) (Used Before Code Date 97011300). 499424 Connecting Rod (Standard) (Used After Code Date 97011200). Note 490566 Connecting Rod (Standard) (Used Before Code Date 97011300). 490743 Connecting Rod (.020 Undersize) (Used Before Code Date 97011300). @@977. Included in Valve Overhaul Gasket SetSee Ref.

1095. 05373 Assemblies include all parts shown in frame. @@@NO. 16 PART NO. DESCRIPTION REF. @@@Used on Type No(s). 0817, 1116. 694059 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0817, 1116.

691455 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0831. 691375 Crankshaft (Used Before Code Date 97011300). Used on Type No(s).

0831. REF. NO. 24 33 34 35 36 40 45 146 741 PART NO. @@@@691450 Crankshaft (Used After Code Date 97011200).

Used on Type No(s). 0600, 0808, 1108 1700, 1908, 2308. 493282 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0600, 0808, 1108. K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref. 121. z Included in Carburetor Gasket SetSee Ref.

977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 05374 Assemblies include all parts shown in frame. @@@NO. 4 4A 12 15 15A 20 20A 22 PART NO. @@@@NO. 46A 15A 20A 15 PART NO. REF. NO.

@@@@691459 Camshaft (Counterclockwise) (Used After Code Date 96060200). Used on Type No(s). 0635. 493738 Camshaft (Counterclockwise) (Used Before Code Date 96060300). Used on Type No(s).

0635. @@@@0635. K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref.

121. z Included in Carburetor Gasket SetSee Ref. 977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 05375 Assemblies include all parts shown in frame. @@@NO. 94 PART NO. DESCRIPTION REF. NO.

PART NO. DESCRIPTION REF. NO. 127 130 PART NO. @@@@Used on Type No(s). 0633, 0634. @@@0633, 0634. @@@0633, 0634. @@ Note 497466 Main Jet (Standard) (Used Before Code Date 96060300). 493637 Main Jet (Standard) (Used Before Code Date 94070400).

[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12C802 user guide](#)



<http://yourpdfguides.com/dref/3639827>

Used on Type No(s). 0633, 0634. 125 496495 Main Jet (High Altitude) (Used After Code Date 94070300). 692677 Main Jet (High Altitude) (Used Before Code Date 94070400). Used on Type No(s).

0633, 0634. 498966 Carburetor (Used After Code Date 96060200). Note 498254 Carburetor (Used After Code Date 95102900 and Before Code Date 96060300). 498170 Carburetor (Used After Code Date 94070300 and Before Code Date 95103000). Used on Type No(s).

0633, 0634. 496114 Carburetor (Used Before Code Date 94070400). Used on Type No(s). 0633, 0634. 133 398187 134 D398188 137 Dz 276 Dz 365 692524 617 Dz 270344 708 D691321 975 493640 K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref. 121. z Included in Carburetor Gasket SetSee Ref. 977.

Included in Valve Overhaul Gasket SetSee Ref. 1095. 05376 Assemblies include all parts shown in frame. 6 69 12C800 to 12C899 271 268 269 604 227 925 564 209 202 789 333 851 1119 474 334 910 356 REF. NO. 188 202 209 PART NO. REF. NO. 269 PART NO. REF.

NO. 616 621 668 745 789 851 910 922 923 925 935 PART NO. 615 404 270 616 188 222 621 562 668 505 935 1160 745 923 621 922 DESCRIPTION DESCRIPTION DESCRIPTION 222 227 268 690877 Screw (Control Bracket) 691829 Mechanical Governor Link 690319 Governor Spring Note 691292 Governor Spring Used on Type No(s). 0600, 0808, 0830, 0831, 1108, 1700, 1908, 2308. 692031 Control Bracket 690783 Governor Control Lever 691072 Control Wire Casing (48" Long Cut to Required Length) 691025 Control Wire Casing (72" Long Cut to Required Length) 270 271 333 334 356 404 474 505 562 564 604 615 691589 Control Wire (54" Long Cut to Required Length) 691026 Control Wire (78" Long Cut to Required Length) 691027 Nut (Control Wire Casing) 691028 Control Lever 802574 Magneto Armature 691061 Screw (Magneto Armature) 398808 Stop Wire 690272 Washer (Governor Crank) 691991 Alternator 231082 Nut (Gov. Control Lever) 94852 Bolt (Gov. Control Lever) 691683 Screw (Control Cover) 691757 Control Cover 690340 Governor Shaft Retainer 1119 1160 691306 Governor Ce 99010100). K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref.

121. z Included in Carburetor Gasket SetSee Ref. 977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 053711 Assemblies include all parts shown in frame. 11 69 12C800 to 12C899 608 65 592 55 58 144 459 689 456 597 60 REF. NO. 55 58 PART NO. DESCRIPTION REF.

NO. 144 456 459 597 PART NO. DESCRIPTION REF. NO. 592 608 689 PART NO. DESCRIPTION 60 65 691421 Rewind Starter Housing 280399 Starter Rope (Cut to Required Length) 281434 Starter Rope Grip 690759 Screw (Rewind Starter) 498144 Pulley/Spring Assembly 692299 Pawl Friction Plate 281505 Ratchet Pawl 691696 Screw (Pawl Friction Plate) 690800 Nut (Rewind Starter) 497680 Rewind Starter 691855 Friction Spring K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref. 121. z Included in Carburetor Gasket SetSee Ref. 977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 053712 Assemblies include all parts shown in frame. @@NO. 55A 144A 57 58 PART NO. DESCRIPTION REF. NO. @@NO. @@No.

455) 224278 Rewind Spacer 262625 Friction Spring 224322 Washer (Pawl Friction Plate) K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref. 121. z Included in Carburetor Gasket SetSee Ref. 977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 053713 Assemblies include all parts shown in frame. 13 69 12C800 to 12C899 309 510 742 545 937 544 651 783 784 785 783A 513 310 803 801 802 697 REF.

NO. 309 310 510 513 544 PART NO. DESCRIPTION REF. NO. 545 651 697 742 783 PART NO. DESCRIPTION REF. NO. 783A 784 785 801 802 803 937 PART NO. 691269 692341 692352 690782 690787 690785 691325 DESCRIPTION Pinion Gear Starter Gear Cover Starter Cover Gasket Drive Cap End Cap Starter Housing Starter Spline 691376 Starter Motor 692327 Bolt (Starter Motor) 494147 Starter Drive 692358 Drive Clutch 690786 Starter Armature 492919 Washer Set (Starter Motor) 690345 Screw (Starter Gear Cover) 691127 Screw (Drive Cap) 93941 ERing Retainer 691918 Pinion Gear K Included in Gasket SetSee Ref. 358.

D Included in Carburetor Overhaul KitSee Ref. 121. z Included in Carburetor Gasket SetSee Ref. 977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 053714 Assemblies include all parts shown in frame. 14 69 12C800 to 12C899 358 ENGINE OVERHAUL GASKET SET 585 9 12 883 668 163 3 20 977 CARBURETOR GASKET SET 163 9 617 708 276 137 137 708 276 51 177 1081 7 1095 VALVE OVERHAUL GASKET SET 7 883 121 CARBURETOR OVERHAUL KIT 163 134 617 127 104 REF. NO. 3 PART NO.

DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION K299819 Oil Seal (Magneto Side) 7 K692249 Cylinder Head Gasket 9 K272481 Breather Gasket 12 K692232 Crankcase Gasket 20 K399781 Oil Seal (PTO Side) 51 K272199 Intake Gasket 104 D691242 Float Hinge Pin 121 498260 Carburetor Overhaul Kit 127 D Welch Plug (Sold in Kit Only) 134 D398188 Needle/Seat Kit 137 D Bowl Gasket (Sold in Kit Only) 163 KD272653 Air Cleaner Gasket 177 K691031 ORing Seal (Dipstick) 276 D Sealing Washer (Sold in Kit Only) 358 497316 Engine Overhaul Gasket Set 585 K691879 Breather Passage Gasket 617 D270344 ORing Seal (Intake Manifold) 668 K493823 Spacer (Includes 2) 708 D691321 Dust Seal (Throttle Shaft) 883 K691881 Exhaust Gasket 977 498261 Carburetor Gasket Set 1081 K692296 ORing Seal (Dipstick Tube) 1095 498528 Valve Overhaul Gasket Set K Included in Gasket SetSee Ref. 358. D Included in Carburetor Overhaul KitSee Ref. 121.

z Included in Carburetor Gasket SetSee Ref. 977. Included in Valve Overhaul Gasket SetSee Ref. 1095. 053715 Assemblies include all parts shown in frame. 15 69 .



You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12C802 user guide
<http://yourpdfguides.com/dref/3639827>