



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 12H800 TO 12H899. You'll find the answers to all your questions on the BRIGGS & STRATTON 12H800 TO 12H899 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual BRIGGS & STRATTON 12H800 TO 12H899**
- User guide BRIGGS & STRATTON 12H800 TO 12H899**
- Operating instructions BRIGGS & STRATTON 12H800 TO 12H899**
- Instructions for use BRIGGS & STRATTON 12H800 TO 12H899**
- Instruction manual BRIGGS & STRATTON 12H800 TO 12H899**



FORM MS-9990-07/01/2008
REPLACES FORM MS-9990-06/08/2008
FILE IN SECT. 2 OF SERVICE MANUAL

12H800

Illustrated Parts List

Model Series

12H800

TYPE NUMBERS
0652 through 6699.

TABLE OF CONTENTS

Alternator	7
Air Cleaner	4
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	3
Controls	5
Crankshaft	2
Cylinder	2
Electric Starter	7
Electrical	7
Engine Sump	2
Exhaust System	4
Flywheel	7
Flywheel Brake	7
Fuel Supply	5
Governor Spring	5
Ignition	7
Kits/Gaskets	2 & 3
Lubrication	2
Piston Group	2
Rewind Starter	7
Valves	2



PRINTED IN U.S.A.
COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12H800 TO 12H899 user guide](http://yourpdfguides.com/dref/3639766)

<http://yourpdfguides.com/dref/3639766>

Manual abstract:

2 OF SERVICE MANUAL 12H800 Illustrated Parts List Model Series 12H800 TYPE NUMBERS 0652 through 6699. TABLE OF CONTENTS Alternator

.
.
.
. 7 Air Cleaner

.
.
.
. 4 Blower Housing/Shrouds

. 6 Camshaft
.
.
.

. 2 Carburetor
.
.
. 3 Controls

.
.
.
. 5 Crankshaft

.
.
. 2 Cylinder
.

.
.
. 2 Electric Starter
.

. 7 Electrical
.
.
.

. 7 Engine Sump
.
.
. 2 Exhaust System

.
.
. 4 Flywheel
.

.
.
. 7 Flywheel Brake
.

. 7 Fuel Supply
.
.
.

. 5 Governor Spring
.
.
. 5 Ignition

.....
.....
... 7 Kits/Gaskets .
.....

.....
... 2 & 3 Lubrication . .
.....
.....

..... 2 Piston Group . . .
.....
.....
.....

2 Rewind Starter
.....
.....
.. 7 Valves

.....
.....
.....

. 2 PRINTED IN U.S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 12H800 1319 WARNING LABEL 1058 OPERATOR'S MANUAL 1330 REPAIR MANUAL 1019 LABEL KIT REQUIRED when replacing parts with warning labels affixed. 1 2 584 718 10 8 9 3 306 306A 585 684 307 7 33 35 54 34 337 635 383 635A 1095 VALVE GASKET SET 9 7 26 28 883 29 32A 27 32 146 741 43 374 743 1102 4 12 4A 12 22 83 46 25 27 24 51 16 374 524 46A 715 721 101 287 525 868 40 36 869 870 871 11 50 40 45 45 847 523 842 13 5 358 ENGINE GASKET SET 3 7 20 20A 51 163 524 9 585 12 617 668 842 883 15 20 15 20 20A 15A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-2 Assemblies include all parts shown in frames.

2 07/01/2008 12H800 125 365 163 98 97 365 125A 163 692 108 127 130 134 94 133 104 975 137 98 95 617 217 109A 633A 133 104 94 975 137 134 130 95 617 633 97 633 127 109 217 118 276 276 117 276 118A 276 117A 276 276 633 PRIMER SYSTEM CHOKE SYSTEM 125B 109B 97 633A 633 121 CARBURETOR OVERHAUL KIT 163 231 108A 127 94 134 276 617 104 134 130 617 127 137 163 633 633A 133 104 975 137 977 CARBURETOR GASKET SET 137 163 118B 276 117B 276 276 617 633 633A AUTOCHOKE SYSTEM Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-3 Assemblies include all parts shown in frames. 3 07/01/2008 12H800 425A 968B 966A 159 967A 445A 443A 966B 970 163 976 529 163 529 976 291 1386 1388 1387 883 300 883 300A 300B 81 613 832 836 832A 836 81 613A 836A 832B 836B 81 613B 836 832E 836C 676 676A 676B 677 676C 677 994 677 677 346 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-4 Assemblies include all parts shown in frames. 4 07/01/2008 12H800 972 957A 930 972B 957B 1059 957 190 957A 670 957B 187 601 187A 601 187B 601 240 601 187C 601A 958 601A 843 222 621 98A 668 222D 222A 843A 188 222B 621 222C 621 227 562 668 668 505 202 615 404 209 267 265 265A 265B 209A 209B 616 668 222E 668 268 271 269 270 267 668 Illustrations cover a range of engines. @@@@Parts shown without corresponding text may not be used on your specific engine. 0990-7 Assemblies include all parts shown in frames. 7 07/01/2008 12H800 REF.

NO. 1 2 PART NO. DESCRIPTION REF. NO. PART NO.

DESCRIPTION REF. NO. 12 13 15 15A PART NO. DESCRIPTION 697322 Cylinder Assembly 399269 Kit-Bushing/Seal (Magneto Side) 3 K299819S Seal-Oil (Magneto Side) 4 493279 Sump-Engine ----- Note ----- 498983 Sump-Engine Used on Type No(s). 1167, 1715, 1955, 1961, 2320, 2324, 2331, 2367, 2673, 2681, 3182. 696294 Sump-Engine Used on Type No(s). 1375, 1376, 1379, 1717, 1718, 1719, 1730, 1731, 1732, 1735, 1754, 1781, 1792, 1795, 1809, 1811, 1959, 1960, 1996, 2002, 2042, 2043, 2108, 2326, 3181, 3187, 3188. 4A 493365 Sump-Engine (Auxilliary PTO) 5 691160 7 K692249 8 495786 9 K699833 10 94650 11 Head-Cylinder Gasket-Cylinder Head Breather Assembly Gasket-Breather Screw (Breather Assembly) 691781 Tube-Breather K692232 Gasket-Crankcase 690912 Screw (Cylinder Head) 691680 Plug-Oil Drain (Square Socket) 691093 Plug-Oil Drain (Hex Socket) K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No.

977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-8 Assemblies include all parts shown in frames. 8 07/01/2008 12H800 REF. NO. 16 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 691452 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0664,0665,0666,0670, 0671,0672,0680,0840, 0866,0868,0873,0877, 0878,1150,1166,1170, 1171,1320,1326,1332, 1366,1368,1370,1371, 1372,1374,1375,1376, 1377,1378,1379,1544, 1559,1569,1723,1727, 1730,1731,1733,1734, 1736,1737,1738,1739, 1740,1748,1749,1770, 1771,1784,1785,1786, 1790,1794,1795,1801, 1803,1804,1805,1810, 1811,1814,1816,1818, 1821,1823,1825,1826, 1827,1829,1830,1831, 1832,1835,1837,1839, 1844,1845,1846,1847, 1849,1852,1914,1917, 1919,1920,1926,1932, 1935,1936,1941,1942, 1943,1947,1948,1958, 1959,1962,1964,1965, 1966,1967,1970,1973, 1976,1977,1983,1985, 1988,1991,1992,1993, 1994,1995,1996,2001, 2002,2006,2008,2009, 2010,2012,2014,2015, 2017,2023,2027,2028, 2035,2042,2043,2108, 2148,2149,2350,2644, 2669,2676,3130,3132, 3137,3166,3169,3170, 3181,3185,3186,3189, 3313,3314,3315,3320, 3322,3323,3325. 694059 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0866,0868,0873,0877, 1166,1170,1332,1366, 1368,1370,1371,1544, 1559,1569,1977. REF. NO.

PART NO. DESCRIPTION 691455 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 1149,1548,1701,1925, 2312,2313,2314,2315, 2316,2324,2328,2352, 2360,2370,2373,2381, 2383,2384,2394,2395, 2396,3172,3173,3180, 3318,3319. 691375 Crankshaft (Used Before Code Date

97011300). Used on Type No(s). 1149,1548. 692822 Crankshaft Used on Type No(s). 1766. 691482 Crankshaft Used on Type No(s).

1961,2329,2334, 3183. 694079 Crankshaft Used on Type No(s). 1717,1767,1768,1775. 692717 Crankshaft Used on Type No(s). 1955,1986,3178. 694478 Crankshaft Used on Type No(s). 1777. 694849 Crankshaft Used on Type No(s). 1714,1726,2013,2044, 2349,2383,2391,2635, 2683. 694850 Crankshaft Used on Type No(s).
1836,2331,2333,2681. 696009 Crankshaft Used on Type No(s). 1720,1776,1778,1840, 1841,2032,2036,2039, 2040. 696290 Crankshaft Used on Type No(s).



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12H800 TO 12H899 user guide](http://yourpdfguides.com/dref/3639766)

<http://yourpdfguides.com/dref/3639766>

2320.

691454 Crankshaft Used on Type No(s). 1706,2151. 791061 Crankshaft Used on Type No(s). 2037,2038. 691451 Crankshaft (Used After Code Date 97011200).

----- Note ----- 694442 Crankshaft (Used Before Code Date 97011300). 691450 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0823,1520,1530,1531, 1532,1533,1567,1705, 1718,1746,1747,1751, 1769,1782,1850,1851, 1905,1906,1907,1910, 1911,1912,1913,1915, 1916,1918,1923,1939, 1940,1950,1951,1952, 1972,1975,1979,1980, 1987,2018,2019,2024, 2029,2150,2313,2375. 2376,2379,2380,2609, 2610,2611,2612,2630, 2631,2649,2667,2677, 2678,2679,2686,3120, 3123,3138,3140,3167, 3176,3184,3187,3188. 694440 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0823,1520,1530,1531, 1532,1533,1567,2630, 2631. 692980 Crankshaft (Used After Code Date 97011200). Used on Type No(s).

0658,0660,1570,1758, 1760,1763,2670. 694443 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0658,0660,1758. K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-9 Assemblies include all parts shown in frames. 9 07/01/2008 12H800 REF. NO.

PART NO. DESCRIPTION REF. NO. 25 PART NO. DESCRIPTION REF. NO. 26 PART NO. DESCRIPTION 20 K399781S Seal-Oil (PTO Side) 20A K691952 Seal-Oil (PTO Side) (Auxilliary PTO) 22 691092 Screw (Crankcase Cover/ Sump) 23A 691987 Flywheel ----- Note ----- 691992 Flywheel Used on Type No(s). 0667, 0878, 1149, 1167, 1369, 1548, 1559, 1569, 1701, 1714, 1715, 1726, 1729, 1750, 1786, 1802, 1807, 1817, 1822, 1824, 1836, 1849, 1919, 1932, 1941, 1942, 1948, 1955, 1961, 1967, 2005, 2009, 2013, 2016, 2037, 2038, 2044, 2320, 2324, 2331, 2333, 2349, 2367, 2383, 2391, 2635, 2669, 2673, 2681, 3133, 3178, 3179, 3183, 3324. 696291 Flywheel Used on Type No(s).

1375, 1376, 1379, 1717, 1718, 1719, 1730, 1731, 1732, 1735, 1754, 1781, 1792, 1795, 1809, 1811, 1959, 1960, 1996, 2001, 2002, 2042, 2043, 2108, 2326, 3181, 3187, 3188. 24 222698S Key-Flywheel 795429 Piston Assembly (Standard) (Used After Code Date 07090300). ----- Note ----- 791097 Piston Assembly (Standard) (Used After Code Date 04031400 and Before Code Date 07090400). 493262 Piston Assembly (Standard) (Used Before Code Date 97011300). 795430 Piston Assembly (.020" Oversize) (Used After Code Date 07090300). 791326 Piston Assembly (.020" Oversize) (Used After Code Date 04102100 and Before Code Date 07040400). 499431 Piston Assembly (.020" Oversize) (Used After Code Date 97011200 and Before Code Date 04102200). 493386 Piston Assembly (.020" Oversize) (Used Before Code Date 97011300). 493387 Piston Assembly (.030" Oversize) (Used Before Code Date 97011300). 795431 Ring Set (Standard) (Used After Code Date 07090300).

----- Note ----- 791098 Ring Set (Standard) (Used After Code Date 04031400 and Before Code Date 07090400). 499425 Ring Set (Standard) (Used After Code Date 97011200 and Before Code Date 04031500). 493261 Ring Set (Standard) (Used Before Code Date 97011300). 795432 Ring Set (.020" Oversize) (Used After Code Date 07090300).

791324 Ring Set (.020" Oversize) (Used After Code Date 04102100 and Before Code Date 07090400). 499427 Ring Set (.020" Oversize) (Used After Code Date 97011200 and Before Code Date 04102200). 493389 Ring Set (.020" Oversize) (Used Before Code Date 97011300). 493390 Ring Set (.030" Oversize) (Used Before Code Date 97011300). 691866 Lock-Piston Pin (Used After Code Date 97011200). ----- Note ----- 691588 Lock- Piston Pin (Used Before Code Date 97011300).

27 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref.

No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-10 Assemblies inc4870 Jet-Main (High Altitude) Used on Type No(s). 0678,0679,1726,1746, 1777,1801,1802,1803, 1804,1805,1836,1926, 1942,1955,1986,2331, 2349. 692677 Jet-Main (High Altitude) 498260 Kit-Carburetor Overhaul 498170 Carburetor (Primer System) ----- Note ----- 498254 Carburetor (Primer System) Used on Type No(s). 1538. 790821 Carburetor (Primer System) Used on Type No(s). 0680,1749,1837,1850, 1917,2035. 499059 Carburetor (Choke System) Used on Type No(s).

1701,1714,1715,1786, 1932,1961,2013,2044, 2324,2329,2333,2334, 2349,2367,2383,2391, 2635,2673,2681,3178, 3183. @@@@790978 Carburetor (Choke System) Used on Type No(s). 0678,0679,1746,1801, 1802,1803,1804,1805. 792253 Carburetor (Choke System) (Used After Code Date 05091800). Used on Type No(s). 1726,1777,1836,1926, 1942,1955,1986,2331, 2349. 499059 Carburetor (Choke System) (Used Before Code Date 05070100). Used on Type No(s). 1726,1777,1926,1942, 1955,1986,2331,2349. @@@@@No.

358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines.

@@12 07/01/2008 12H800 REF. NO. 209 PART NO. DESCRIPTION REF. NO.

209B PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 691292 Spring- Governor Used on Type No(s).

@@691852 Spring- Governor Used on Type No(s). @@691864 Spring-Governor Used on Type No(s). 2329. ----- Note ----- 690242 Spring- Governor Used on Type No(s). 1932. 690241 Spring- Governor Used on Type No(s). 1961,3183. 790944 Spring- Governor Used on Type No(s). 1701. 690567 Spring-Governor Used on Type No(s).

1167. ----- Note ----- 690568 Spring- Governor Used on Type No(s). 1149,1548. 691835 Spring- Governor Used on Type No(s). 0664,0665,0666,0667, 1170,1368,1369,1370, 1373. 262663 Spring- Governor Used on Type No(s). 0671,0672. 690569 Spring- Governor Used on Type No(s). 1374,1377,1747. 791157 Spring- Governor Used on Type No(s).

1746,1801,1803,1804, 1805. 791315 Spring- Governor Used on Type No(s). 0678, 0679. 792666 Spring- Governor Used on Type No(s). 1802.

@@@@693187 Spring- Governor Used on Type No(s). 2383,2683. 691291 Spring- Governor Used on Type No(s). 1715,1777,1786,1836, 1942,1955,1986,2320, 2324,2331,2349,2391, 3178. 691290 Spring- Governor Used on Type No(s).

@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. @@13 07/01/2008 12H800 REF. NO. 217 222 222A PART NO. DESCRIPTION REF. NO. 227 PART NO. DESCRIPTION REF. NO. 291 300 PART NO.

@@1149, 1167, 1548. 790982 Bracket- Control Used on Type No(s). 0678, 0679, 1746, 1801, 1803, 1804, 1805. @@@@792677 Muffler Used on Type No(s). 1844.

@@No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. @@14 07/01/2008
12H800 REF. NO.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12H800 TO 12H899 user guide](http://yourpdfguides.com/dref/3639766)

<http://yourpdfguides.com/dref/3639766>

304 PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION 696298 Housing- Blower Used on Type No(s). @@790826 Housing- Blower Used on Type No(s). 1706, 1829, 1831, 1835, 1846, 1965, 2018, 2022, 2028. 790983 Housing- Blower Used on Type No(s). 1738, 1739, 1808, 1823, 1825, 1826, 1964, 2015, 2017. 791291 Housing- Blower Used on Type No(s). 1750, 1807, 1817, 1824, 1849, 1851, 2016, 2034. REF.

NO. PART NO. DESCRIPTION 695892 Housing- Blower (Used After Code Date 06081300). Used on Type No(s). @@493293 Housing- Blower (Used Before Code Date 06081400). Used on Type No(s). @@790826 Housing- Blower (Used After Code Date 06081300). Used on Type No(s). 1748, 1816, 1827, 1844, 1845, 1963, 2011, 2012, 2041. 790983 Housing- Blower (Used Before Code Date 06081400). Used on Type No(s). 1748, 1816, 1847, 1963, 2011, 2012. 493293 Housing-Blower ----- Note ----- 493294 Housing- Blower Used on Type No(s). 0666, 0667, 0868, 0878, 1149, 1150, 1167, 1171, 1369, 1548, 1559, 1569, 1701, 1705, 1714, 1715, 1726, 1729, 1755, 1766, 1777, 1786, 1802, 1822, 1836, 1839, 1919, 1926, 1932, 1941, 1942, 1948, 1955, 1961, 1967, 1988, 2005, 2009, 2013, 2014, 2027, 2037, 2038, 2044, 2150, 2320, 2324, 2329, 2331, 2333, 2334, 2349, 2350, 2367, 2383, 2391, 2635, 2669, 2673, 2681, 3110, 3120, 3123, 3133, 3138, 3140, 3167, 3176, 3178, 3179, 3183, 3184, 3324. 695892 Housing- Blower Used on Type No(s). 1721, 1724, 1746, 1747, 1784, 1790, 1830, 1837, 1841, 1850, 1852, 1901, 1906, 1907, 1910, 1911, 1912, 1913, 1915, 1972, 1975, 1989, 2019, 2029, 2033, 2320, 2360, 2370, 2384, 2385, 2386, 2389, 2390, 2394, 2395, 2641, 2643, 2646, 2649, 2684, 2685, 2686, 3129, 3180, 3182, 3308, 3309, 3318, 3319, 3509. K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref.

No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-15 Assemblies include all parts shown in frames. 15 07/01/2008 12H800 REF. NO. 305 306 306A 307 309 309A 310 332 333 PART NO. DESCRIPTION REF. NO. 333A PART NO. DESCRIPTION REF. NO. 356 356A 356B 356D 356F 356H 358 359 363 365 373 374 383 404 425A 443A PART NO. 692390 690650 693010 496381 494250 690791 497316 691077 19069 691688 691612 691074 89838S 690272 690670 692523 DESCRIPTION Wire-Stop Wire-Stop Wire-Stop Wire-Stop Wire-Stop Gasket Set-Engine Washer (Ground Terminal) Flywheel Puller Screw (Carburetor) Nut (Ground Terminal) Washer (Camshaft) Wrench-Spark Plug Washer (Governor Crank) Screw (Air Cleaner Cover) Screw (Air Cleaner Primer Base) Filter-Air Cleaner Cartridge Cup-Flywheel Plate-Pawl Friction Plate-Ratchet Alternator Screw (Stop Switch Bracket) Washer (Key Switch) Nut (Governor Control Lever) Insulator Drive-Starter Clutch-Drive Terminal-Ground Dipstick Seal-Dipstick Tube Tube-Dipstick 691108 Screw (Blower Housing) 690450 Shield-Cylinder 790836 Shield-Cylinder 690345 Screw (Cylinder Shield) 695550 Motor-Starter (Used Before Code Date 07052900). 795092 Motor-Starter (Used After Code Date 07052800). 692327 Bolt (Starter Motor) 690662 Nut (Flywheel) 802574 Armature-Magneto ----- Note ----- 790817 Armature- Magneto Used on Type No(s). 0680,1738,1739,1748, 1749,1750,1807,1808, 1816,1817,1844,1846, 1847,1917,1963,1964, 1965,2011,2021, 2034. 792640 Armature-Magneto (Screw On Spark Plug Boot) ----- Note ----- 793353 Armature- Magneto (Snap In Spark Plug Boot) 792631 Armature- Magneto (Screw On Spark Plug Boot) Used on Type No(s). 0680,1706,1739,1748, 1749,1750,1807,1808, 1816,1823,1824,1825, 1829,1831,1835,1837, 1917,1963,1965,2011, 2015,2016,2017,2021, 2028. 793354 Armature- Magneto (Snap In Spark Plug Boot) Used on Type No(s). 0680,1706,1739,1748, 1749,1750,1807,1808, 1816,1823,1824,1825, 1826,1827,1829,1831, 1835,1837,1844,1845, 1846,1847,1849,1850, 1917,1963,1965,2011, 2015,2016,2017,2021, 2028,2035,2041. 691061 Screw (Magneto Armature) 802592S Plug-Spark (Resistor) ----- Note ----- 697451 Plug-Spark (EMS) 690661 Screw (Spark Arrestor) 691396 Switch-Rocker 445A 491588S 455 791960 456 692299 459 281505S 474 691991 497 690664 500 505 507 510 513 520 523 524 525 691086 691251 691972 795093 692358 691084 499621 K692296 495265 334 337 346 347 K Included in Engine Gasket Set-Ref. No.358.

D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-16 Assemblies include all parts shown in frames. 16 07/01/2008 12H800 REF. NO. 529 544 545 562 564 PART NO. DESCRIPTION REF. NO. 613 PART NO. DESCRIPTION REF. NO. 664 668 670 676 676A 676B 676C 677 684 689 692 697 715 718 721 741 PART NO. DESCRIPTION 691923 Grommet 690786 Armature-Starter 492919 Washer Set (Starter Motor) 92613 Bolt (Governor Control Lever) 690664 Screw (Control Cover) ----- Note ----- 691132 Screw (Control Cover) 691142 Screw (Control Cover) 698589 Screw (Control Cover) 697734 Cover-Breather Passage K691879 Gasket-Breather Passage 690800 Nut (Rewind Starter) 691696 Screw (Pawl Friction Plate) 791850 Clamp-Hose 691038 Clamp-Hose 691757 Cover-Control 691344 Cover-Control 790703 Cover-Control 792418 Cover-Control 793770 Cover-Control 497680 Starter-Rewind 691340 Screw (Muffler) ----- Note ----- 790833 Screw (Muffler) Used on Type No(s). @@792678 Screw (Muffler) Used on Type No(s). 1844. 613A 691653 Screw (Muffler) 613B 691114 Screw (Muffler) 615 690340 Retainer-Governor Shaft 616 698801 Crank-Governor 617KDz270344 Seal-O Ring (Intake Manifold) 621 692310 Switch-Stop 627 692872 Bracket-Stop Switch ----- Note ----- 792565 Bracket-Stop Switch Used on Type No(s). 1701, 1836, 1961. 633 Dz691321 Seal-Choke/Throttle Shaft 633A Dz693867 Seal-Choke/Throttle Shaft 635 66538S Boot-Spark Plug 635A 792597 Boot-Spark Plug (Screw On Style) ----- Note ----- 793351 Boot-Spark Plug (Snap On Style) 651 691660 Screw (Starter Gear Cover) 691087 Nut (Key Switch) K493823 Spacer 692294 Spacer-Fuel Tank 396548 Deflector-Muffler (Louvered) 393756 Deflector-Muffler (Side Out) 397931 Deflector-Muffler (Direct Out) 493871 Deflector-Muffler (Side Out) (Extended) 690661 Screw (Muffler Deflector) 690345 Screw (Breather Passage Cover) 691855 Spring-Friction 690572 Spring-Detent 691127 Screw (Drive Cap) 691147 Screw (Shaft Stop) 690959 Pin-Locating 690449 Stop-Shaft 795755 Gear-Timing (Plastic) ----- Note ----- 794388 Gear-Timing (Use Without Woodruff Key) (Used After Code Date 07093000). 790345 Gear-Timing (Use Without Woodruff Key) (Used Before Code Date 07100100). 691830 Gear-Timing (Uses Woodruff Key) 93941 Retainer-E Ring 691772 Gear-Drive (Counterclockwise) ----- Note ----- 690516 Gear-Drive (Clockwise) Used on Type No(s). 0823. 691648 Screw (Brake) 564A 564B 584 585 592 597 601 601A 604 604A 604B 604C 604D 608 742 743 745 K Included in Engine Gasket Set-Ref.

No.358.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12H800 TO 12H899 user guide](http://yourpdfguides.com/dref/3639766)
<http://yourpdfguides.com/dref/3639766>

D Included in Carburetor Overhaul Kit-Ref. No. 121. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-17 Assemblies include all parts shown in frames. 17 07/01/2008 12H800 REF. NO.

783 783A 784 785 789A 789B PART NO. 691918 691269 795095 692352 691372 696547 DESCRIPTION Gear-Pinion Gear-Pinion Cover-Starter Gear Gasket-Starter Cover Harness-Wiring (Used Before Code Date 00040700). Harness-Wiring ----- Note ----- 696546 Harness- Wiring Used on Type No(s). 2333, 3138, 3179. Cap-Drive Cap-End (Used After Code Date 00040600).

----- Note ----- 695975 Cap-End (Used Before Code Date 00040700). Housing-Starter (Used After Code Date 00040600). ----- Note ----- 695975 Housing-Starter (Used Before Code Date 00040700). Guard-Muffler Guard-Muffler Guard-Muffler Guard-Muffler Screw (Muffler Guard) Screw (Muffler Guard) Screw (Muffler Guard) Seal-O Ring (Dipstick Tube) Sleeve-Lever (Speed Control) Sleeve-Lever (Choke) REF. NO. 847 PART NO. DESCRIPTION REF. NO. 923 923A PART NO. DESCRIPTION 692047 Dipstick/Tube Assembly 851 493880S Terminal-Spark Plug 851A 692424 Terminal-Spark Plug 853 695268 Adapter-Wire 868 697338 Seal-Valve 869 691155 Seat-Valve (Intake) 870 690380 Seat-Valve (Exhaust) 871 262001 Bushing-Valve Guide (Exhaust) ----- Note ----- 63709 Bushing-Valve Guide (Intake) 883 K691881 Gasket-Exhaust 892 690646 Switch-Key 910 691094 Stud (Alternator) 921 497233 Cover-Blower Housing 921A 695886 Cover-Blower Housing 921B 692931 Cover-Blower Housing Used on Type No(s).

2012, 2320, 2331, 2626, 2391, 2396. ----- Note ----- 692932 Cover-Blower Housing Used on Type No(s). 2333, 2334. 921C 695889 Cover-Blower Housing 921E 696262 Cover-Blower Housing 921F 697343 Cover-Blower Housing 921G 790701 Cover-Blower Housing 921H 790037 Cover-Blower Housing 921J 790036 Cover-Blower Housing 921K 699984 Cover-Blower Housing 921N 792675 Cover-Blower Housing 921P 792687 Cover-Blower Housing 921R 793771 Cover-Blower Housing 921U 794355 Cover-Blower Housing 922 691831 Spring-Brake 922A 692135 Spring-Brake 691994 Brake 695891 Brake ----- Note ----- 695891 Brake (Used Before Code Date 08050100). Used on Type No(s). 0680, 1700, 1706, 1721, 1724, 1737, 1746, 1747, 1748, 1749, 1753, 1782, 1816, 1818, 1820, 1827, 1829, 1830, 1831, 1835, 1837, 1841, 1844, 1845, 1846, 1850, 1852, 1906, 1907, 1908, 1910, 1911, 1912, 1913, 1915, 1917, 1930, 1963, 1965, 1966, 1972, 1975, 2011, 2012, 2018, 2019, 2021, 2022, 2024, 2028, 2029, 2033, 2035, 2041, 2148, 2149, 2308, 2639, 3170, 3185, 3189, 3509. 796136 Brake (Used After Code Date 08043000). Used on Type No(s). 0680, 1700, 1706, 1721, 1724, 1737, 1746, 1747, 1748, 1749, 1753, 1782, 1816, 1818, 1820, 1827, 1829, 1830, 1831, 1835, 1837, 1841, 1844, 1845, 1846, 1850, 1852, 1906, 1907, 1908, 1910, 1911, 1912, 1913, 1915, 1917, 1930, 1963, 1965, 1966, 1972, 1975, 2011, 2012, 2018, 2019, 2021, 2022, 2024, 2028, 2029, 2033, 2035, 2041, 2148, 2149, 2308, 2639, 3170, 3185, 3189, 3509. 801 802 690782 695267 803 695266 923B 832 832A 832B 832E 836 836A 836B 836C 842 843 843A 499034 691424 497683 793568 690664 690661 691147 790745 K691031 691884 691895 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. @@18 07/01/2008 12H800 REF. NO. 925 PART NO. DESCRIPTION REF. NO. 972 972B PART NO. DESCRIPTION REF. NO. 1095 1102 PART NO.

DESCRIPTION 795403 Cover-Linkage (Used After Code Date 07072200). @@@@2384, 3312, 3318, 3319. @@1375, 1376, 1379, 1717, 1718, 1719, 1730, 1731, 1732, 1735, 1754, 1781, 1792, 1795, 1959, 1960, 1996, 2001, 2002, 2042, 2043, 2108, 2326, 3181, 3187, 3188. 493640 Bowl-Float 694395 Primer-Carburetor 498261 Gasket Set-Carburetor 693514 Filter-Debris Foam 691959 Key Set 695951 Key Set (Touch N Mow) 398067 Arrestor-Spark 691346 Fan-Flywheel 696255 Screw (Starter Motor) 494256 Kit-Label ----- Note ----- 790231 Kit-Label (Touch N Mow) Label-Emissions (Available From A Briggs & Statton Authorized Dealer) 277039 Operator's Manual ----- Note ----- 277101 Operator's Manual (Touch N Mow) 692311 Kit-Screw/Washer ----- Note ----- 696293 Kit-Screw/ Washer (Touch N Mow) 498528 Gasket Set-Valve 691266 Pilot-Guide Used on Type No(s). 1167, 1715, 2367, 2673. ----- Note ----- 691255 Pilot-Guide Used on Type No(s). 1955, 1961, 2681, 3183. 691648 Screw (Alternator) 690345 Screw (Interlock Switch) 498144 Pulley/Spring Assembly (Pulley) 498144 Pulley/Spring Assembly (Spring) 695959 Starter-Mechanical (Touch N Mow) (Do Not Service Individual Parts, Only As A Whole) ----- Note ----- 699914 Starter-Mechanical (Touch N Mow) (Do Not Service Individual Parts, Only As A Whole) Used on Type No(s). 2001. 794467 Label-Warning 270962 Manual-Repair 790848 Vane-Air (Autochoke System) 790849 Spring-Air Vane 790850 Screw (Air Vane) (Autochoke System) 930 930A 935 937 940 946 957 1119 1160 1210 1211 1236 975 976 977 986 990 990A 994 1005 1009 1019 957A 957B 958 966A 966B 967A 968B 969 969A 970 1036 1058 1319 1330 1386 1387 1388 1059 K Included in Engine Gasket Set-Ref. No.358. D Included in Carburetor Overhaul Kit-Ref. No. 121.

Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No 1095.

z Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 0990-19 Assemblies include all parts shown in frames. 19 07/01/2008 .



You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12H800 TO 12H899 user guide
<http://yourpdfguides.com/dref/3639766>