



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 12K702. You'll find the answers to all your questions on the BRIGGS & STRATTON 12K702 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BRIGGS & STRATTON 12K702**  
**User guide BRIGGS & STRATTON 12K702**  
**Operating instructions BRIGGS & STRATTON 12K702**  
**Instructions for use BRIGGS & STRATTON 12K702**  
**Instruction manual BRIGGS & STRATTON 12K702**

FORM MS-500-897  
FILE IN SECTION 3 OF SERVICE MANUAL

**12K700 to 12K799**


**Illustrated Parts List**  
**Model Series**  
**12K700 to 12K799**

TYPE NUMBERS  
0109

**TO FIND  
THE CORRECT NUMBER OF THE PART YOU NEED:  
FOLLOW THE INSTRUCTIONS BELOW**

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the Illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."**
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION

All rights reserved. No part of this material may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12K702 user guide](http://yourpdfguides.com/dref/3640329)  
<http://yourpdfguides.com/dref/3640329>

**Manual abstract:**

2 OF SERVICE MANUAL 12K700 to 12K799 Illustrated Parts List Model Series 12K700 to 12K799 TYPE NUMBERS 0109. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. @@@@The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. @@@@For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.

S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. B.

C. D. E. F. 12K700 to 12K799 615 230 616 592 584 307 227 562 284 1 2 3 116 523 847 585 54 625 869 51 7 383 5 306 635 337 13 1019 LABEL KIT REF. NO. PART NO. DESCRIPTION Cylinder Assembly Bushing SealOil HeadCylinder GasketCylinder Head Breather Assembly GasketBreather ScrewHex. TubeBreather ScrewHex. GasketIntake ScrewHex. SealORing SealORing LeverGovernor REF. NO. 230 284 306 307 337 383 523 525 562 584 585 592 615 616 525 8 871 9 870 307 1058 OWNER'S MANUAL PART NO. 67072 94511 224324 94515 802592 89838 495264 495265 92613 224328 K272238 231082 94474 263175 DESCRIPTION WasherFlat ScrewShoulder ShieldCylinder ScrewHex. PlugSpark WrenchSpark Plug Dipstick TubeOil Fill BoltGovernor Lever GasketBreather Passage GasketBreather Passage NutHex.

Retainer CrankGovernor REF. NO. @@@SEE REPAIR INSTRUCTION MANUAL. PART NO. @@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No. @@@2 87 12K700 to 12K799 25 26 28 27 29 32 REF.

NO. 25 PART NO. DESCRIPTION REF. NO. 26 PART NO.

DESCRIPTION REF. NO. @@@(.010" O.S.

) 493386 Piston Assy. (.020" O.S.) 493387 Piston Assy. @@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No.

498528. 59063 Assemblies include all parts shown in frames. 3 87 12K700 to 12K799 24 16 35 34 40 35 33 357 40 45 45 741 146 REF. NO. 16 24 33 34 PART NO. 493363 222698 262651 262652 DESCRIPTION Crankshaft KeyFlywheel ValveExhaust ValveIntake REF. NO. 35 40 45 PART NO.

DESCRIPTION REF. NO.

@@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No.

@@@@NO. 4 12 15 20 PART NO. @@@NO. 22 PART NO. DESCRIPTION REF.

NO. 43 46 PART NO. DESCRIPTION 94220 ScrewHex. @@@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No. @@@@NO. PART NO.

DESCRIPTION REF. NO. 124 125 127 130 131 133 134 PART NO. DESCRIPTION REF. @@@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No. @@@@NO.

188 202 209 258 265 267 PART NO. DESCRIPTION REF. NO. 268 PART NO. DESCRIPTION REF.

NO. 333 334 356 620 621 670 843 851 923 PART NO. @@@@213146 ClampCasing 94882 ScrewSlotted Hex. 269 270 271 66986 CasingWire (48" Long) (Cut to Required Length) 26099 WireControl (54" Long) (Cut to Required Length) 63426 LocknutCasing 290568 LeverControl ArmatureMagneto ScrewHex. WireStop BracketControl SwitchStop Spacer (Includes 2) 272616 SleeveLever 493880 TerminalCable 493442 Brake K Included in Gasket SetPart Number 497316.

D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No. 498528. 59067 Assemblies include all parts shown in frames. 7 87 12K700 to 12K799 972 930 187 601 957 240 670A 284 188A REF. NO. 187 188A 240 284 PART NO.

298049 398540 298090 94511 DESCRIPTION LineFuel ScrewShoulder FilterFuel ScrewShoulder REF. NO. 601 PART NO. DESCRIPTION REF. NO. 670A 930 957 972 PART NO. @@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261.

Included in Valve Overhaul Gasket SetPart No. @@@@NO. PART NO. REF. NO.

613 676 832 967 968 969 971 PART NO. 94231 393756 499034 491588 281340 94120 94121 REF. NO. @@@ScrewHex. PART NO.

@@@346A 94602 ScrewHex. 529 281299 Grommet ScrewHex. BracketAir Cleaner PrimerCarburetor FilterAir (PreFilter) 398067 ArresterSpark K Included in Gasket SetPart Number 497316. D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No. 498528. 59069 Assemblies include all parts shown in frames.

9 87 12K700 to 12K799 332 305 37 363 304 455 305 23 73 REF. NO. 23 37 73 PART NO. DESCRIPTION REF. NO. 304 305 332 PART NO. DESCRIPTION REF. NO. 363 455 PART NO. DESCRIPTION 492177 Flywheel 224511 GuardFlywheel 225125 ScreenRotating 493293 HousingBlower 94744 ScrewHex.

@@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No.

@@@10 87 12K700 to 12K799 608 65A 55 58 373 459 57 60 369 56 456 461 REF. NO. 55 56 57 PART NO. DESCRIPTION REF. NO.

58 PART NO. DESCRIPTION REF. NO. 373 456 459 461 608 PART NO. 94980 281503 281505 94943 497680 DESCRIPTION NutHex. @@@@D Included in Carburetor KitPart No. 498260. z Included in Carburetor Gasket SetPart No. 498261. Included in Valve Overhaul Gasket SetPart No.

@@@11 87 12K700 to 12K799 358 GASKET SET 12 9 163 7 585 3 670 116 116A 977 CARBURETOR GASKET SET 163 137 617 110 634 PART NO. D 20 51 121 CARBURETOR KIT 1095 VALVE OVERHAUL GASKET SET 7 9 134 127 110 634 104 163 617 137 REF. NO. PART NO. DESCRIPTION REF. NO. 121 127 DESCRIPTION REF. NO. PART NO. DESCRIPTION 3 K299819 7 K272916 9 K272481 12 K272198 20 K399781 51 K272199 104 D231371 110 Dz 116 116A SealOil GasketCylinder Head GasketBreather GasketCrankcase SealOil GasketIntake PinFloat Hinge WasherBowl (Sold in Kit Only) K280393 SealORing K280966 SealORing 498260 Carburetor Kit PlugWelch (Sold in Kit Only) 134 D398188 ValveNeedle 137 Dz Gasket&



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12K702 user guide](http://yourpdfguides.com/dref/3640329)  
<http://yourpdfguides.com/dref/3640329>