



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 12T802. You'll find the answers to all your questions on the BRIGGS & STRATTON 12T802 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 12T802
User guide BRIGGS & STRATTON 12T802
Operating instructions BRIGGS & STRATTON 12T802
Instructions for use BRIGGS & STRATTON 12T802
Instruction manual BRIGGS & STRATTON 12T802

FORM MS-0915-499
REPLACES FORM MS-0915-299
FILE IN SEC 7 OF SERVICE MANUAL
12T800 to 12T899

Illustrated Parts List

Model Series

12T800 to 12T899

TYPE NUMBERS

0840, 0842, 0818,

0819, 0820, 0833,

0839,

0854 through 0866,

0873, 0879,

0880 through 0888,

0894, 0896,

1123 through 1136,

1162 through 1176,

1522,

1566 through 1571,

1580, 1581, 1582,

1584.

TO FIND

THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- Refer to the Illustrations and compare the original part with Illustration. The number next to the Illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12T802 user guide](http://yourpdfguides.com/dref/3639989)
<http://yourpdfguides.com/dref/3639989>

Manual abstract:

2 OF SERVICE MANUAL 12T800 to 12T899 Illustrated Parts List Model Series 12T800 to 12T899 TYPE NUMBERS 0640, 0642, 0818, 0819, 0820, 0833, 0839, 0854 through 0866, 0873, 0879, 0880 through 0888, 0894, 0896, 1128 through 1136, 1162 through 1176, 1522, 1566 through 1571, 1580, 1581, 1582, 1584. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames.

All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. @@@@COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved.

@@NO. 1 2 PART NO. DESCRIPTION REF. NO. 177 227 287 306 307 337 383 404 505 227 562 1 505 2 3 177 287 847 523 51 383 5 306 337 870 871 635 1058 OWNER'S MANUAL PART NO.

DESCRIPTION REF. NO. 585 615 616 635 684 REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. PART NO. DESCRIPTION 493260 Cylinder Assembly 399269 Bushing/Seal Kit (Magneto Side) 3 K299819 Oil Seal (Magneto Side) 5 691160 Cylinder Head (Used After Code Date 98062100). Note 214626 Cylinder Head (Used Before Code Date 98062200). 7 K272916 Cylinder Head Gasket 8 495786 Breather Assembly 9 K272481 Breather Gasket 10 691125 Screw (Breather Assembly) 11 231933 Breather Tube 13 94547 Screw (Cylinder Head) 50 497465 Intake Manifold 51 K272199 Intake Gasket 54 94526 Screw (Intake Manifold) 523 525 562 584 K280393 O-Ring Seal (Dipstick) 690783 Governor Control Lever 94511 Screw (Dipstick Tube) 690450 Cylinder Shield 690345 Screw (Cylinder Shield) 802592 Spark Plug 89838 Spark Plug Wrench 690272 Washer (Governor Crank) 231082 Nut (Governor Control Lever) 495264 Dipstick 495265 Dipstick Tube 691119 Bolt (Governor Control Lever) 692342 Breather Passage Cover 847 869 870 871 1019 1058 1081 K272238 Breather Passage Gasket 690340 Governor Shaft Retainer 691306 Governor Crank 66538 Spark Plug Boot 690345 Screw (Breather Passage Cover) 495263 Dipstick/Tube Assembly 691125 Valve Seat (Intake) 690380 Valve Seat (Exhaust) 262001 Guide Bushing (Exhaust) Note 63709 Guide Bushing (Intake) 494256 Label Kit 272262 Owner's Manual K280966 O-Ring Seal (Dipstick Tube) K Included in Engine Gasket SetRef. No. 358.

D Included in Carburetor Overhaul KitRef. No. 121. z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef. No. 1095. 05182 Assemblies include all parts shown in frames.

2 69 12T800 to 12T899 25 27 29 32 28 26 27 REF. NO. 25 PART NO. DESCRIPTION REF. NO.

26 PART NO. DESCRIPTION REF. NO. 27 PART NO. DESCRIPTION REF. NO. 499429 Piston Assembly (Standard) (Used After Code Date 97011200). Note 493262 Piston Assembly (Standard) (Used Before Code Date 97011300). 499430 Piston Assembly (.010 O.S.) (Used After Code Date 97011200). 493385 Piston Assembly (.010 O.S.) (Used Before Code Date 97011300). 499431 Piston Assembly (.

.020 O.S.) (Used After Code Date 97011200). 493386 Piston Assembly (.020 O.S.) (Used Before Code Date 97011300). 499432 Piston Assembly (.030 O.S.) (Used After Code Date 97011200). 493387 Piston Assembly (.030 O.S.) (Used Before Code Date 97011300). 499425 Ring Set (Standard) (Used After Code Date 97011200). Note 493261 Ring Set (Standard) (Used Before Code Date 97011300). 499426 Ring Set (.010 O.S.) (Used After Code Date 97011200). 493388 Ring Set (.010 O.S.) (Used Before Code Date 97011300). 499427 Ring Set (.020 O.S.) (Used After Code Date 97011200). 493389 Ring Set (.

.020 O.S.) (Used Before Code Date 97011300). 499428 Ring Set (.030 O.S.) (Used After Code Date 97011200). 493390 Ring Set (.030 O.S.) (Used Before Code Date 97011300). 28 29 32 263190 Piston Pin Lock (Used After Code Date 97011200). Note 26026 Piston Pin Lock (Used Before Code Date 97011300). 499423 Piston Pin (Standard) (Used After Code Date 97011200). Note 298909 Piston Pin (Standard) (Used Before Code Date 97011300). 298908 Piston Pin (.005 O.S.) (Used Before Code Date 97011300). 499424 Connecting Rod (Standard) (Used After Code Date 97011200). Note 490566 Connecting Rod (Standard) (Used Before Code Date 97011300). @@@@No. 358. D Included in Carburetor Overhaul KitRef. No. 121. z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef.

No. 1095. 05183 Assemblies include all parts shown in frames. @@@@No. 16 PART NO. DESCRIPTION REF. @@@@Used on Type No(s). @@@@692980 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0640, 0642.

493946 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0854, 0864, 0879, 0880, 0894, 1135, 1164, 1522. REF. NO. 24 33 34 35 36 40 45 146 741 PART NO. @@@@691450 Crankshaft (Used After Code Date 97011200). Used on Type No(s). 0858, 0884, 1132, 1133, 1134. 493282 Crankshaft (Used Before Code Date 97011300). Used on Type No(s). 0858, 0884, 1132, 1133, 1134. 691452 Crankshaft (Used After Code Date 97011200). Used on Type No(s). K Included in Engine Gasket SetRef. No. 358. D Included in Carburetor Overhaul KitRef. No. 121.

z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef. No. 1095. 05184 Assemblies include all parts shown in frames. @@@@NO. 4 4A 12 15 15A 20 20A 22 PART NO. 493279 493365 K272198 94880 691093 K399781 DESCRIPTION REF.

NO. 46 PART NO. DESCRIPTION REF. NO. 83 PART NO.

@@@@691459 Camshaft (Used After Code Date 96060200). @@@@0854, 0886, 1133. @@@@No. 358. D Included in Carburetor Overhaul KitRef. No. 121. z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef. No. 1095. 05185 Assemblies include all parts shown in frames. @@@@NO.

95 97 104 117 PART NO. REF. NO. 125 PART NO. REF. NO. @@@@497315 Main Jet (Standard) (Used Before Code Date 95103000).

[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12T802 user guide](#)



<http://yourpdfguides.com/dref/3639989>

497315 Main Jet (High Altitude) (Used After Code Date 96060200). 496495 Main Jet (High Altitude) (Used Before Code Date 96060300). @@@@497314 Carburetor (Primer System) (Used Before Code Date 95103000).

127 D223749 130 691203 133 398187 134 D398188 137 Dz280492 163KDz272653 276 Dz271716 365 94840 Welch Plug Throttle Valve Carburetor Float Needle/Seat Kit Float Bowl Gasket Air Cleaner Gasket Sealing Washer Screw (Carburetor) 617 Dz270344 ORing Seal (Intake Manifold) 708 Dz691321 Dust Seal (Throttle Shaft) 975 493640 Float Bowl K Included in Engine Gasket SetRef. No. 358. D Included in Carburetor Overhaul KitRef. No. 121. z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef.

No. 1095. 05186 Assemblies include all parts shown in frames. 6 69 12T800 to 12T899 125A 109 618 365 708 133 708 104 97 134 108 163 975 137 127 98 130A 95 617 CHOKE SYSTEM REF. NO. 94 95 97 98 104 108 109 117A PART NO. REF. NO. 125A PART NO. REF.

NO. 365 617 618 708 PART NO. 276 117A 276 94 DESCRIPTION DESCRIPTION DESCRIPTION D493765 Idle Mixture Kit 94098 Screw (Throttle Valve) 493267 Throttle Shaft 398185 Idle Speed Kit D691242 Float Hinge Pin 691182 Choke Valve 494218 Choke Shaft 498977 Main Jet (Standard) (Used After Code Date 96060200). Note 493637 Main Jet (Standard) (Used Before Code Date 96060300). 498981 Main Jet (High Altitude) (Used After Code Date 96060200). 496063 Main Jet (High Altitude) (Used Before Code Date 96060300). 498965 Carburetor (Choke System) (Used After Code Date 96060200). Note 494217 Carburetor (Used Before Code Date 96060300). 127 D223749 Welch Plug 130A 691181 Throttle Valve 133 398187 Carburetor Float 134 D398188 Needle/Seat Kit 137 Dz280492 Float Bowl Gasket 163KDz272653 Air Cleaner Gasket 276 Dz271716 Sealing Washer 975 94840 Screw (Carburetor) Dz270344 ORing Seal (Intake Manifold) 262749 Choke Return Spring Dz691321 Dust Seal (Throttle Shaft) Note 691321 Dust Seal (Choke Shaft) Air Cleaner Primer Bracket 163KDz272653 Air Cleaner Gasket 300 496106 Exhaust Muffler 346 94896 Screw (Spark Arrester) 423 94873 Screw (Air Cleaner Primer Base) 425 94872 Screw (Air Cleaner Cover) 445 491588 Air Cleaner Cartridge Filter 281299 Grommet 94231 Screw (Exhaust Muffler) 493871 Muffler Deflector 94896 Screw (Muffler Deflector) 494224 Muffler Guard 94874 Screw (Muffler Guard) 496116 Air Cleaner Primer Base 281340 Air Cleaner Cover 976 994 94749 Screw (Air Cleaner Primer Bracket) 694395 Carburetor Primer (Used After Code Date 99103100). Note 496115 Carburetor Primer (Used Before Code Date 99110100).

398067 Spark Arrester K Included in Engine Gasket SetRef. No. 358. D Included in Carburetor Overhaul KitRef. No.

121. z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef.

No. 1095. 051811 Assemblies include all parts shown in frames. 11 69 12T800 to 12T899 604 930 332 564 455 78 363 37 23 304 305 925 23A REF. NO. 23 PART NO. DESCRIPTION REF. NO. 304 PART NO. DESCRIPTION REF.

NO. 332 363 455 564 604 925 930 PART NO. DESCRIPTION 23A 37 78 492177 Flywheel Note 492893 Flywheel Used on Type No(s). 0839. 492175 Flywheel 224511 Flywheel Guard 691108 Screw (Flywheel Guard) 305 493294 Blower Housing (Used on Compliance Engines) Note 493293 Blower Housing (Used on Non Compliance Engines) 691108 Screw (Blower Housing) 94877 Nut (Flywheel) 19069 Flywheel Puller 691219 Flywheel Cup 93801 Screw (Control Cover) 225103 Control Cover 690595 Linkage Cover 281136 Rewind Guard K Included in Engine Gasket SetRef. No. 358. D Included in Carburetor Overhaul KitRef. No. 121.

z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef. No.

1095. 051812 Assemblies include all parts shown in frames. @ @NO. 55 56 57 PART NO. DESCRIPTION REF.

NO. 58 PART NO. DESCRIPTION REF. NO. @ @No. 358. D Included in Carburetor Overhaul KitRef. No. 121. z Included in Carburetor Gasket SetRef.

No. 977. Included in Valve Overhaul Gasket SetRef. No. 1095. 051813 Assemblies include all parts shown in frames. @ @NO. 55A 57 58A PART NO. REF. NO.

65 101 144 276A 455 455A 456A PART NO. REF. NO. 459A 592 608A 678 689A 946 1134 PART NO. 946 58A DESCRIPTION DESCRIPTION DESCRIPTION 59 60A 492831 Rewind Starter Housing 491889 Rewind Starter Spring 280399 Starter Rope (Cut To Required Length) 396892 Grip Insert 393152 Starter Rope Grip 94904 Screw (Rewind Starter) 262626 Shaft Pin 493824 Pulley/Spring Assembly 280973 Sealing Washer 691219 Flywheel Cup 224250 Flywheel Cup 224321 Pawl Friction Plate 492833 Ratchet Pawl 94908 Nut (Rewind Starter) 497598 Rewind Starter 224278 Rewind Spacer 262625 Friction Spring 223294 Rope Stop 224322 Washer (Pawl Friction Plate) K Included in Engine Gasket SetRef.

No. 358. D Included in Carburetor Overhaul KitRef. No. 121.

z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef. No. 1095. 051814 Assemblies include all parts shown in frames. 14 69 12T800 to 12T899 309 510 742 937 544 651 784 545 783 785 783A 513 310 803 801 697 802 REF. NO. 309 310 510 513 544 545 PART NO.

DESCRIPTION REF. NO. 651 697 742 783 783A PART NO. DESCRIPTION REF. NO. 784 785 801 802 803 937 PART NO. 692341 692352 690782 690787 690785 691325 DESCRIPTION Gear Cover Starter Cover Gasket Drive Cap End Cap Starter Housing Starter Spline 692376 Starter Motor 692327 Screw (Starter Motor) 494147 Starter Drive 692358 Drive Clutch 690786 Starter Armature 492919 Washer Set (Starter Motor) 690345 Screw (Starter Gear Cover) 691127 Screw (Drive Cap) 93941 ERing Retainer 281127 Pinion Gear 691269 Pinion Gear K Included in Engine Gasket SetRef. No. 358. D Included in Carburetor Overhaul KitRef.

No. 121. z Included in Carburetor Gasket SetRef. No. 977.

Included in Valve Overhaul Gasket SetRef. No. 1095. 051815 Assemblies include all parts shown in frames. 15 69 12T800 to 12T899 358 ENGINE GASKET SET 177 3 1081 20 668 9 12 585 7 163 51 1095 VALVE OVERHAUL GASKET SET 977 CARBURETOR GASKET SET 163 121 CARBURETOR OVERHAUL KIT 94 134 104 127 276 163 7 9 617 137 708 708 276 PART NO.

137 REF. NO. 668 708 617 PART NO. REF. NO. 3 PART NO. DESCRIPTION REF. NO. DESCRIPTION Welch Plug Needle/Seat Kit Float Bowl Gasket Air Cleaner Gasket O-Ring Seal (Dipstick) Sealing Washer Engine Gasket Set Breather Passage Gasket ORing Seal (Intake Manifold) DESCRIPTION K299819 Oil Seal (Magneto Side) 7 K272916 Cylinder Head Gasket 9 K272481 Breather Gasket 12 K272198 Crankcase Gasket 20 K399781 Oil Seal (PTO Side) 51 K272199 Intake Gasket 94 D493765 Idle Mixture Kit 104 D691242 Float Hinge Pin 121 498260 Carburetor Overhaul Kit 127 D223749 134 D398188 137 Dz280492 163KDz272653 177 K280393 276 Dz271716 358 497316 585 K272238 617 Dz270344 977 1081 1095 K493823 Spacer (Includes 2) Dz691321 Dust Seal (Throttle Shaft) Note Dz691321 Dust Seal (Choke Shaft) 498261 Carburetor Gasket Set K280966 O-Ring Seal (Dipstick Tube) 498528 Valve Overhaul Gasket Set K Included in Engine Gasket SetRef.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12T802 user guide](http://yourpdfguides.com/dref/3639989)
<http://yourpdfguides.com/dref/3639989>

No.

358. D Included in Carburetor Overhaul KitRef. No. 121. z Included in Carburetor Gasket SetRef. No. 977. Included in Valve Overhaul Gasket SetRef. No. 1095.

051816 Assemblies include all parts shown in frames. 16 69 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 12T802 user guide](http://yourpdfguides.com/dref/3639989)
<http://yourpdfguides.com/dref/3639989>