



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 194412. You'll find the answers to all your questions on the BRIGGS & STRATTON 194412 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 194412
User guide BRIGGS & STRATTON 194412
Operating instructions BRIGGS & STRATTON 194412
Instructions for use BRIGGS & STRATTON 194412
Instruction manual BRIGGS & STRATTON 194412

FORM MS-2833-1097
REPLACES FORM MS-2833-567
FILE IN SECT. TOP SERVICE MANUAL
194400 to 194499

Illustrated Parts List Model Series 194400 to 194499

TYPE NUMBERS
1110, 1112, 1114,
1120, 1121,
1123 through 1131,
1150, 1151.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- Refer to the illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- After the Reference Number has been identified, refer to the Numerical List, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 194412 user guide](http://yourpdfguides.com/dref/3640287)
<http://yourpdfguides.com/dref/3640287>

Manual abstract:

2 OF SERVICE MANUAL 194400 to 194499 Illustrated Parts List Model Series 194400 to 194499 TYPE NUMBERS 1110, 1112, 1114, 1120, 1121, 1123 through 1131, 1150, 1151. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. @@@@The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed.

THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. @@@@COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. @SEE REPAIR INSTRUCTION MANUAL. REF.

NO. 1 PART NO. DESCRIPTION REF. NO. 15 308 13 14 5 635 337 11 10 1019 LABEL KIT PART NO.

DESCRIPTION 1058 OWNER'S MANUAL REF. NO. 635 869 870 871 PART NO. DESCRIPTION 495656 Cylinder Assembly (Includes OIL GARDR Cover) 2 495657 Bushing 3 K391086 SealOil 5 214015 HeadCylinder 6 22963 Washer 7 K272163 GasketCylinder Head 8 495724 Breather Assembly 9 K27803 GasketBreather 10 94719 ScrewHex. 11 280267 TubeBreather 13 94565 ScrewHex. 13A 94733 StudHex Drive 14 94622 ScrewHex. (3" Long) 306 307 308 337 347 347A 354 383 552 94239 PlugOil Drain Note 92738 PlugOil Drain (Magnetic) 496797 ShieldCylinder 94930 ScrewHex. @89838 WrenchSpark Plug 491986 BushingGov. @299577. D Included in Carburetor KitPart No.

398235. Included in Valve Overhaul Gasket SetPart No. @@@@NO. 16 PART NO. DESCRIPTION REF. NO. 27 PART NO. DESCRIPTION REF. NO. 34 35 PART NO.

@1112, 1114, 1120, 1121, 1129, 1130, 1150, 1151. 496974 Crankshaft Used on Type No(s). 1131. @(.010" O.S. S. 499275 Piston Assy. (.020" O.S.

) 499276 Piston Assy. (.030" O.S.) 393881 Ring Set (Standard) Note 299743 Ring Set (Chrome Standard) 393882 Ring Set (.010" O.S.) 393883 Ring Set (.020" O.S.

) 393884 Ring Set (.030" O.S.) 28 29 30 31 32 33 33A 263181 LockPiston Pin Note 68546 LockPiston Pin (Used Before Code Date 96102800). 499302 Pin-Piston (Standard) Note 499303 PinPiston (.005" O.S.) 295840 PinPiston (Standard) 295841 PinPiston (.005" O.S.

) (Used Before Code Date 96102800). 390401 RodConnecting (Standard) Note 390773 RodConn. (.020" Undersize) 222113 DipperConn. Rod 222114 Lock-Rod Screw 92659 ScrewConn.

Rod 263017 ValveExhaust (Used After Code Date 95041600). 390420 ValveExhaust (Used Before Code Date 95041700). 36 40 41 42 45 146 741 261055 ValveIntake 65906 SpringValve (Intake and Exhaust) (Used After Code Date 95041600). 26828 SpringValve (Exhaust Only) (Used Before Code Date 95041700). 221596 RetainerValve (Intake) 292260 RetainerValve (Exhaust) (Used Before Code Date 95041700).

494553 KeeperValve (Used Before Code Date 95041700). 260933 TappetValve 94388 KeyTiming 263025 GearTiming Note 262479 GearTiming (Used Before Code Date 95022000) K Included in Gasket SetPart No. 299577. D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. @@@@NO. 12 PART NO. DESCRIPTION REF. NO.

15A 15B 18 19 20 PART NO. @@NO. 21 22 46 219 220 PART NO. @@@@299577. D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. @@@@NO. 90 91 93 94 95 96 97 98 99 100 PART NO. @@NO.

101 102 103 104 105 107 108 109 PART NO. 93043 D27918 99333 D230896 D394681 399442 DESCRIPTION REF. NO. 110 111 112 113 114 118 119 843 PART NO. @@SleeveLever PinThrottle Lever GasketCarb.

@299577. D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. @@@@NO.

222 227 230 232 307A 333 334 353 354A 356 356A 474 PART NO. @@NO. 482 507 520 562 592 614 615 616 616A 851 877 878 PART NO. @@NO. PART NO. DESCRIPTION DESCRIPTION BracketControl LeverGovernor Washer SpringLink ScrewHex. ArmatureMagneto ScrewHex. WasherLock NutHex. Wire-Stop WireStop Alternator DESCRIPTION ScrewHex. Insulator Terminal BoltCarriage NutHex.

PinCotter Retainer CrankGovernor CrankGovernor TerminalCable WireAlternator HarnessAlternator 50 212488 ManifoldIntake 51 KD270684 Gasket-Intake 51A K27828 GasketIntake 53 93956 ScrewShoulder 53A 94616 ScrewTorxr Hex. 54 93208 ScrewPhillips 188 94627 ScrewHex. 206 231266 Nut 207 26855 SpringControl Rod 208 261959 RodGovernor Control 209 260695 SpringGovernor 212 260872 LinkThrottle K Included in Gasket SetPart No.

299577. D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. @@@@NO. 188 346 353 354A 729 PART NO. 94627 93705 92791 90576 223528 DESCRIPTION ScrewHex.

ScrewHex. WasherLock NutHex. ClipWire REF. NO. 948 978 979 980 PART NO.

@@NO. 982 982A 983 984 PART NO. 94657 94139 398660 223773 DESCRIPTION ScrewHex. ScrewHex. @299577.

D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. @@@@NO. 116 180 181 182 182A 183 184 185 PART NO. REF. NO. 186 186A 187 PART NO. REF. NO.

240 601 917 957 958 960 961 972 PART NO. 298090 93053 223271 493988 399517 492990 198 182 188 DESCRIPTION DESCRIPTION DESCRIPTION 280203 SealO-Ring 290816 TankFuel (4 Quart) 392305 CapFuel Tank 222758 BracketFuel Tank 495664 BracketFuel Tank (Upper) 291367 StrapFuel Tank 91257 ScrewSlotted 90970 Nut 188 198 199 210 67218 ConnectorHose 230318 ConnectorHose 296004 LineFuel (Cut to Required Length) 94627 ScrewHex. 293934 ScrewShut Off 297563 ValveShut Off 492044 StrainerFuel FilterFuel ClampHose HandleShut Off Valve CapFuel Tank ValveShut-Off BracketFuel Tank (Lower) 94095 ScrewHex. 493337 TankFuel K Included in Gasket SetPart No.



[You're reading an excerpt. Click here to read official BRIGGS &](http://yourpdfguides.com/dref/3640287)

[STRATTON 194412 user guide](http://yourpdfguides.com/dref/3640287)

<http://yourpdfguides.com/dref/3640287>

299577. D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. 498533. 28328 Assemblies include all parts shown in frames.

8 107 194400 to 194499 165 467 536 642 161 643 445 445 535 167 850 300 302 346 346 536A 642A 81 643 676 994 300A 883 613 862 535 REF. NO. 81 161 PART NO. DESCRIPTION REF. NO.

302 346 445 467 535 536 536A 613 PART NO. 261409 93705 393957 493903 271794 391063 399810 94042 DESCRIPTION LocknutMuffler ScrewHex. @@@@299577. D Included in Carburetor KitPart No. 398235.

Include09, Previous Page. 94003 Bolt. @299577. D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. @13 107 194400 to 194499 121 CARBURETOR OVERHAUL KIT 118 3 102 105 113 114 1095 VALVE OVERHAUL GASKET SET 883 51A 7 9 7 9 51A 12 94 104 883 978 20 358 GASKET SET 51 51 REF. NO. PART NO. DESCRIPTION SealOil GasketCylinder Head GasketBreather GasketCrankcase (.015" Thick) Note K27876 Gasket Crankcase (.005" Thick) K27877 Gasket Crankcase (.009" Thick) REF. NO. PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION Gasket Set GasketExhaust Gasket Gasket SetValve Overhaul 3 K391086 7 K272163 9 K27803 12 K271701 20 K391086 SealOil 51 KD270684 GasketIntake 51A K27828 GasketIntake 94 D292681 ValveIdle Adjustment 102 D27918 GasketCarburetor Body 104 D230896 PinFloat Hinge 105 D394681 ValveNeedle 113 D398202 NozzleCarburetor 114 D68667 GasketNozzle 118 D99525 ValveHigh Speed 121 398235 Carburetor Kit 358 299577 883 K272309 978 K271736 1095 498533 K Included in Gasket SetPart No. 299577.

D Included in Carburetor KitPart No. 398235. Included in Valve Overhaul Gasket SetPart No. 498533. 283214 Assemblies include all parts shown in frames. 14 107 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 194412 user guide](http://yourpdfguides.com/dref/3640287)
<http://yourpdfguides.com/dref/3640287>