



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 21B700 TO 21B799. You'll find the answers to all your questions on the BRIGGS & STRATTON 21B700 TO 21B799 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 21B700 TO 21B799
User guide BRIGGS & STRATTON 21B700 TO 21B799
Operating instructions BRIGGS & STRATTON 21B700 TO 21B799
Instructions for use BRIGGS & STRATTON 21B700 TO 21B799
Instruction manual BRIGGS & STRATTON 21B700 TO 21B799



FORM MS-3675-02/29/2008
REPLACES FORM MS-3675-11/05/2007
FILE IN SECT. 2 OF SERVICE MANUAL
21B700

Illustrated Parts List Model Series 21B700

TYPE NUMBERS
0453, 0505.

TABLE OF CONTENTS

Air Cleaner	6
Alternator	9
Blower Housing	6
Camshaft	3
Carburetor	5
Controls	8
Crankshaft	3
Cylinder	2
Cylinder Head	4
Electric Starter	7
Engine Sump	2
Flywheel	7
Fuel System	8
Gasket Set - Carburetor	5
Gasket Set - Engine	4
Gasket Set - Valve	4
Ignition	8
Kit - Carburetor Overhaul	5
Lubrication	3
Operator's Manual	2
Piston, Rings, Connecting Rod	3
Valves	4
Warning Label	2



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 21B700 TO 21B799 user guide](http://yourpdfguides.com/dref/3640118)
<http://yourpdfguides.com/dref/3640118>

Manual abstract:

2 OF SERVICE MANUAL 21B700 Illustrated Parts List Model Series 21B700 TYPE NUMBERS 0453, 0505. TABLE OF CONTENTS Air Cleaner

.
.
. 6 Alternator

.
.
.
. 9 Blower Housing

.
. 6 Camshaft
.
.

.
. 3 Carburetor
.
.

. 5 Controls
.
.
.

. 8 Crankshaft
.
.
. 3 Cylinder

.
.
.
. 2 Cylinder Head

.
.
. 4 Electric Starter
.

.
. 7 Engine Sump
.
.

. 2 Flywheel
.
.
.

. 7 Fuel System
.
.
. 8 Gasket Set - Carburetor

. 5 Gasket Set - Engine
.
.

. 4 Gasket Set - Valve

.
. 4 Ignition
.
.

.....
.. 8 Kit-Carburetor Overhaul . . .

.....
..... 5 Lubrication

.....
.....
.....
3 Operator's Manual

..... 2 Piston, Rings, Connecting Rod . .

.....
3 Valves

.....
.....
4 Warning Label

..... 2 PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 21B700 1058 OPERATOR'S MANUAL 1319 WARNING LABEL REQUIRED when replacing parts with warning labels affixed. 11 10 584 9 1264 1263 850 1 2 3 4 12 552 691 718 22 306 20 15 307 Illustrations cover a range of engines. @@@@3 02/29/2008 21B700 45 1026 5 34 42 36 238 33 42 868 337 883 635 383 7 35 1022 1034 830 617 850 1022 914 1029 192 654 53 50 13 617 51 1023 54 358 ENGINE GASKET SET 3 12 7 1095 VALVE GASKET SET 868 7 1022 51 9 20 51 524 617 691 842 868 883 1266A 1266 1022 Illustrations cover a range of engines.

Parts shown without corresponding text may not be used on your specific engine. 3675-4 Assemblies include all parts shown in frames. 4 02/29/2008 21B700 125A 131A 130A 95A 987A 108A 634A 98A 141A 117 118 51 94A 105A 133A 104A 127A 109I 276A 947 975A 137A 135 137A 1127 NIKKI 121A CARBURETOR OVERHAUL KIT 137A 51 105A 95A 127A 104A 276A 987A 1266 1266A 617 634A 977A CARBURETOR GASKET SET 137A 51 276A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3675-5 Assemblies include all parts shown in frames.

5 02/29/2008 21B700 1040 1036 EMISSIONS LABEL 304 305A 305 643 967 445 1267 968 431 1266A 1266 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3675-6 Assemblies include all parts shown in frames. 6 02/29/2008 21B700 74 73 1005A 1070 415A 1005B 73A 1070A 1005 309 801 1051 510 783 513 803 1090 579 797 802 311 783 310 363 23 1051 544 1044 37 729A 697 78 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3675-7 Assemblies include all parts shown in frames. 7 02/29/2008 21B700 187 601 240 789 334 333 616 404 227 614 505 851 562 222 216 188 209 265 268 267 269 271 270 202 232 Illustrations cover a range of engines. @@@@1119 mounting screw. @@@@9 02/29/2008 21B700 REF. NO.

1 2 PART NO. DESCRIPTION REF. NO. 26 PART NO. DESCRIPTION REF. NO. 74 PART NO. @@@@34 791935 Valve-Intake (Used After Code Date 06120300). @@@@ (Used Before Code Date 07040900). 73A 794437 Screen-Rotating (Used After Code Date 07040800). 697897 Screw (Rotating Screen) (Used Before Code Date 07040900). @@@@699475) 791405 Jet-Main (Nikki)(High Altitude)(Carburetor Part No. 793371) ----- Note ----- 699898 Jet-Main (Nikki)(High Altitude)(Carburetor Part No. 699475) 698787 Kit-Carburetor Overhaul (Nikki) 794294 Carburetor (Nikki)(Gravity Feed) D690727 Plug-Welch (Nikki) 698774 Valve-Throttle (Nikki) 698776 Kit-Throttle Shaft (Nikki) 694914 Float-Carburetor (Nikki) 78 94A 95A 98A 104A 105A 108A 117 118 121A 125A 127A 130A 131A 133A K Included in Engine Gasket Set-Ref. No. 358. D Included in Carburetor Overhaul Kit-Ref. No. 121A. z Included in Carburetor Gasket Set-Ref. No. 977A. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3675-10 Assemblies include all parts shown in frames. 10 02/29/2008 21B700 REF. NO. 135 137A 141A 146 187 PART NO.

DESCRIPTION REF. NO. 307 309 310 311 333 334 337 PART NO. DESCRIPTION REF. NO. 579 584 PART NO. DESCRIPTION 698780 Tube-Fuel Transfer (Nikki)(Gravity Feed) Dz698781 Gasket-Float Bowl (Nikki) 698778 Kit-Choke Shaft (Nikki) 691639 Key-Timing 791805 Line-Fuel (Formed)(10-1/4 Inches Long)(Cut To Required Length) 691693 Screw (Control Bracket) 691986 Adjuster-Rocker Arm 691841 Link-Mechanical Governor 792602 Spring-Governor 691840 Link-Choke 694042 Bracket-Control 691374 Lever-Governor Control 691842 Spring-Governor Link 691843 Cap-Valve 394358S Filter-Fuel (White, 75 Microns) 691024 Clamp-Casing 794904 Screw (Casing Clamp) 691025 Casing-Control Wire (Cut To Required Length) 691026 Wire-Control (Cut To Required Length) 691027 Nut (Control Wire Casing) 691028 Lever-Control Dz695410 Washer-Sealing 698473 Housing-Blower (Black) 697102 Screw (Blower Housing) 697103 Screw (Blower Housing) 697359 Shield-Cylinder 691003 Screw (Cylinder Shield) 693551 Motor-Starter 690323 Screw (Starter Motor) 497608 Brush Set 795315 Armature-Magneto 691061 Screw (Magneto Armature) 491055S Plug-Spark Used on Type No(s). 0453. ----- Note ----- 691043 Plug-Spark Used on Type No(s). 0505.

697151 Gasket Set-Engine 19203 Puller-Flywheel 89838S Wrench-Spark Plug 691691 Washer (Governor Crank) 794129 Plug (Cover/Retainer) (Used After Code Date 07040800). 697122 Elbow-Intake 698413 Filter-Air Cleaner Cartridge (Non Washable) 696459 Alternator (Dual Circuit) 691251 Nut (Governor Control Lever) 693699 Drive-Starter 692024 Clutch-Drive 699908 Dipstick K691032 Seal-Dipstick Tube 697184 Tube-Dipstick 692034 Armature-Starter 697144 Bushing-Governor Crank 691119 Bolt (Governor Control Lever) 691029 Nut (Starter Cable) 794682 Cover-Breather Passage (Used After Code Date 07071800). (Use With Liquid Sealant Reference 850) ----- Note ----- 697112 Cover- Breather Passage (Used Before Code Date 07071900). 791850 Clamp-Hose 691620 Pin-Cotter 692012 Crank-Governor KD692138 Seal-O Ring (Intake Manifold) D698779 Spring/Seal Assembly (Nikki) 691909 Boot-Spark Plug 697155 Retainer-Air Filter 690958 Nut (Carburetor) K692407 Seal-Governor Shaft 690372 Screw (Drive Cap) 690959 Pin-Locating 691224 Clip-Wire (Starter Motor) 697128 Gear-Timing 693713 Gear-Pinion 698329 Harness-Wiring 693167 Nut (Brush Retainer) 691283 Cap-Drive 691286 Cap-End Housing-Starter (Not Serviced Separately, Order Stater Motor 693551) 691095 Stud-Rocker Arm K691031 Seal-O Ring (Dipstick Tube) 188 192 202 209 216



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 21B700 TO 21B799 user guide](http://yourpdfguides.com/dref/3640118)
<http://yourpdfguides.com/dref/3640118>

No.

358. D Included in Carburetor Overhaul Kit-Ref. No. 121A. z Included in Carburetor Gasket Set-Ref.

No. 977A. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. @@11 02/29/2008 21B700 REF. NO. 847 850 PART NO.
DESCRIPTION REF. NO.

1005 PART NO. DESCRIPTION REF. NO. 1058 1059 1070 PART NO. @@@@1005A 794440 Fan-Flywheel (Used Before Code Date 07040900). 1005B
Fan-Flywheel (No Longer Available) (See Reference1005A For Service Flywheel Fan). 1022K272475S Gasket-Rocker Cover (Used Before Code Date
07091000). (After Date Code Use liquid Sealant Reference 850) 1023 791079 Cover-Rocker 1026 697395 Rod-Push (Exhaust) ----- Note ----- 697394 Rod-
Push (Intake) 1029 691751 Arm-Rocker 1034 690822 Guide-Push Rod 1036 Label-Emissions (Available From A Briggs & Stratton Authorized Dealer) 1040
698368 Plate-Trim 1044 698139 Screw (Flywheel) 1051 691265 Ring-Retaining 276344 Operator's Manual 698516 Kit-Screw/Washer 690372 Screw
(Flywheel Fan) (Used Before Code Date 07040900). 690363 Screw (Flywheel Fan) (Used After Code Date 07040800). 691293 Retainer-Brush 691333 Cap-
Limiter 691581 Gasket Set-Valve 691183 Screw (Alternator) 695407 Screw (Float Bowl) 697124 Reed-Breather 697104 Screw (Breather Reed) KD691917
Seal-O Ring (Intake Elbow) K.



[You're reading an excerpt. Click here to read official BRIGGS &
STRATTON 21B700 TO 21B799 user guide](http://yourpdfguides.com/dref/3640118)

<http://yourpdfguides.com/dref/3640118>