



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 21M300 TO 21M399. You'll find the answers to all your questions on the BRIGGS & STRATTON 21M300 TO 21M399 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 21M300 TO 21M399
User guide BRIGGS & STRATTON 21M300 TO 21M399
Operating instructions BRIGGS & STRATTON 21M300 TO 21M399
Instructions for use BRIGGS & STRATTON 21M300 TO 21M399
Instruction manual BRIGGS & STRATTON 21M300 TO 21M399



FORM MS-4275-06/102008
FILE IN SECT. 2 OF SERVICE MANUAL
21M300

Illustrated Parts List Model Series 21M300

TYPE NUMBER
0641

TABLE OF CONTENTS

Alternator	9
Blower Housing/Shrouds	6, 7
Camshaft	2
Carburetor	4
Controls	8
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	9
Exhaust System	5
Flywheel	7
Fuel Supply	9
Gasket Set - Engine	3
Gasket Set - Valve	3
Governor Spring	8
Ignition	9
Kit - Carburetor Overhaul	4
Lubrication	2
Operator's Manual	2
Piston/Rings/Connecting Rod	2
Rewind Starter	7
Valves	3
Warning Label	2



PRINTED IN U.S.A.
COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 21M300 TO 21M399 user guide](http://yourpdfguides.com/dref/3640276)
<http://yourpdfguides.com/dref/3640276>

Manual abstract:

@@.....
.....
.....
..... 9 Blower Housing/Shrouds

..... 6, 7 Camshaft ...
.....
.....

..... 2 Carburetor

..... 4 Controls

..... 8 Crankcase Cover ...
.....
.....
..... 2 Crankshaft ..
.....

.....
..... 2 Cylinder ..
.....
.....

..... 2 Cylinder Head

..... 3 Electric Starter

..... 9 Exhaust System

.....
.....
..... 5 Flywheel

.....
..... 7 Fuel Supply ...
.....
.....

..... 9 Gasket Set - Engine ...
.....
.....

..... 3 Gasket Set - Valve

.....
..... 3 Governor Spring ...
.....
.....

..... 8 Ignition

.....
.....
.....

. 9 Kit - Carburetor Overhaul
... 4 Lubrication
.....

..... 2 Operator's Manual
.....
..... 2 Piston/Rings/Connecting Rod

.... 2 Rewind Starter
.....
..... 7 Valves

.....
.....
..... 3 Warning Label

.....
.....
... 2 PRINTED IN U.S.

A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. @307 529 306 847 287 523 842 525 725 1351 1 2 3 524 415 1194 18 21 12 219 19 20 220 746 742 21 29 16 146 741 24 552 718 15 998A 15B 718A 46 28 27 25 26 22 170 32 30 27 Illustrations cover a range of engines. @2 06/10/2008 21M300 5 122 51A 1023A 51 1022 33 42 35 1022 7 34 42 36 1029 868 1100 883 192 337 635 1026 45 798 13 1171 914 383 358 ENGINE GASKET SET 3 20 51A 7 51 7 163 1022 12 868 1095 VALVE GASKET SET 868 51 51A 1022 883 883 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 4270-3 Assemblies include all parts shown in frames. 3 06/10/2008 21M300 97A 109G 125 97A 109G 633B 98A 633B 108C 633B 98A 633B 108C 122 51A 130A 95A 117 135 127A 118 122 51A 130A 95A 117 135 127A 118 51 369 105A 133A 104A 51 105A 133A 104A 975 975A 137A 137 1127A 1127A 121A CARBURETOR OVERHAUL KIT 98A 127A 137A 121 CARBURETOR OVERHAUL KIT 98A 127A 137 104A 105A 51A 51 632 104A 105A 51A 51 163 633B 163 633B Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 4270-4 Assemblies include all parts shown in frames. @355 819 Illustrations cover a range of engines.

@@@Parts shown without corresponding text may not be used on your specific engine. 4270-6 Assemblies include all parts shown in frames. @@@@ mounting screw. @See repair instruction manual for additional information. @@@@ 06/10/2008 21M300 REF. NO. 1 2 3 5 7 11B 12 13 15 15B 16 18 19 20 21 22 23 24 25 PART NO. DESCRIPTION REF. NO. PART NO. @@@@Jet-Main (High Altitude) (Used After Code Date 08050600). ----- Note ----- 696135 Jet-Main (High Altitude) (Used Before Code Date 08050700). Kit-Carburetor Overhaul (Used After Code Date 08050600). Kit-Carburetor Overhaul (Used Before Code Date 08050700). REF. NO. 122 125 127A 130A 133A 135 PART NO. 694876 796122 D690727 696139 694914 698780 DESCRIPTION Spacer-Carburetor Carburetor Plug-Welch Valve-Throttle Float-Carburetor Tube-Fuel Transfer (Used After Code Date 08050600). ----- Note ----- 696142 Tube-Fuel Transfer (Used Before Code Date 08050700). Gasket-Float Bowl (Used After Code Date 08050600). Gasket-Float Bowl (Used Before Code Date 08050700). @No. 358. D Included in Carburetor Overhaul Kit-Ref. No. 121A. Included in Valve Gasket Set-Ref. No. 1095. Illustrations cover a range of engines.

@10 06/10/2008 21M300 REF. NO. 270 271 278 281 287 300B 300C PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. @DESCRIPTION 691027 Nut (Control Wire Casing) 691028 Lever-Control 792008 Washer (Governor Control Lever) 697268 Panel-Control 699629 Screw (Dipstick Tube) 794948 Muffler 793701 Muffler (This muffler is intended for replacement purposes only and is not to be used for retrofitting to engines with different exhaust systems) 795699 Housing-Blower 699481 Screw (Blower Housing) 697240 Shield-Cylinder 794822 Screw (Cylinder Shield) 793524 Motor-Starter 794824 Nut (Flywheel) 492341 Armature-Magneto 699477 Screw (Magneto Armature) 491055S Plug-Spark 698338 Switch-Rocker 794842 Washer (Muffler Bracket) 692603 Wire-Stop 795201 Gasket Set-Engine 19203 Puller-Flywheel 695422 Spring-Float Bowl (Used Before Code Date 08050700). 19374S Wrench-Spark Plug 795759 Washer (Governor Crank) 691363 Plug 792374 Manifold-Exhaust 794844 Screw (Exhaust Manifold) 455 795011 Cup-Flywheel 456 692299 Plate-Pawl Friction 459 281505S Pawl-Ratchet 472C 791948 Knob-Choke Shaft 474B 793118 Alternator 505 691251 Nut (Governor Control Lever) 523 790477 Dipstick 524 691876 Seal-Dipstick Tube 525 792041 Tube-Dipstick 528 793006 Hose-Primer (Cut to Required Length) 529 791822 Grommet 552 694674 Bushing-Governor Crank 562 793216 Bolt (Governor Control Lever) 564 699854 Screw (Control Cover) 597 691696 Screw (Pawl Friction Plate) 601 791850 Clamp-Hose 604A 696758 Cover-Control 604B 790473 Cover-Control 608A 699335 Starter-Rewind 610 794541 Arrester-Intake 613 794846 Screw (Muffler) 613B 794844 Screw (Muffler) 614 691620 Pin-Cotter (Governor Crank) 616A 795758 Crank-Governor 632 695917 Spring/Link- Mechanical Governor 633B D690998 Seal-Choke/Throttle Shaft 635 691909 Boot-Spark Plug (Alternator) 668B 794539 Spacer (Snow Hood) 689 691855 Spring-Friction 695 698807 Screw (Ring Gear) 795012 Screw (Drive Cap) 690959 Pin-Locating (Cylinder) 695178 Pin-Locating (Head) 696756 Shield-Heat 697465 Cover-Starter Drive 794540 Hood-Snow 793621 Hood-Snow 699200 Screw (Starter Drive Cover) 795901 Cord-Starter 710090 Nut (Muffler Bracket) 794843 Nut (Muffler Bracket) 691288 Gear-Timing 692564 Retainer-E Ring 694679 Gear-Idler 794839 Washer (Stop Wire) 697890 Screw (Rocker Arm) 794832 Screw (Muffler Bracket) 795078 Guard Muffler 792380 Guard-Muffler 699234 Screw (Muffler Guard) 710023 Screw (Muffler Guard) 691031 Seal-O Ring (Dipstick Tube) 790476 Dipstick/Tube Assembly 692424 Terminal-Spark Plug 793700 Bracket-Muffler K794086 Seal-Valve 398661 Wire/Connector- Alternator K695398 Gasket-Exhaust 710250 Gasket-Exhaust 791944 Switch-Key 794827 Screw (Rocker Cover) 696709 Guard-Rewind 304 305 306 307 309A 332 333 334 337 347 355 356 358 363 369 383 404 415 436C 437 K Included in Engine Gasket Set-Ref. No. 358. D Included in Carburetor Overhaul Kit-Ref. No. 121A.

Included in Valve Gasket Set-Ref. No. 1095. Illustrations cover a range of engines. @11 06/10/2008 21M300 REF. NO. 957 957A PART NO. DESCRIPTION REF. NO. 1023A 1026 1029 1036 PART NO. DESCRIPTION REF. NO. @@@@696138 Bowl-Float (Used Before

Code Date 08050700). 793382 Primer-Carburetor 794696 Key Set 696683 Pipe-Oil 794815 Fan-Flywheel 794544 Tube-Vent K690971 Gasket-Rocker Cover
698042 Cover-Rocker 695177 Rod-Push 690972 Arm-Rocker Label-Emissions (Available From A Briggs & Stratton Authorized Dealer) 277104 Manual
Operator's 794821 Screw (Flywheel Fan) 795200 Gasket Set-Valve 791959 Pivot-Rocker Arm 699772 Screw (Alternator) 695407 Screw (Float Bowl) 79482.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 21M300 TO 21M399 user guide](http://yourpdfguides.com/dref/3640276)

<http://yourpdfguides.com/dref/3640276>