



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 28R700 TO 28R799. You'll find the answers to all your questions on the BRIGGS & STRATTON 28R700 TO 28R799 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

- User manual BRIGGS & STRATTON 28R700 TO 28R799**
- User guide BRIGGS & STRATTON 28R700 TO 28R799**
- Operating instructions BRIGGS & STRATTON 28R700 TO 28R799**
- Instructions for use BRIGGS & STRATTON 28R700 TO 28R799**
- Instruction manual BRIGGS & STRATTON 28R700 TO 28R799**

FORM MS-4990-11/21/2005
REPLACES FORM MS-4990-10/21/2004
FILE IN SECT. 2 OF SERVICE MANUAL
28R700

Illustrated Parts List

Model Series

28R700

TYPE NUMBERS
0140 through 1158.

TABLE OF CONTENTS

Air Cleaner	4
Alternator	6
Blower Housing/Shrouds	5
Cams	2
Carburetor	3
Controls	4
Crankcase Cover/Sump	2
Crankshaft	2
Cylinder	2
Electric Starter	6
Flywheel	5
Governor Spring	4
Head	2
Ignition	6
Kits/Gaskets-Carburetor	3
Kits/Gaskets-Valve	2
Muffler	4
Oil	2
Piston Group	2
Valves	2



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 28R700 TO 28R799 user guide](http://yourpdfguides.com/dref/3640311)

<http://yourpdfguides.com/dref/3640311>

Manual abstract:

.....
.....
.....
... 4 Alternator

.....
.....
.... 6 Blower Housing/Shrouds .
.....

. 5 Cams

.....
.....
.....

. 2 Carburetor

.....
.....
..... 3 Controls

.....
.....
.....

... 4 Crankcase Cover/Sump

..... 2 Crankshaft

.....
.....
.....

. 2 Cylinder

.....
.....
.....

..... 2 Electric Starter ..

.....
.....
.....

.... 6 Flywheel .
.....

.....
.....
.....

. 5 Governor Spring

.....

..... 4 Head

.....
.....
.....

..... 2 Ignition

.....
.....
.....

..... 6 Kits/Gaskets-Carburetor

.....

.. 3 Kits/Gaskets-Valve

.....

..... 2 Muffler

.....
.....
.....

... 4 Oil.....

.....

.....

.....

..... 2 Piston Group.....

.....

.....

..... 2 Valves .

.....

.....

.....

..... 2 PRINTED IN U.S.

A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 28R700 29 847 523 525 842 287 28 27 25 27 1 524 26 306 2 3 34 36 33 27A 32A 32 35 40A 40 42 45 45 552 691 13 5 7 307 718 322A 308 13A 668 16B 733 24 810 668 635 383 337 46 43 8 9 871 869 870 10 1019 LABEL KIT 322 1058 OPERATOR'S MANUAL 16 733 810 358 ENGINE GASKET SET 3 12 176 741 146 741 146 7 524 691 758 4 12 759 757 761 9 20 51A 842 883 1095 VALVE GASKET SET 9 7 176 15 20 51A 883 22 4990-2 Assemblies include all parts shown in frames. @ @3 11/21/2005 28R700 467 968 167 R 51A 445 50 53 654 54 967 971 875 185 344 300 176 613A 11 646 607 607A 883 613 725 269 268 270 271 616 227 404 202 615 614 505 562 188 216 222 232 209 265 267 4990-4 Assemblies include all parts shown in frames. 4 11/21/2005 28R700 1044 74 74A 668A 332 75 73B 73C 668B 668C 455 934 1006 196 74 1005 1005 23 1051 783 363 726 726A 695 165 1051 783A 727 732 78 304 37 305 1036 EMISSIONS LABEL 305A 4990-5 Assemblies include all parts shown in frames. 5 11/21/2005 28R700 DC ONLY 474 356D 877A DUAL CIRCUIT 474A 474B 526 877 877B 501A TRI CIRCUIT 1054 1059 1059 1059 729 334 333 851 578 878 878A 789 NOTE: All Stators Use No. @ @6 11/21/2005 28R700 REF. NO. 1 2 PART NO.

DESCRIPTION REF. NO. 25 PART NO. DESCRIPTION REF. NO.

27 27A 28 PART NO. @ @16B 693653 Crankshaft (Used Before Code Date 95080100). @ @1141, 1150. @ @696399 Piston Assembly (.020" Oversize) (Used After Code Date 01060600).

696400 Piston Assembly (.030" Oversize) (Used After Code Date 01060600). ----- Note ----- 499284 Piston Assembly (Standard) (Used Before Code Date 01060700). @ @696403 Ring Set (Standard) (Used After Code Date 01060600). @ @ @ @ @ @392331 Ring Set (Standard Chrome) (Used Before Code Date 01060700). @ @691299 Lock-Piston Pin (Used After Code Date 95101500). 691792 Lock-Piston Pin (Used Before Code Date 95101600). 498319 Pin-Piston (Standard) (Used After Code Date 95101500). @ @ @ @ @ @ @ @7 11/21/2005 28R700 REF. NO.

40 PART NO. DESCRIPTION REF. NO. 117 118 121 PART NO. DESCRIPTION REF. NO. 142 PART NO. @ @----- Note ----- 691674 Screw (Rotating Screen) (1 1/2" Long) (Used Before Code Date 00040300). 74A 691655 Screw (13/32" Long) 75 690582 Washer (Flywheel) 78 690661 Screw (Flywheel Guard) 93 690602 Bushing-Throttle Shaft 94 498030 Kit-Idle Mixture 94A 494383 Kit-Idle Mixture 95 D691636 Screw (Throttle Valve) 95A D690718 Screw (Throttle Valve) 98 495800 Kit-Idle Speed 98A 694907 Kit-Idle Speed 104 D690525 Pin-Float Hinge 104A D694918 Pin-Float Hinge 105 D231855 Valve-Float Needle 105A D696136 Valve-Float Needle 106 D690577 Seat-Inlet 108 690464 Valve-Choke (Manual Choke) 108A 692344 Valve-Choke (Choke A Matic) 108B 694923 Valve-Choke D690880 Jet-Main (Standard) D694925 Jet-Main (High Altitude) 499220 Kit-Carburetor Overhaul (LMT 58, 59, 60, 61, 62, 92, 93, 94, 95, 96, 108, 111, 162, 165, 169) ----- Note ----- 499231 Kit-Carburetor Overhaul (LMT 133, 134, 135, 136, 166, 168) 697884 Kit-Carburetor Overhaul (697212, 697906 694930 Kit-Carburetor Overhaul (Nikki) 698171 Carburetor (696160, 696162, 696164, 696166, 697212, 697213, 697214, 697906) ----- Note ----- 498027 Carburetor (Gravity) (LMT 1, 2, 3, 4, 5, 6, 7, 32, 37, 38, 39, 40, 41, 63, 64, 65, 66, 77, 78, 79, 80, 81, 92, 93, 94, 95, 96, 97, 108, 111, 133, 134, 135, 136, 162, 163, 164, 165) 699831 Carburetor (Nikki) D695005 Plug-Welch D694916 Plug-Welch 690468 Valve-Throttle 691750 Valve-Throttle 694917 Valve-Throttle 494379 Kit-Throttle Shaft 694909 Kit-Throttle Shaft 494381 Float-Carburetor 694914 Float-Carburetor D281165 Gasket-Float Bowl D2694920 Gasket-Float Bowl 495097 Kit-Choke Shaft (Manual Choke) 495931 Kit-Choke Shaft (Choke A Matic) 694913 Kit-Choke Shaft D697592 Nozzle-Carburetor (Standard) (696160, 696162, 696164, 696166, 697212, 697213, 697214, 697906) ----- Note ----- D691434 Nozzle- Carburetor (Standard) (LMT 92, 93, 94, 96) 143 497737 Nozzle-Carburetor (High Altitude) (LMT 92, 96) 147 D497472 Jet-Pilot (LMT 37, 39, 41, 77, 79, 81) ----- Note ----- 231983 Jet-Pilot (LMT 136) 147A D694927 Jet-Pilot 146 691639 Key-Timing 165 693148 Nut (Ring Gear) 167 692297 Seal-Air Cleaner Nut 173 694926 Valve-Idle Mixture 176 K691917 Seal-O Ring (Air Cleaner Base) 185 690958 Nut (Air Cleaner Base) 186 692317 Connector-Hose 187 691050 Line-Fuel (Cut to Required Length) ----- Note ----- 296004 Line-Fuel (Cut to Required Length) Used on Type No(s). 0140, 0148, 0637, 0648. 188 691693 Screw (Control Bracket) 196 695493 Fan/Screen Assembly (Used Before Code Date 00042400). Used on Type No(s). 1148. 202 691841 Link-Mechanical Governor Used on Type No(s). @ @8 11/21/2005 28R700 REF.

NO. 209 PART NO. DESCRIPTION REF. NO. 309 PART NO.

DESCRIPTION REF. NO. @ @ @ @1114. @ @1141, 1150. 691532 Strap-Starter 691251 Nut (Governor Control Lever) 693699 Drive-Starter (Used With Steel Ring Gear) 696541 Drive-Starter (Used With Aluminum And Plastic Ring Gears) 696540 Drive-Starter 692024 Clutch-Drive 692014 Dipstick K281370 Seal-Dipstick Tube 691398 Tube-Dipstick 690326 Screw (Regulator) 692034 Armature-Starter (3 5/8" Housing Length) 390837 Armature-Starter (3 5/8" Housing Length) ----- Note ----- 490309 Armature- Starter (4 3/8" 8 1059 PART NO. DESCRIPTION REF. NO. 1083 1083A 1090 1091 1095 1119 PART NO. DESCRIPTION 696770 Label-Emissions (Used After Code Date 01093000). ----- Note ----- 695699 Label- Emissions (Used After Code Date 00063000 and Before Code Date 01100100).

@ @694325 Label- Emissions (Used After Code Date 99010300 and Before Code Date 99100100). @ @499361 Label- Emissions (Used Before Code Date 97070100). @ @11 11/21/2005 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 28R700 TO 28R799 user guide](#)

