



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 290400 TO 290499. You'll find the answers to all your questions on the BRIGGS & STRATTON 290400 TO 290499 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 290400 TO 290499
User guide BRIGGS & STRATTON 290400 TO 290499
Operating instructions BRIGGS & STRATTON 290400 TO 290499
Instructions for use BRIGGS & STRATTON 290400 TO 290499
Instruction manual BRIGGS & STRATTON 290400 TO 290499



FORM MS-5369-10/31/2006
REPLACES FORM MS-5369-11/1987
FILE IN SECT. 2 OF SERVICE MANUAL

290400

Illustrated Parts List Model Series 290400

TYPE NUMBERS
0022 through 0035,
0040 through 0062,
0070, 0076.0100,
0102,
0120 through 0125,
0307, 0318, 0320,
0326,
0340 through 0366,
0370 through 0378,
0382, 0385, 0390,
0391, 0394, 0398,
0402.

TYPE NUMBERS
0406 through 0454,
0457 through 0460,
0500 through 0505,
1066,
1072 through 1077,
1094, 1106, 1114,
1133, 1136, 1137,
1146 through 1149,
1152, 1153, 1154,
1157 through 1160,
1163, 1191, 1205,
1206.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- Refer to the illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 290400 TO 290499 user guide](http://yourpdfguides.com/dref/3639700)
<http://yourpdfguides.com/dref/3639700>

Manual abstract:

@@@@@@Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note." If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.

For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply. PRINTED IN U.S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved.

No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. B. C. D. E.

F. 290400 1 11A 18 634 12 38 10 370 8 9 718 20 22 1058 OPERATOR'S MANUAL REF. NO. 1 PART NO. REF. NO. 12 PART NO. REF. NO. 20 22 38 89 116 11 2 3 718A 116 572 89 15 REQUIRES SPECIAL TOOL TO INSTALL.

SEE REPAIR INSTRUCTION MANUAL. DESCRIPTION PART NO. DESCRIPTION DESCRIPTION 2 3 8 9 10 11 11A 808440 Cylinder Assembly ----- Note ----- 807521 Cylinder Assembly (Used Before Code Date 97050100). 807687 Bushing K805101 Seal-Oil 807795 Breather Assembly ----- Note ----- 807893 Breather Assembly (Used Before Code Date 90111500). K807688 Gasket-Breather 805751 Screw 806114 Tube-Breather (Used After Code Date 96101000). 805362 Tube-Breather (Used Before Code Date 96101100). 15 18 806190 Gasket-Crankcase ----- Note ----- K805112 Gasket- Crankcase (Used Before Code Date 97050100). 805048 Plug-Oil Drain 808502 Cover-Crankcase ----- Note ----- 807628 Cover- Crankcase (Used Before Code Date 97050100). 808506 Cover- Crankcase Used on Type No(s). 0414, 1114, 1163, 1211.

807884 Cover- Crankcase (Used Before Code Date 97050100). Used on Type No(s). 0414, 1114, 1163. 370 572 634 718 718A 1058 K805049 Seal-Oil 805017 Screw 805194 Screw (Used Before Code Date 90111500). 805059 Plug-Oil 806191 Seal-O-Ring ----- Note ----- K805198 Seal-O-Ring (Used Before Code Date 97050100).

805484 Washer 805197 Plate-Breather 805416 Washer 805103 Dowel-Sleeve 805102 Dowel-Sleeve (Used Before Code Date 90091100). 272105 Operator's Manual K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-2 Assemblies include all parts shown in frames. 2 10/31/2006 290400 635 337 5B 871 830A 13 6 1026 1029A 1031 5 830 35 1022 871 7 GRAPHOILR 7A METAL 33 45 34 868 35 7A METAL 383 40 40A 192 5C 830A 6 13 871 1030 5A REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. 1029 1100 34 868 192 32 167 34 33 167 7 868 1029 1100 830 871 35 40 40A 40 40A GRAPHOILR 192 1022 REF.

NO. 5 5A 5B 5C 6 7 7A 13 33 34 35 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. 1026 PART NO. DESCRIPTION 808381 Head-Cylinder #1 808382 Head-Cylinder #2 807987 Head-Cylinder #1 (Used Before Code Date 96040100). 807988 Head-Cylinder #2 (Used Before Code Date 96040100).

805193 Washer (Used Before Code Date 94050100). K806085 Gasket-Cylinder Head K807986 Gasket-Cylinder Head (Used Before Code Date 96040100). 805097 Screw 807681 Valve-Exhaust 807680 Valve-Intake 805937 Spring-Valve ----- Note ----- 805078 Spring-Valve (Used Before Code Date 94011800). 40 805092 Retainer-Valve 40A 807683 Retainer-Valve 45 262679 Tappet-Valve 167 K805420 Washer 192 807623 Screw-Valve Adj. 337 491055 Plug-Spark 383 19374 Wrench-Spark Plug 635 805529 Boot-Spark Plug 830 806037 Stud-Rocker Arm 830A 805343 Stud-Rocker Arm (Used Before Code Date 96040100). 868 805094 Seal-Valve 871 805084 Bushing-Guide 1022 K806039 Gasket-Rocker Cover 1029 1029A 1030 1031 1100 805352 Rod-Push (Steel) ----- Note ----- 805617 Rod-Push (Aluminum) (Exhaust Side Only) 806036 Arm-Rocker (Used After Code Date 96033100). 808096 Arm-Rocker (Used After Code Date 96011700). ----- Note ----- 808159 Arm-Rocker (Used Before Code Date 94011800). 805342 Shaft-Rocker Arm 805341 Support-Rocker Arm 806038 Pivot-Rocker Arm K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-3 Assemblies include all parts shown in frames. 3 10/31/2006 290400 21 524A 53 51A 171 54 1023A 167 1022 1023 122 50 51 51A 54 1022 1023B REF.

NO. 21 50 PART NO. DESCRIPTION REF. NO. 122 167 171 524A 1022 PART NO. 805328 K805420 805019 K271983 K806039 DESCRIPTION Spacer-Carburetor Washer Nut Seal-Fill Tube Gasket-Rocker Cover REF. NO. 1023 PART NO. DESCRIPTION 51 51A 53 54 491832 Dipstick 805772 Manifold-Intake ----- Note ----- 805409 Manifold- Intake (Used Before Code Date 92050100). K805700 Gasket-Intake K805023 Gasket-Intake 805466 Screw 805006 Screw 1023A 1023B 805100 Cover-Rocker ----- Note ----- 807665 Cover-Rocker Cyl.

#1 Fuel Pump Installed 805842 Cover-Rocker 808032 Cover-Rocker Cyl. #1 Fuel Pump Installed ----- Note ----- 805997 Cover-Rocker Used on Type No(s). 1074, 1137, 1157, 1159, 1160, 1163, 1205, 1206. K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-4 Assemblies include all parts shown in frames. 4 10/31/2006 290400 25 27 26 46 1025 29 32 28 27 27 REF. NO. 25 PART NO. DESCRIPTION REF. NO. 27 28 29 PART NO.

DESCRIPTION REF. NO. 32 46 1025 PART NO. DESCRIPTION 26 807619 Piston Assembly (Standard) ----- Note ----- 807807 Piston Assy. (.010" Oversize) 807809 Piston Assy. (.020" Oversize) 807811 Piston Assy. (.030" Oversize) 807620 Ring Set (Standard) ----- Note ----- 807808 Ring Set (.010" Oversize) 807810 Ring Set (.020" Oversize) 807812 Ring Set (.030" Oversize) 805099 Lock-Piston Pin 807621 Pin-Piston 807900 Rod-Connecting (Standard) ----- Note ----- 807803 Rod- Connecting (.020" Undersize) 805395 Screw 807542 Gear-Cam 805313 Spool-Governor K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-5 Assemblies include all parts shown in frames. 5 10/31/2006 290400 24 16 220 741 146 17 357 REF.

NO. 16 PART NO. REF. NO. PART NO.

REF. NO. 17 24 PART NO. DESCRIPTION DESCRIPTION 807806 Crankshaft Used on Type No(s).



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 290400 TO 290499 user guide](http://yourpdfguides.com/dref/3639700)
<http://yourpdfguides.com/dref/3639700>

0124, 0407, 0421, 0429, 0451. 807849 Crankshaft Used on Type No(s). 0414, 1114, 1163. 808000 Crankshaft Used on Type No(s). 0500. 808417 Crankshaft Used on Type No(s).

1074, 1075, 1106, 1149, 1154, 1159. 808419 Crankshaft Used on Type No(s). 1077, 1137, 1146, 1157, 1160, 1205, 1206. 808422 Crankshaft Used on Type No(s). 1163. DESCRIPTION 807589 Crankshaft ----- Note ----- 807590 Crankshaft Used on Type No(s). 0041, 0049, 0051, 0351, 1147, 1153. 807745 Crankshaft (Used After Code Date 89051700). Used on Type No(s). 0022, 0027, 0042, 0044, 0052, 0054, 0059, 0060, 0061, 0062, 0122, 0318, 0320, 0342, 0350, 0352, 0354, 0359, 0360, 0361, 0366, 0373, 0374, 0377, 0378, 0382, 0385, 0390, 0391, 0394, 0398, 0408, 0412, 0413, 0415, 0416, 0417, 0419, 0427, 0433, 0436, 0443, 0445, 0446, 0447, 0448, 0452, 0457, 0458, 0460, 0501, 0502, 0505, 1066, 1073, 1077, 1094, 1133, 1136, 1137, 1146, 1148, 1152, 1157, 1160, 1191, 1205, 1206.

146 220 357 741 805213 Bearing-Ball 806066 Key-Flywheel ----- Note ----- 805016 Key-Flywheel (Used Before Code Date 95030100). 94196 Key-Timing 807625 Washer Set 91540 Key-Drive Pulley 805675 Gear-Timing K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-6 Assemblies include all parts shown in frames. 6 10/31/2006 290400 125 91 119 955 102 95 108 141 987 634B 131 142 103 105 51 947 REF. NO. 51 91 PART NO.

DESCRIPTION REF. NO. 108 116D 117 PART NO. DESCRIPTION REF. NO.

127 130 131 141 142 634A 634B 947 955 987 1091 PART NO. D805559 805554 807720 807722 D805553 D805557 D805543 807664 807723 D805544 D805862 DESCRIPTION Plug-Welch Valve-Throttle Shaft-Throttle Shaft-Choke Nozzle-Carburetor Collar-Throttle Collar-Choke Shaft Solenoid-Fuel Plug-Carburetor Seal-Shaft Cap-Limiter 94 117 127 1091 98 116D 104 634A 130 95 987 94 95 98 102 103 104 105 K805700 Gasket-Intake 807919 Body Assembly-Upper ----- Note ----- 807721 Body Assy- Upper (Used Before Code Date 90120100). D808257 Valve-Idle Adjustment ----- Note ----- D807719 Valve-Idle Adjustment (Used Before Code Date 95010100). 805538 Screw 808177 Screw-Idle Speed D805541 Gasket-Carburetor Body 805546 Float -Carburetor D805545 Pin-Float Hinge D805547 Valve-Needle (Pump Feed Carburetors) ----- Note ----- D805620 Valve-needle (Gravity Feed Carburetors) 119 125 805539 Valve-Choke D805549 Washer D805852 Jet-Main (Standard) (Used After Code Date 94123100). ----- Note ----- D805624 Jet-Main (Standard) (Used Before Code Date 95010100). D805625 Jet-Main (High Altitude) (Used After Code Date 89111700). 805540 Screw 808249 Carburetor (Pump Feed) (Used After Code Date 90113000). ----- Note ----- 807832 Carburetor (Pump Feed) (Used Before Code Date 90120100). 808295 Carburetor (Pump Feed) Used on Type No(s). 1106, 1149, 1154.

808250 Carburetor (Gravity Feed) K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-7 Assemblies include all parts shown in frames. 7 10/31/2006 290400 539 216A 212A 1012 227 277 592 269 REF. NO. 206 207 208 PART NO. DESCRIPTION REF. NO. 216 216A 227 232 265 216 657 265 212 232 280 562 951 271 208 268 PART NO. 805439 805509 807528 805465 221535 207 688 1054A 206 REF. NO. 280 PART NO.

DESCRIPTION 270 DESCRIPTION 212 212A 805470 Nut 805473 Spring-Control Rod 806080 Rod-Control (Used After Code Date 96033100). ----- Note ----- 808453 Rod-Control (Used Before Code Date 96040100). 805996 Rod-Control (Used After Code Date 94113000 and Before Code Date 96040100). 805471 Rod-Control (Used Before Code Date 94120200). 805480 Link-Throttle 805918 Link-Throttle 268 65616 269 26633 270 271 277 63426 290568 805018 Link-Choke Rod-Hand Choke Lever-Governor Spring-Link Clamp-Casing ----- Note ----- 22372 Clamp-Casing Used on Type No(s).

0123, 0409. Casing-Wire (72" Long) (Cut to Required Length) Wire-Control (78" Long) (Cut to Required Length) Locknut-Casing Lever-Control Washer 539 562 592 657 688 951 1012 1054A 805926 Bracket-Rod ----- Note ----- 805472 Bracket-Rod (Used Before Code Date 95050100). 221372 Clip-Rod 805381 Bolt 805383 Nut 805762 Screw 805485 Cap-Spring 807609 Control-Choke 280869 Retainer-Link 710349 Tie-Cable K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-8 Assemblies include all parts shown in frames. @@NO. 209 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. PART NO. @@805454 Spring-Governor Idler Used on Type No(s). 0326, 0437. Bracket-Control (Used With Control Lever and/or Wire With a 807594 Wire-Stop (Cylinder No. 2) (Used Before Code Date 90120200).

@@@NO. 1017 1024 1027 PART NO. @@NO. 39 87 89 116A 116B 116C 166 189 239 284 305 523 PART NO. @@NO. @@@@NO. 182 187 187A 240 240A 240B 284C 307 387 527 539A PART NO. DESCRIPTION REF. NO. 542 601 601A 601B 725 788 823 843 918 PART NO. @@NO. 957 958 958A 959 959A 960 960A 961 972 1038 1054 1054 PART NO. @@@@REF. NO. 958B 959B 959C 960B 960C 972A 1038A 1054 PART NO.

@@NO. 182A 187B 187C 187D 188 210 240C 284C 307 PART NO. @@NO. @@@@NO. @@NO.

862 862A 966 967 968 969 971 991 PART NO. DESCRIPTION REF. NO. 1004 1004A 1014 1014A PART NO. @@@@NO. 11 161A PART NO. DESCRIPTION REF. NO. 165 171B 284A 445A 467A 535A 537 537A PART NO. @@NO.

642A 643A 643B 862B 862C 968A PART NO. 224885 224198 222272 492133 DESCRIPTION 806114 Tube-Breather (Used After Code Date 96101000). 808414 Base-Air Cleaner (Used After Code Date 96101000). ----- Note ----- 808117 Base-Air Cleaner (Used Before Code Date 96101100). Cover-Air Cleaner Retainer-Air Filter Retainer-Air Filter Strap-Cleaner Mounting 808113 Strap-Cleaner Mounting 280903 Cover-Air Cleaner K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-16 Assemblies include all parts shown in frames. 16 10/31/2006 290400 300 884 884 305 307 676 346 676A 423 307 300C 300B 882 300A 836 300D 837 832 526 REF. NO. 300 300A 300B 300C 300D PART NO. REF. NO.

305 307 346 423 526 676 676A PART NO. 805406 805025 810079 805260 805448 495518 808393 REF. NO. 832 PART NO. DESCRIPTION DESCRIPTION Screw Screw Screw Screw Screw Deflector-Muffler Deflector-Muffler DESCRIPTION 807741 Muffler-Exhaust (Used With Manifold 805378) 807742 Muffler-Exhaust Used With Manifold 805142 807965 Muffler 807964 Muffler 808340 Muffler 836 837 882 884 808227 Guard-Muffler ----- Note ----- 808009 Guard-Muffler (Used Before Code Date 96042400).

805849 Screw 808085 Spacer (Includes 2) 805502 Flange-Exhaust 807595 Clamp-Muffler K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-17 Assemblies include all parts shown in frames. 17 10/31/2006 290400 526 884A 300G 863B 307A 277A 436 436A 526 436B 994 863A 613A 346A 676B 676C 307 676D 613A 883 346A REF.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 290400 TO 290499 user guide](http://yourpdfguides.com/dref/3639700)
<http://yourpdfguides.com/dref/3639700>

NO. 277A 300G 307 307A 346A 436 PART NO. 810108 807948 805025 810107 93705 805142 DESCRIPTION Washer Muffler-Exhaust Screw Screw Screw
Manifold-Exhaust (Used With Muffler 807742) 346A REF.

NO. 436A 436B 526 613A PART NO. 346A DESCRIPTION REF. NO. PART NO. DESCRIPTION 805378 Manifold-Exhaust (Used With Muffler 807741)
805403 Manifold-Exhaust (Muffler Supplied By OEM) 805448 Screw 805158 Screw 676B 396903 Deflector-Muffler 676C 393761 Deflector-Muffler 676D
397630 Deflector-Muffler 863A 805812 Bracket-Muffler 863B 805811 Bracket-Muffler 883 K805024 Gasket-Exhaust 884A 392649 Clamp-Muffler 994
392390 Arrester-Spark K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-18 Assemblies
include all parts shown in frames. 18 10/31/2006 290400 304 ADAPTER FOR METAL AIR CLEANER BASE ADAPTER (CURRENT STYLE) 284B 171C
FOR PLASTIC AIR CLEANER BASE 304A 307 WELDNUT LOCATION (IF EQUIPPED) 189A 305 1036 LABEL KIT-EMISSION REF. NO. 171C 189A
284B 304 PART NO. 810056 806101 93410 808055 DESCRIPTION Nut Washer Screw Housing-Blower (Red Without Weld Nut) ----- Note ----- 808408
Housing- lower (Black Without Weld Nut) REF.

NO. 304A PART NO. 284C DESCRIPTION REF. NO. PART NO. DESCRIPTION 807814 Housing-Blower (Black Without Weld Nut) ----- Note ----- 807891
Housing- Blower (Black Without Weld Nut) (Used Before Code Date 90111700). 807820 Housing- Blower (Red Without Weld Nut) 807892 Housing- Blower
(Red Without Weld Nut) (Used Before Code Date 90111700). 808008 Housing- Blower (Red With Weld Nut) 305 307 1036 807654 Housing- lower (Red With
Weld Nut) (Used Before Code Date 90111700). 807662 Housing- Blower (Black With Weld Nut) (Used Before Code Date 90111700). 805406 Screw 805025
Screw ----- Note ----- 805247 Screw Engines With Fuel Tanks Label-Emissions (Available from Authorized Briggs & Stratton Service Dealer) K Engine
Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-19 Assemblies include all parts shown in
frames.

19 10/31/2006 290400 308A 866 573 1046 305 308B 529 REF. NO. 37 PART NO. 305 865 308 37 308C 373 423 727 657 879 189 526 REF. NO.
PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION DESCRIPTION 807651 Cover- Cylinder (Cylinder #2 Red) (Used Before Code Date
90111700).

Nut Screw Screw Grommet Plate-Back (Black) ----- Note ----- 690902 Plate-Back (Red) Screw Cover-Starter Drive (Black) ----- Note ----- 841313 Cover-
Starter Drive (Red) Cover-Air Guide (Black) Cover-Air Guide (Black) ----- Note ----- Cover-Air Guide (Red) Cover-Carburetor Plug-Blower Housing 189
305 308 308A 805506 Guard-Flywheel (Black) ----- Note ----- 805504 Guard- Flywheel (Red) 805449 Washer 805406 Screw 808309 Cover-Cylinder (Used
After Code Date 95071400). ----- Note ----- 807868 Cover- Cylinder (Cylinder #1 Black) (Used After Code Date 90111600 and Before Code Date
95071500). 807656 Cover- Cylinder (Cylinder #1 Black) (Used Before Code Date 90111700). 807869 Cover-Cylinder (Cylinder #2 Black) (Used After Code
Date 90111600). ----- Note ----- 807657 Cover- Cylinder (Cylinder #2 Black) Or 308B 308C 807649 Cover- Cylinder (Cylinder #2 Red) (Used Before Code
Date 90111700). 808310 Cover-Cylinder (Used After Code Date 95071400). ----- Note ----- 807870 Cover- Cylinder (Cylinder #1 Black) (Used After Code
Date 90111600 and Before Code Date 95071500). 807658 Cover- Cylinder (Cylinder #1 Black) Or 807650 Cover- Cylinder (Cylinder #1 Red) 808100 Cover-
Cylinder (Cylinder #2 Black) (Used After Code Date 90111600). ----- Note ----- 807659 Cover- Cylinder (Cylinder #2 Black) Or 373 423 526 529 573
805383 805260 805448 805641 807663 657 727 805009 805505 865 866 807661 805738 879 1046 805841 805753 K Engine Gasket Set-Reference 358 D
Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-20 Assemblies include all parts shown in frames. 20 10/31/2006 290400 23
1047 363 73B 188A 75 718B 321 78 74 73A 189B 85 85A 307 455 73 332 726 668 REF.

NO. 23 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 807530 Flywheel Used on Type No(s). 0124, 0407, 0410, 0414, 0421, 0429, 0430,
0503, 1114, 1163. Screen-Rotating Screen-Rotating Screen-Rotating Screw Washer Screw Screw Washer Screw Fan-Booster Nut Flywheel
Puller REF. NO. 455 PART NO.

DESCRIPTION 807531 Flywheel ----- Note ----- 807520 Flywheel Used on Type No(s). 0307, 0318, 0320, 0340, 0347, 0350, 0353, 0357, 0359, 0360, 0361,
0363, 0366, 0370, 0372, 0385, 0390, 0391, 0398, 0402, 0408, 0409, 0412, 0415, 0416, 0422, 0426, 0427, 0433, 0443, 0445, 0446, 0447, 0448, 0454, 0457,
0458, 0459, 0500, 0503, 0505, 1066, 1072, 1133, 1136, 1146, 1147, 1148, 1157, 1159, 1191, 1205, 1206. 73 73A 73B 74 75 78 85 85A 188A 189B 307 321
332 363 494439 224779 805723 94626 805007 805447 94385 94493 93847 90366 805025 213472 805021 19203 668 718B 726 1047 805876 Cup-Flywheel
----- Note ----- 805153 Cup-Flywheel (Used Before Code Date 93072600). 805402 Spacer 805613 Pin-Locating 807805 Gear-Ring 807867 Shaft-Stub K
Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-21 Assemblies include all parts shown
in frames. 21 10/31/2006 290400 608 58 456 459 515 56 615 461 57 60 55 59 954 305 949 REF.

NO. 55 56 57 58 PART NO. DESCRIPTION REF. NO. 59 60 305 456 459 461 515 PART NO.

805957 808167 805406 805954 808166 805955 805953 DESCRIPTION Insert-Grip Grip-Starter Rope Screw Plate-Retainer Pawl-Ratchet Screw Spring-
Pawl REF. NO. 608 615 949 PART NO. DESCRIPTION 808186 Housing-Rewind Starter 805949 Pulley-Starter 805951 Spring-Rewind Starter 66574 Rope-
Starter (Cut to Required Length) 954 808087 Starter-Rewind 805952 Retainer 808086 Guard-Finger Used on Type No(s). 0431, 0504, 1149, 1154.

@@@NO. 55A 56A 57A 58A PART NO. DESCRIPTION REF. NO. 60A 69 69A 305 455 456A PART NO.

@@NO. 459A 461A 515B 608A PART NO. @@23 10/31/2006 290400 309 510 783 802 1090 615A 803 311 110 592 544 310 503 801 284C REF. NO. 110
284C 309 310 311 503 510 PART NO. 225137 805247 499521 95035 497608 806000 497606 DESCRIPTION Washer Screw Motor-Starter Screw Brush Set
Strap-Starter Drive-Starter REF. NO. 5441 592 615A 783 PART NO. DESCRIPTION REF. NO.

801 802 803I 1090 PART NO. DESCRIPTION Armature-Starter (Serviced By 499521 Starter Motor Only) 92278 Nut 263080 Retainer 280104 Gear-Starter
497626 Cap-Drive 497607 Cap-End Housing-Starter (Serviced By 499521 Starter Motor Only) 497605 Retainer-Brush K Engine Gasket Set-Reference 358 D
Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-24 Assemblies include all parts shown in frames. 24 10/31/2006 290400
309A 510A 513 876 783 802A 896 803 284C 801A 311A 544 1003 503 310A REF.



[You're reading an excerpt. Click here to read official BRIGGS &
STRATTON 290400 TO 290499 user guide
http://yourpdfguides.com/dref/3639700](http://yourpdfguides.com/dref/3639700)

NO. 284C 309A 310A 311A 503 510A PART NO.

DESCRIPTION REF. NO. 513 544 783 801A 802A PART NO. 398003 490309 280104 394856 490310 DESCRIPTION Clutch-Drive Armature-Starter Gear-Starter Cap-Drive Cap-End (4 9/16" Housing Length) ----- Note ----- 494988 Cap-End (4 3/8" Housing Length) REF. NO. 803 PART NO. DESCRIPTION 805247 Screw 494990 Motor-Starter (4 3/8" Housing Length) 94004 Screw (4 3/8" Housing Length) 490311 Brush Set 806000 Strap-Starter (4 9/16" Housing Length) 495878 Drive-Starter (4 3/8" Housing Length) 876 896 1003 398892 Housing-Starter (4 9/16" Housing Length) ----- Note ----- 494205 Housing-Starter (4 3/8" Housing Length) 495877 Kit-Gear 94288 Pin-Roll 490316 Spring-Brush K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-25 Assemblies include all parts shown in frames. 25 10/31/2006 290400 309B 510B 801B 615B 802B 284C 803A 311B 503 544A 310B REF. NO. 284C 309B 310B PART NO. DESCRIPTION REF. NO. 311B 503 510B 544A PART NO. 496887 806000 496881 496816 DESCRIPTION Brush Set Strap-Starter Drive-Starter Armature-Starter REF. NO.

615B 801B 802B 803A PART NO. 94953 496814 496813 496815 DESCRIPTION Retainer Cap-Drive Cap-End Housing-Starter 805247 Screw 808106 Motor-Starter (Steel Pinion) 496880 Screw K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-26 Assemblies include all parts shown in frames. 26 10/31/2006 290400 358 ENGINE GASKET SET 978 978A 51 12 1022 51A 20 3 116 116A 116B 116C 7 GRAPHOILR 7A METAL 883 537A 537 87 PART NO. 524 9 524A 167 REF. NO. PART NO. REF. NO. PART NO. DESCRIPTION REF. NO. 116 116A 116B 116C 167 358 DESCRIPTION DESCRIPTION 3 K805101 Seal-Oil 7 K806085 Gasket-Cylinder Head 7A K807986 Gasket-Cylinder Head (Used Before Code Date 96040100). 9 K807688 Gasket-Breather 12 K805112 Gasket-Crankcase 20 K805049 Seal-Oil 51 K805700 Gasket-Intake 51A K805023 Gasket-Intake 87 K805054 Seal-Governor Shaft K805198 Seal-O-Ring (Crankcase Cover) K805386 Seal-O-Ring K805058 Seal-O-Ring (Oil Pump) K805316 Seal-O-Ring (Pick-Up Tube) K805420 Washer 808390 Set-Engine Gasket ----- Note ----- 807989 Set-Engine Gasket (Used Before Code Date 96040100). 524 K281370 Seal-Fill Tube 524A K271983 Seal-Fill Tube 537 K805655 Gasket-Air Cleaner 537A K805003 Gasket-Air Cleaner 883 K805024 Gasket-Exhaust 978 K805250 Gasket 978A K805229 Gasket 1022 K806039 Gasket-Rocker Cover K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-27 Assemblies include all parts shown in frames. 27 10/31/2006 290400 1095 VALVE OVERHAUL KIT 1022 7 GRAPHOILR 7A METAL 524A 883 167 171 6 51A 121 CARBURETOR OVERHAUL KIT 127 104 142 117 94 1091 102 634B 634A 987 105 116D REF.

NO. PART NO. DESCRIPTION REF. NO. 105 PART NO.

DESCRIPTION REF. NO. 121 PART NO. DESCRIPTION 6 805193 Washer (Used Before Code Date 94050100). 7 K806085 Gasket-Cylinder Head 7A K807986 Gasket-Cylinder Head (Used Before Code Date 96040100). 51A K805023 Gasket-Intake 94 D808257 Valve-Idle Adjustment ----- Note ----- D807719 Valve-Idle Adjustment (Used Before Code Date 95010100). 102 D805541 Gasket-Carburetor Body 104 D805545 Pin-Float Hinge 116D 117 D805547 Valve-Needle (Pump Feed Carburetors) ----- Note ----- D805620 Valve-Needle (Gravity Feed Carburetors) D805549 Washer-Seal D805852 Jet-Main (Standard) (Used After Code Date 94123100). ----- Note ----- D805624 Jet-Main (Standard) (Used Before Code Date 95010100). D805625 Jet-Main (High Altitude) (Used After Code Date 89111700). 127 142 167 171 524A 634A 634B 883 987 1022 1091 1095 807850 Kit-Carburetor Overhaul ----- Note ----- 808262 Kit-Carburetor Overhaul Used on Type No(s).

0478, 1155, 1178. D805559 Plug-Welch D805553 Nozzle-Carburetor K805420 Washer 805019 Nut K271983 Seal-Fill Tube D805557 Collar-Throttle D805543 Collar-Choke Shaft K805024 Gasket-Exhaust D805544 Seal-Shaft K806039 Gasket-Rocker Cover D805862 Cap-Limiter 808392 Kit-Valve Overhaul ----- Note ----- 807990 Kit-Valve Overhaul (Used Before Code Date 96040100). K Engine Gasket Set-Reference 358 D Carburetor Overhaul Kit-Reference 121 Valve Overhaul Kit-Reference 1095 5389-28 Assemblies include all parts shown in frames. 28 10/31/2006 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 290400 TO 290499 user guide](http://yourpdfguides.com/dref/3639700)
<http://yourpdfguides.com/dref/3639700>