



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 31A600 TO 31A699. You'll find the answers to all your questions on the BRIGGS & STRATTON 31A600 TO 31A699 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 31A600 TO 31A699
User guide BRIGGS & STRATTON 31A600 TO 31A699
Operating instructions BRIGGS & STRATTON 31A600 TO 31A699
Instructions for use BRIGGS & STRATTON 31A600 TO 31A699
Instruction manual BRIGGS & STRATTON 31A600 TO 31A699



FORM MS-3726-11/09/2007
REPLACES FORM MS-3726-07/06/2007
FILE IN SECT. 2 OF SERVICE MANUAL
31A600

Illustrated Parts List

Model Series

31A600

TYPE NUMBERS
0111 Through 0786.

TABLE OF CONTENTS

Air Cleaner	5
Alternator	6
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	6
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	6
Engine Sump	2
Exhaust System	5
Flywheel	5
Fuel Supply	6
Gasket Set - Engine	2
Gasket Set - Valve	3
Governor Spring	6
Ignition	6
Intake Manifold	3
Kit - Carburetor Overhaul	4
Lubrication	3
Operator's Manual	2
Piston, Rings, Connecting Rod	2
Valves	3
Warning Label	2



PRINTED IN U.S.A.
COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 31A600 TO 31A699 user guide](http://yourpdfguides.com/dref/3639807)

<http://yourpdfguides.com/dref/3639807>

Manual abstract:

2 OF SERVICE MANUAL 31A600 Illustrated Parts List Model Series 31A600 TYPE NUMBERS 0111 Through 0786. TABLE OF CONTENTS Air Cleaner . . .

.....
.....
.....
..... 5 Alternator
.....
.....
.....
.. 6 Blower Housing
.....
.....
.....
... 5 Camshaft ..
.....
.....
.....
2 Carburetor
.....
.....
..... 4 Controls
.....
.....
.....
..... 6 Crankshaft
.....
.....
..... 2 Cylinder .
.....
.....
.....
..... 2 Cylinder Head ...
.....
.....
.....
... 3 Electric Starter .
.....
.....
.....
. 6 Engine Sump
.....
.....
..... 2 Exhaust System
.....
.....
..... 5 Flywheel
.....
.....
.....
.....
. 5 Fuel Supply
.....
.....
.....
. 6 Gasket Set - Engine
.....
.....
... 2 Gasket Set - Valve
.....
.....
.....
. 3 Governor Spring
.....

.....
6 Ignition

.....
6 Intake Manifold

.....
. 3 Kit - Carburetor Overhaul

. . . 4 Lubrication . .

.....
..... 3 Operator's Manual . .

.....
..... 2 Piston, Rings, Connecting Rod

. . . 2 Valves

. . . 3 Warning Label

..... 2 PRINTED IN U.S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

31A600 1058 OPERATOR'S MANUAL 29 32 1319 WARNING LABEL 28 27 REQUIRED when replacing parts with warning labels affixed. 43 11 25 27 10 584 850 9 26 306 1264 1263 307 1 23 358 ENGINE GASKET SET 3 12 883 943 7 20 51 9 524 51A 4 617 4A 552 691 842 868 1022 1266 16 46 45 24 1017 146 357 718 691 15 12 12 1032 741 758 22 1270 757 759 20 20 415 Illustrations cover a range of engines. @@@@ Parts shown without corresponding text may not be used on your specific engine. 3735-4 Assemblies include all parts shown in frames. 4 11/09/2007 31A600 304 968 1040 1267 305A 643 967 305 445 1036 EMISSIONS LABEL 74 1005A 73 73A 415A 823 1070 1070A 1005B 1005 1044 78 37 363 23 1051 783 864 883 300 883 613B 823 81 613 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3735-5 Assemblies include all parts shown in frames. 5 11/09/2007 31A600 DC ONLY 474 877A 1059 DUAL CIRCUIT 474A 877 877B 1059 474B TRI CIRCUIT 1059 5/9 AMP REGULATED 578 878 878A 501A 526A NOTE: All stators use a No. 1119 mounting screw. NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output.

See repair instruction manual for additional information. 334 333 309 1051 510 783 513 803 1090 462 579 797 802 216 311 310 616 404 227 505 614 562 202 232 601 187A 601 240 240A 268 269 270 271 222 209 559 267 265 1054 801 729A 697 544 356 851 729 789A 789 503 188 521 187 958 187B 601 601A 918 385 387 385A 387A 788 431 1266A 601 385 1266 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3735-6 Assemblies include all parts shown in frames. 6 11/09/2007 31A600 REF.

NO. 1 2 3 4 4A 5 7 9 PART NO. DESCRIPTION REF. NO. 23 PART NO.

DESCRIPTION REF. NO. 50 50A PART NO. DESCRIPTION 793987 Cylinder Assembly 399265 Kit-Bushing/Seal (Magneto Side) K391086S Seal-Oil (Magneto Side) 697106 Sump-Engine 697188 Sump-Engine Used on Type No(s). 0036, 0119, 0128. 793989 Head-Cylinder K699168 Gasket-Cylinder Head K697109 Gasket-Breather (Used Before Code Date 07071900). (After Date Code Use Liquid Sealant Reference 850) 697157 Screw (Breather Assembly) 794683 Tube-Breather (Used After Code Date 07071800). ----- Note ----- 697113 Tube-Breather (Used Before Code Date 07071900). K697110 Gasket-Crankcase (.015" Thick) (Standard) 793988 Screw (Cylinder Head) (Used After Code Date 07011400).

----- Note ----- 690360 Screw (Cylinder Head) (Used Before Code Date 07011500). @@0113, 0119, 0120, 0124, 0125, 0138, 0458, 0470, 0508, 0740, 0741.

----- Note ----- 693556 Flywheel Used on Type No(s). @@@@0026G1, 0036G1. @@@@73A 794437 Screen-Rotating (Used After Code Date 07040800).

@@0026, 0036. @@No. 358. D Included in Carburetor Overhaul Kit-Ref. No.

121 or 121A. z Illustrations cover a range of engines. @@No. 977. Included in Valve Gasket Set-Ref.

No. 1095. 3735-7 Assemblies include all parts shown in frames. 7 11/09/2007 31A600 REF. NO.

108 108B 117 PART NO. DESCRIPTION REF. NO. 142 146 186 187 PART NO. DESCRIPTION REF. NO. 216 222 227 232 238 240 PART NO.

@@@@0026G1, 0036G1. @@0026, 0036, 0119, 0120, 0458, 0740, 0741, 0786. ----- Note ----- 260902 Spring- Governor Used on Type No(s).

0508. 690576 Spring- Governor Used on Type No(s). 0111, 0113, 0116, 0123, 0124, 0128, 0132, 0138, 0470. 691795 Spring- Governor Used on Type No(s). 0014, 0115, 0117, 0118, 0125, 0126, 0127, 0137. @@@@0026, 0036, 0113, 0115, 0117, 0123, 0126, 0128, 0132, 0137. @@@@No.358. D Included in Carburetor Overhaul Kit-Ref. No.

121 or 121A. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref.

No 1095. Illustrations cover a range of engines. @@8 11/09/2007 31A600 REF. NO. 304 PART NO.

DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. 474A PART NO. DESCRIPTION 698402 Housing-Blower (Red) Used on Type No(s). 0111, 0113, 0116, 0117, 0118, 0119, 0120, 0124, 0125, 0126, 0127, 0137, 0138, 0458, 0470, 0508, 0740, 0741, 0786. ----- Note ----- 698599 Housing- Blower (Black) Used on Type No(s). 0026, 0036, 0114, 0115, 0123, 0128, 0132.

697102 Screw (Blower Housing) 793376 Screw (Blower Housing)(Lift Screw) 697107 Shield-Cylinder 691003 Screw (Cylinder Shield) 693551 Motor-Starter Used on Type No(s). 0026, 0036, 0111, 0116, 0117, 0118, 0119, 0120, 0123, 0124, 0125, 0126, 0127, 0128, 0132, 0137, 0138, 0458, 0470, 0508, 0740, 0741, 0786. ----- Note ----- 693552 Motor-Starter Used on Type No(s). 0113, 0114, 0115. 690323 Screw (Starter Motor) ----- Note ----- 691263 Screw (Starter Motor) Used on Type No(s). 0113, 0114, 0115. 497608 Brush Set 795315 Armature-Magneto 691061 Screw (Magneto Armature) 337 491055S Plug-Spark Used on Type No(s). 0119, 0458, 0741. ----- Note ----- 691043 Plug-Spark Used on Type No(s). 0026, 0036, 0111, 0113, 0114, 0115, 0116, 0117, 0118, 0120, 0123, 0124, 0126, 0127, 0128, 0132, 0137, 0740, 0786.

792015 Plug-Spark Used on Type No(s). 0125, 0138, 0470, 0508. 344 693675 Screw (Cable Clamp) 356 697089 Wire-Stop 357 691483 Key-Drive Pulley 358 794150 Gasket Set-Engine 363 19203 Puller-Flywheel 383 89838S Wrench-Spark Plug 385 694476 Screw (Fuel Pump) 385A 690297 Screw (Fuel Pump) 387 697090 Pump-Fuel 387A 808656 Pump-Fuel 404 691691 Washer (Governor Cr 616 617 634 634B 635 643 654 691 697 718 729 729A 741 750 757 758 759 783 788 789 789A 797 801 802 823 698941 552 559 830 842 847 691095 K691031 790442 562 578 579 584 K Included in Engine Gasket Set-Ref.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 31A600 TO 31A699 user guide](http://yourpdfguides.com/dref/3639807)

<http://yourpdfguides.com/dref/3639807>

No.358.

D Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A. z Included in Carburetor Gasket Set-Ref. No.

977. Included in Valve Gasket Set-Ref. No 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 3735-10 Assemblies include all parts shown in frames. 10 11/09/2007 31A600 REF. NO. 850 PART NO. DESCRIPTION REF.

NO. 975 975A 977 987 987A 1005 1005A 1005B PART NO. 495933 699502 690192 D691326 D698777 794438 794436 DESCRIPTION Bowl-Float Bowl-Float Gasket Set-Carburetor Seal-Throttle Shaft Seal-Throttle Shaft Fan-Flywheel (Used After Code Date 07040800). Fan-Flywheel (Used Before Code Date 07040900). Fan-Flywheel (No Longer Available) (See Reference1005A For Service Flywheel Fan). Screen-Oil Pump Gasket-Rocker Cover (Used Before Code Date 07091000). (After Date Code Use liquid Sealant Reference 850) Cover-Rocker Pump-Oil (Used Before Code Date 07051700). Pump-Oil (Used After Code Date 07051600). Rod-Push (Intake) ----- Note ----- 692011 Rod-Push (Exhaust) Filter-Oil Arm-Rocker Ball-Oil Pump Guide-Push Rod Label-Emissions (Available From A Briggs & Stratton Authorized Dealer) REF. NO.

1040 1044 1054 1051 1058 PART NO. DESCRIPTION 100100 Sealant-Liquid (Rocker Cover Gasket and Breather Gasket) (Used After Code Date 07071800). 692424 Terminal-Spark Plug 697346 Adapter-Muffler Used on Type No(s). 0026, 0036. @@0111, 0116, 0117, 0118, 0123, 0128, 0132. @@@@690363 Screw (Flywheel Fan) (Used After Code Date 07040800). 691293 Retainer-Brush 691333 Cap-Limiter 690190 Gasket Set-Valve 691183 Screw (Alternator) 697124 Reed-Breather 697104 Screw (Breather Reed) KD691917 Seal-O Ring (Intake Elbow) D697123 Seal-O Ring (Intake Elbow) 697419 Latch-Blower Housing 697156 Plug-AVS Counterweight 794467 Label-Warning 851 864 868 877 877A 877B 878 878A 883 914 918 943 947 947A 958 1017 690770 1022K272475S 1059 1070 1070A 1023 1024 1024A 1026 791079 499054 794644 692003 1090 1091 1095 1119 1263 1264 1266 1266A 1267 1270 1319 965 967 968 1027 492932S 1029 691751 1032 491710 1034 690822 1036 K Included in Engine Gasket Set-Ref. No. 358. D Included in Carburetor Overhaul Kit-Ref.

No. 121 or 121A. z Illustrations cover a range of engines. @@No. 977. Included in Valve Gasket Set-Ref. No. 1095. 3735-11 Assemblies include all parts shown in frames. 11 11/09/2007 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 31A600 TO 31A699 user guide](http://yourpdfguides.com/dref/3639807)
<http://yourpdfguides.com/dref/3639807>