



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 402707. You'll find the answers to all your questions on the BRIGGS & STRATTON 402707 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 402707
User guide BRIGGS & STRATTON 402707
Operating instructions BRIGGS & STRATTON 402707
Instructions for use BRIGGS & STRATTON 402707
Instruction manual BRIGGS & STRATTON 402707

FORM MS 8475-695
REPLACES FORM MS 8475-1094
FILE IN SECT 2 OF SERVICE MANUAL
402700 to 402799

Illustrated Parts List
Industrial/Commercial
Model Series
402700 to 402799

TYPE NUMBERS
1115 through 1117,
1200 through 1228,
1232, 1233, 1235,
1239 through 1246,
1270, 1272, 1280,
1401, 1500, 1502,
1505 through 1509,
1511, 4001, 7017.

TO FIND
THE CORRECT NUMBER OF THE PART YOU NEED:
FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate part identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT©



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 402707 user guide](http://yourpdfguides.com/dref/3639960)
<http://yourpdfguides.com/dref/3639960>

Manual abstract:

2 OF SERVICE MANUAL 402700 to 402799 Illustrated Parts List Industrial/Commercial Model Series 402700 to 402799 TYPE NUMBERS 1115 through 1117, 1200 through 1228, 1232, 1233, 1235, 1239 through 1246, 1270, 1272, 1280, 1401, 1500, 1502, 1505 through 1509, 1511, 4001, 7017. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number.

Assemblies include all parts shown in frames.

All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."

" If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number. @@NO. @@DESCRIPTION Cylinder Assembly See Last Pages. @@@ScrewHex. TubeBreather ScrewHex.

PlugPipe (1/827) (Impulse Pump Hole) REF. NO. 22 244 337 881 5A 13 7A 337 520 985 383 1019 LABEL KIT 1058 OWNER'S MANUAL PART NO. DESCRIPTION REF. NO. 569 572 635 869 870 871 524 9 847 354 9 354 353 635 REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. PART NO. DESCRIPTION 506 10 572 353 354 383 506 507 520 523 9 10 10A 11 13 15A K27803 94382 94830 280225 94565 94497 524 525 93882 ScrewHex. 230318 ConnectorFuel Line (Impulse Pump) 802592 PlugSpark Note 394539 PlugSpark (2 3/8" High, 62 mm) 92791 WasherLock 90576 NutHex.

89838 WrenchSpark Plug 231174 Terminal 280180 Insulator 93722 Terminal 494947 CapOil Fill (Used Before Code Date 92071900). K271157 SealFill Tube 495348 TubeOil Fill (Used After Code Date 92071900). Note 280224 TubeOil Fill (Used Before Code Date 92072000). 881 985 1019 1058 842 847 K272062 GasketBase BaffleAir See Last Pages. 66538 BootSpark Plug 261463 SeatValve (Intake) 213316 SeatValve (Exhaust) 261961 BushingGuide (Exhaust Valve) Note 231218 Bushing Guide (Brass) (Intake Valve) 222860 CoverCrankcase 398525 Insulator 491261 Label Kit 272112 Owner's Manual SealCap See Last Pages. Dipstick and Tube Assembly See Last Pages. K Included in Gasket SetPart No. 491856. D Included in Carburetor KitPart No. 491539.

H Included in Pump Repair KitPart No. 393397. 94792 Assemblies include all parts shown in frames. 2 65 402700 to 402799 24 16 615 634 552A 615 552 45 616 741 32 230 46 26 219A 220 REF. NO.

16 24 25 222698 394955 PART NO. REF. NO. PART NO. 40 42 41 36 868 35 34 33 219 29 819 120 31 27 27 28 DESCRIPTION REF. NO. 34 35 36 40 41 42 45 46 120 219 219A 220 230 552 552A 615 616 634 741 819 868 25 PART NO. 261528 65906 26828 221596 292260 93630 261368 213520 92290 393415 394348 222773 223882 262332 262331 94296 491530 K491287 262694 94675 393606 DESCRIPTION ValveIntake SpringValve SpringValve RetainerValve RetainerValve KeeperValve TappetValve GearCam WasherLock SlingerOil GearGovernor WasherThrust Washer Lower Bushing-Gov. Upper Bushing Gov. RetainerE-Ring CrankGovernor SealGovernor Shaft GearTiming ScrewHex. SealValve DESCRIPTION Crankshaft See Last Pages. KeyFlywheel Piston Assy. (Std.) 394956 Piston Assy. (.

010" O.S.) 394957 Piston Assy. (.020" O.S.) 394958 Piston Assy. (.030" O.S.
) Ring Set (Std.) 394960 Ring Set (.010" O.S.) 394961 Ring Set (.
020" O.S.) 394962 Ring Set (.030" O.S.

) LockPiston Pin PinPiston (Standard) 391286 PinPiston (.005" O.S.) RodConnecting (Standard) 393714 Rod Connecting (.020" Undersize) 31 26 394959 32 27 28 260924 299691 33 29 393270 Note 492667 RodConn. Used on Model Series 402777. 492911 RodConn. (.020" Undersize) Used on Model Series 402777. 220863 Washer (Used Before Code Date 92083100).

94671 ScrewHex. (Used After Code Date 92083000). Note 92909 ScrewHex. (Used Before Code Date 92083100). 390420 ValveExhaust Note 390419 Valve-Exhaust Used on Type No(s). 1500, 1502, 1505, 1506, 1507, 1508, 1509, 1511, 7017. K Included in Gasket SetPart No. 491856. D Included in Carburetor Kit-Part No. 491539.

H Included in Pump Repair KitPart No. 393397. 94793 Assemblies include all parts shown in frames. 3 65 402700 to 402799 982 1027 239 84 1032 1028 615A 116 12 19 12 20 19 20 243 979 819A 84 978 21 524A REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. 615A 1035 1024 15 18 REF. NO. 12 PART NO. REF. NO.

84 116 239 243 524A 615A 653 18A PART NO. 91488 K280801 491657 491722 K271485 94400 93585 15 REF. NO. 982 1024 1027 1028 PART NO. 94362 492196 491056 491721 653 DESCRIPTION DESCRIPTION DESCRIPTION 15 18 18A 19 21 20 K271703 GasketCrankcase (.015" Thick) K271188 Gasket Crankcase (.005" Thick) K271189 Gasket Crankcase (.009" Thick) 94239 PlugOil Drain Note 94613 Plug-Pipe (Hex. Socket Head) 493304 SumpEngine 492575 SumpEngine 399264 Bushing 399195 PlugOil Fill K291675 SealOil 819A 978 979 PlugPipe SealO-Ring SwitchOil Pressure ScreenOil Pump Seal-Plug RingOil Pump ScrewHex. Note 93730 Stud 90366 WasherLock 22963 Washer Used on Type No(s).

1212, 1223, 1511. 94410 Screw K272060 Gasket 492197 CoverOil Pump 1032 1035 ScrewSocket Pump-Oil FilterOil AdapterOil Filter Note 492675 Adapter Filter (Remote) Use(s): 492061 Filter Kit (Remote) (18" Hose) Or 492062 Filter Kit (Remote) (30" Hose) 491710 SpringCompression 492589 Shaft-Pump K Included in Gasket SetPart No.



You're reading an excerpt. Click here to read official BRIGGS & STRATTON 402707 user guide
<http://yourpdfguides.com/dref/3639960>

491856. D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. 393397. 94794 Assemblies include all parts shown in frames. 4 65 402700 to 402799 90 119 109 102 104 95 97 99 391 860 634A 860 394 432 435 434 858 392 117 REF. NO. 91 108 95 105 51 51A 51 52 205 REQUIRES SPECIAL TOOLS TO INSTALL. @@@@ @@@@ PlugWelch Link See Last Pages. 54 947 257 REF. NO. @@@@ ScrewHex.

SpringLink ScrewSlotted Hex. @@@@ @@@@ @@@@ 102 D271607 GasketCarb. @@@@ 491856. D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. @@@@ NO. 161 161A 165 187 PART NO. 496599 398826 94289 299146 REF. NO. PART NO. REF. NO. 642 642A 643 643A 725 PART NO. @@@@ @@@@ 491856.

D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. @@@@ NO. 201 PART NO. REF. NO. 229 258 259 265 265A 267 268 PART NO. 222289 94623 223890 221535 22372 93496 65616 REF. NO. @@@@ BracketCable ClampCasing ClampCasing ScrewHex. @@@@ @@@@ 490207 CrankBell 94298 NutSquare 262337 SpringControl Rod SpringGovernor See Last Pages. 261563 SpringGovernor Idle 262375 Link 491282 BracketControl 94297 ScrewTorxR 491297 LeverGovernor 270 271 284A 414 422 562 592 26633 WireControl (78" Long) Note If Longer Wire is Required, Specify Length in Inches; if Shorter Wire is Needed, Order and Cut to Required Length. (72& Set 221798 TerminalCable 393422 HarnessAlternator 394970 MagnetronR Ignition Kit 281053 FanFlywheel 224413 RetainerFan K Included in Gasket SetPart No. 491856.

D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. 393397. 947910 Assemblies include all parts shown in frames. 10 65 402700 to 402799 DC ONLY SEE FLYWHEEL ASSEMBLY DUAL CIRCUIT SEE FLYWHEEL ASSEMBLY TRICIRCUIT SEE FLYWHEEL ASSEMBLY 16 AMP SEE NOTE UNDER FLYWHEEL ASSEMBLY 474B 877A 9 AMP SEE NOTE UNDER FLYWHEEL ASSEMBLY 474A 887 877B 877 474 877A 474A 878A 878 814 878A 814 501A 501 NOTE: ALL STATORS USE NO. 482 MOUNTING SCREW. 526A 878B REF. NO. 474 474A 474B 482 501 PART NO. 393474 392595 393295 93621 394890 DESCRIPTION Alternator Alternator ScrewHex. Regulator REF. NO. 501A 526A 814 877 877A PART NO. 491546 94137 392606 393456 393537 DESCRIPTION Regulator ScrewHex.

HarnessAlternator WireAlternator WireAlternator REF. NO. 877B 878 878A 878B 887 PART NO. 393814 393362 393422 399916 391529 DESCRIPTION WireAlternator HarnessAlternator HarnessAlternator HarnessAlternator Alternator K Included in Gasket SetPart No. 491856. D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. 393397. 947911 Assemblies include all parts shown in frames. 11 65 402700 to 402799 510 801 783 309 615 802 653 311 803 310 544 1090 REF. NO. 309 310 311 510 PART NO. 497596 94003 497608 497606 DESCRIPTION MotorStarter ScrewHex. Brush Set DriveStarter REF. NO. 544 615 653 783 PART NO. 497603 263080 93585 280104 DESCRIPTION ArmatureStarter Retainer ScrewHex. GearStarter REF. NO. 801 802 803 1090 PART NO. 394860 497607 497604 497605 DESCRIPTION CapDrive CapEnd HousingStarter RetainerBrush K Included in Gasket SetPart No. 491856. D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. 393397. 947912 Assemblies include all parts shown in frames. 12 65 402700 to 402799 309A 801 510A 189 876 653 802A 783 513 803A 896 311A 1003 310 544A REF. NO.

189 309A PART NO. REF. NO. PART NO. REF. NO. PART NO. DESCRIPTION DESCRIPTION 492020 Brush Set (For 315/32" Length) DriveStarter Clutch Drive ArmatureStarter (For 35/8" Length) 490309 Armature Starter (For 41/2" and 43/8" Length) ScrewHex. GearStarter CapDrive CapEnd (For 35/8" Length) 490310 CapEnd (For 41/2" Length) DESCRIPTION 492022 CapEnd (For 315/32" Length) 494988 CapEnd (For 43/8" Length) HousingStarter (For 35/8" Length) 398892 Hsg.Starter (For 41/2" Length) 494205 Hsg. Starter (For 43/8" Length) KitGear PinRoll (Black) 94288 PinRoll (Copper) SpringBrush (For 41/2" Length) 310 311A 90366 WasherLock 394808 Motor-Starter (For 35/8" and 315/32" Length) 399928 MotorStarter (For 41/2" Length) 495100 MotorStarter (For 43/8" Length) 94003 ScrewHex. (For 35/8" Length) 94169 ScrewHex. (For 41/2" Length) 94004 ScrewHex. (For 43/8" Length) 395538 Brush Set (For 35/8" Length) 490311 Brush Set (For 41/2" Length) 510A 513 544A 490421 398003 390837 803A 398159 653 783 801 802A 93585 280104 394860 395537 876 896 490467 94192 1003 490316 K Included in Gasket SetPart No. 491856.

D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. 393397. 947913 Assemblies include all parts shown in frames. 13 65 402700 to 402799 524 524A 883A 9 569 883 51 52 537 978 7A 7 104 118 432 358 GASKET SET 392 51 3 20 116A 116 12 634A 842 392 432 860 105 860 127 394 858 859 394 858 861 PUMP REPAIR KIT 634 121 CARBURETOR KIT REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL. 859 102 REF. NO. 3 7 7A 9 12 PART NO. K391086 K271867 K271868 K27803 K271703 DESCRIPTION SealOil GasketCyl. Head #1 GasketCyl. Head #2 GasketBreather GasketCrankcase (.015" Thick) K271188 Gasket Crankcase (.005" Thick) K271189 Gasket Crankcase (.009" Thick) SealOil GasketIntake GasketIntake GasketCarburetor Body (Used After Code Date 93063000). REF. NO. PART NO. @@@@ PinFloat Hinge Valve-Needle SealO-Ring SealO-Ring ValveIdle Adjustment Carburetor Kit PlugWelch Gasket Set SpringDiaphragm DiaphragmCarburetor CapSpring SealFill Tube SealPlug REF. NO. PART NO. DESCRIPTION 20 K291675 51 KD271412 52 K270884 102 D271607 104 D230896 105 D394683 116 K280801 116A K280474 118 D491538 121 491539 127 D223472 358 495868 392 DH261395 394 DH272638 432 DH221377 524 K271157 524A K271485 537 KD271411 GasketAir Cleaner 569 K272062 GasketBase 634 K491287 SealGovernor Shaft 634A D271013 WasherFoam 842 K270920 SealCap (Used After Code Date 92071900). Note K271170 SealCap (Used Before Code Date 92072000). 858 DH270989 Diaphragm Carburetor 859 DH271025 GasketPump 860 DH261358 SpringDiaphragm 861 393397 KitPump Repair 883 K272250 GasketExhaust 883A K272293 GasketExhaust 978 K272060 Gasket K Included in Gasket SetPart No.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 402707 user guide](http://yourpdfguides.com/dref/3639960)
<http://yourpdfguides.com/dref/3639960>

491856. D Included in Carburetor KitPart No. 491539. H Included in Pump Repair KitPart No. 393397.

947914 Assemblies include all parts shown in frames. 14 65 402700 to 402799 REF. NO. 1 PART NO. DESCRIPTION REF.

NO. 203 PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 497074 Cylinder Assembly (Used After Code Date 91080400). Note 492438
Cylinder Assy. Used on Model Series 402777. @@94196. 393523 Crankshaft Used on Type No(s).

1116. 493236 Crankshaft Used on Type No(s). 1221, 1223, 1224, 1232, 1239, 1245, 1272. 262684 Link (Used After Code Date 89120300). @@280997 Crank-
Bell (Used After Code Date 89120300). @@@@Used on Type No(s). 1205, 1212, 1215, 1217, 1218, 1220, 1221, 1223, 1225, 1228, 1232, 1239, 1240, 1244,
1245, 1246, 1270, 1272, 1511. 262354 SpringGov. Used on Type No(s). 1227, 1508.

262441 SpringGov. Used on Type No(s). 1207, 1210, 1233, 1235, 1280, 1509. 224816 BaffleAir (Cyl. #2) (Used After Code Date 94041000).

Note 224580 BaffleAir (Cyl. #2) (Used Before Code Date 94041100 and After Code Date 91080400). 224362 BaffleAir (Cyl. #2) (Used Before Code Date
91080500). K270920 SealCap (Used After Code Date 92071900).

Note 271170 SealCap (Used Before Code Date 92072000). 495715 Dipstick and Tube Assembly (Used After Code Date 92071900). Note 394394 Dipstick
and Tube Assembly (Used Before Code Date 92072000). 16 209 842 847 202 572 K Included in Gasket SetPart No. 491856. D Included in Carburetor Kit-
Part No. 491539. H Included in Carburetor KitPart No. 491539 and Pump Repair KitPart No. 393397.

947915 Assemblies include all parts shown in frames. 15 65 .



[You're reading an excerpt. Click here to read official BRIGGS &
STRATTON 402707 user guide
http://yourpdfguides.com/dref/3639960](http://yourpdfguides.com/dref/3639960)