



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 99772. You'll find the answers to all your questions on the BRIGGS & STRATTON 99772 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BRIGGS & STRATTON 99772**  
**User guide BRIGGS & STRATTON 99772**  
**Operating instructions BRIGGS & STRATTON 99772**  
**Instructions for use BRIGGS & STRATTON 99772**  
**Instruction manual BRIGGS & STRATTON 99772**

FORM MS-2918-697  
REPLACES FORM MS-2938-397  
FIELD SELECT POP SERVICE MANUAL  
**99700 to 99799**

## Illustrated Parts List Model Series 99700 to 99799

TYPE NUMBERS  
0100 through 0103,  
0110 through 0118,  
0901, 0905,  
0610, 0611, 0612,  
0614, 0615,  
0618 through 0626,  
0630 through 0636,  
0814 through 0826,  
0916, 0918, 0920,  
0925, 0932, 0934,  
0935, 0937, 0938,  
0942, 0945, 0950,  
0951, 0953.

TYPE NUMBERS  
3015, 3016,  
3024, 3025, 3026,  
3101, 3102, 3103,  
3111 through 3120,  
3141, 3142, 3143,  
3515, 3525, 3601,  
3608 through 3613,  
3616, 3617, 3620,  
3624, 3625, 3641,  
3642, 3643, 3650.

### TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- Refer to the Illustrations and compare the original part with illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



PRINTED IN U.S.A.  
COPYRIGHT BY BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 99772 user guide](#)  
<http://yourpdfguides.com/dref/3640166>

**Manual abstract:**

2 OF SERVICE MANUAL 99700 to 99799 Illustrated Parts List Model Series 99700 to 99799 TYPE NUMBERS 0100 through 0103, 0110 through 0118, 0601, 0606, 0610, 0611, 0612, 0614, 0615, 0618 through 0626, 0630 through 0638, 0814 through 0826, 0916, 0918, 0920, 0925, 0932, 0934, 0935, 0937, 0938, 0942, 0945, 0950, 0951, 0953, TYPE NUMBERS 3015, 3016, 3024, 3025, 3026, 3101, 3102, 3103, 3111 through 3120, 3141, 3142, 3143, 3515, 3525, 3601, 3608 through 3613, 3616, 3617, 3620, 3624, 3625, 3641, 3642, 3643, 3650. TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE." If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. @@@@COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved.

@@@NO. 13 33 34 35 40 45 122 192 238 294 307 337 383 584 585 PART NO. 94547 493778 493777 262716 262552 262679 281193 492160 262499 810104 94515 491055 19374 224328 K272238 DESCRIPTION ScrewHex. ValveExhaust ValveIntake SpringValve RetainerValve TappetValve Spacer-Carburetor NutRocker Arm CapValve ScrewTorx ScrewHex. PlugSpark WrenchSpark Plug BaffleCylinder GasketBreather Passage REF. NO. 635 718 830 868 868A 871 883 1019 1022 1023 1026 1029 1034 1058 PART NO. 66538 230192 94555 K495773 K272376 262718 K272313 495337 K272323 224588 493527 224111 224400 273123 DESCRIPTION BootSpark Plug DowelSleeve StudRocker Arm SealValve SealValve BushingGuide Gasket-Exhaust Label Kit GasketRocker Cover CoverRocker RodPush ArmRocker GuidePush Rod Owner's Manual 718 1019 LABEL KIT REF. NO. 1 2 3 5 PART NO. 494728 293708 K299819 496054 DESCRIPTION Cylinder Assembly Bushing SealOil HeadCylinder (Used After Code Date 92080400). Note 494726 HeadCylinder (Used Before Code Date 92080500). GasketCylinder Head Breather Assembly GasketBreather ScrewHex. TubeBreather 7 K272314 8 495786 9 K272481 10 94650 11 231933 K Included in Gasket SetSee Ref. No.

358. Included in Valve Overhaul KitSee Ref. No. 1033. z Included in Carburetor Gasket SetPart No. 490937. D Included in Carburetor KitSee Ref. No. 121. 25182 Assemblies include all parts shown in frames.

2 67 99700 to 99799 847 523 28 116A 284 27 27 25 525 26 27 1024 377 116B 43 979 116 15 346 REF. NO. 4 12 15 16 20 22 PART NO. REF. NO. PART NO. 29 32 615 230 227 562 592 16 741 146 4 12 616 46 22 20 REF. NO. 346 377 523 525 562 592 615 616 PART NO. 94513 93065 495264 495265 92613 231082 94474 263175 DESCRIPTION DESCRIPTION 495270 Ring Set (0.

020 O.S.) 495272 Ring Set (0.030 O.S.) LockPiston Pin PinPiston (Standard) RodConnecting (Standard) 493689 RodConn. (.020" Undersize) Screw-Connecting Rod Governor/Oil Slinger GearCam SealO Ring SealO Ring SealO Ring KeyTiming LeverGovernor Washer ScrewShoulder DESCRIPTION ScrewHex. KeyWoodruff Dipstick TubeOil Fill BoltGovernor Lever NutHex. @@@@One Used in Hole Nearest Breather.

493781 Piston Assembly (Standard) 495267 Piston Assy. (0.010 O.S.) 495269 Piston Assy. (0.020 O.S.) 495271 Piston Assy. @@No.

358. Included in Valve Overhaul KitSee Ref. No. 1033. z Included in Carburetor Gasket SetPart No.

490937. D Included in Carburetor KitSee Ref. No. 121. 25183 Assemblies include all parts shown in frames.

@@@NO. 94 PART NO. DESCRIPTION REF. @496495 JetMain (High Altitude) (Used Before Code Date 94112100). ScrewShoulder Carburetor (Used After Code Date 94112000). 494971 Carburetor (Used Before Code Date 94112100). @@@@One Used in Hole Nearest Breather. 358. Included in Valve Overhaul KitSee Ref.

No. 1033. z Included in Carburetor Gasket SetPart No. 490937. D Included in Carburetor KitSee Ref. No. 121. 25184 Assemblies include all parts shown in frames. @@@NO. 11A PART NO.

DESCRIPTION REF. NO. 236 258 265 265A 267 268 PART NO. @@ClampCasing ClampCasing ScrewSlotted Hex. @@FilterAir REF.

NO. 467 535 620 621 642 922 923 935 PART NO. @@@@One Used in Hole Nearest Breather. 358. Included in Valve Overhaul KitSee Ref.

No. 1033. z Included in Carburetor Gasket SetPart No. 490937. D Included in Carburetor KitSee Ref. No. 121. 25185 Assemblies include all parts shown in frames. 5 67 99700 to 99799 38 37 304 527 37A 24 23 346 334 333 258 851 474 356 305 1036 LABEL KITEMISSION REF. NO.

23 23A PART NO. DESCRIPTION REF. NO. 333 334 346 346A 356 PART NO. 802574 94731 94513 94582 398808 DESCRIPTION ArmatureMagneto ScrewHex. ScrewHex. ScrewHex. WireStop Note 496381 WireStop (Used After Code Date 93080300). 398153 WireStop (Used Before Code Date 93080400). Used on Type No(s).

0110, 0610, 3111, 3611, 3624. 496721 WireStop Used on Type No(s). 0625. Flywheel Puller CupFlywheel Alternator ClampTube REF. NO. 789 PART NO. DESCRIPTION 363 332 455 346A 789A 23A 789 24 37 37A 38 258 304 305 332 492177 Flywheel 492175 Flywheel Note 492893 Flywheel Used on Type No(s). 0625, 0626, 0636, 0925. 222698 KeyFlywheel 224511 GuardFlywheel 281206 GuardFlywheel 94786 ScrewHex. 94512 ScrewSlotted Hex.

494961 HousingBlower Used on Engines With Band Brake. Note 494962 Housing Blower Used on Engines Without Band Brake. 94510 StudStator Mounting 92284 NutFlywheel 789A 851 1036 363 455 474 527 19069 225121 492841 224722 494543 HarnessWiring Used on Engines Without Band Brake. 494544 HarnessWiring Used on Engines With Band Brake Except as Listed Below: Note 493380 Harness Wiring Used on Type No(s). 0916, 3616.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 99772 user guide](http://yourpdfguides.com/dref/3640166)  
<http://yourpdfguides.com/dref/3640166>

493880 TerminalCable 499335 Label KitEmission Used on Type No(s). 0814, 0815, 0816, 0824, 0825, 0826, 0916, 0918, 0920, 0925, 0932, 0934, 0935, 0937, 0938, 0942, 0945, 0950, 0951. K Included in Gasket SetSee Ref. No. 358.

Included in Valve Overhaul KitSee Ref. No. 1033. z Included in Carburetor Gasket SetPart No. 490937. D Included in Carburetor KitSee Ref. No. 121. 25186 Assemblies include all parts shown in frames. 6 67 99700 to 99799 300 346 930 883 65 181A 972 181 284 188 832 670 346 994 187 199 346B 601 REF. NO. 65 181 181A 187 PART NO. 94058 397974 494277 296004 DESCRIPTION REF. NO. 199 284 300 346 346B 601 PART NO.

494768 94511 494717 94513 93705 93053 DESCRIPTION ValveShut Off ScrewShoulder MufflerExhaust ScrewHex. ScrewHex. ClampHose REF. NO. PART NO.

DESCRIPTION 188 ScrewHex. @@No. 358. IncludedKit Only) SealORing SealORing SealORing Carburetor Kit (Used After Code Date 94112000). 493762 Carburetor Kit (Used Before Code Date 94112100). @@No. 358. Included in Valve Overhaul KitSee Ref. No. 1033.

z Included in Carburetor Gasket SetPart No. 490937. D Included in Carburetor KitSee Ref. No. 121. 251811 Assemblies include all parts shown in frames. 11 67 99700 to 99799 REF. NO. 16 PART NO. DESCRIPTION REF.

NO. PART NO. DESCRIPTION REF. NO. PART NO.

DESCRIPTION 262659 Spring Governor Used on Type No(s). @262660 Spring Governor Used on Type No(s). 3143, 3643. 262661 Spring Governor Used on Type No(s). 0638, 0938, 0950.

262665 Spring Governor Used on Type No(s). 0115, 0615, 0637, 0937,3112, 3113, 3612, 3613. 262666 Spring Governor Used on Type No(s). 0116, 0619, 0622. 262667 Spring Governor Used on Type No(s). 0633, 0916, 0920, 3120, 3616, 3620. @0638, 0938. 497334 Crankshaft Used on Type No(s). 0118, 3025, 3111. 494637 Crankshaft Used on Type No(s).

0100, 0102, 0103, 0112, 0116, 3015, 3101, 3103, 3120, 3143. 494639 Crankshaft Used on Type No(s). 0110, 0111, 0115, 3026. 495515 Crankshaft Used on Type No(s). 0623. 495793 Crankshaft Used on Type No(s). 0618, 0622, 0633, 0825, 0918, 0945, 0950, 0951, 0953, 3525, 3611, 3617, 3624, 3625. 495794 Crankshaft Used on Type No(s). 0824, 3641. 495795 Crankshaft Used on Type No(s).

0612, 0625, 0626, 0630, 0636, 0815, 0916, 0920, 0925, 0935, 0942, 3515, 3601, 3608, 3616, 3620, 3642, 3643. 495796 Crankshaft Used on Type No(s). 0601, 0606, 0614, 0619, 0621, 0632, 0634, 0814, 0816, 0932, 0934, 3612, 3613, 3650. 495797 Crankshaft Used on Type No(s). 0610, 0611, 0615, 0624, 0637, 0826, 0937.

262678 SpringGovernor Note 262657 SpringGovernor Used on Type No(s). 0110, 0610, 0625, 0925, 0945, 0951, 0953, 3111, 3611, 3617, 3624, 3625. 209 K Included in Gasket SetSee Ref. No. 358.

Included in Valve Overhaul KitSee Ref. No. 1033. z Included in Carburetor Gasket SetPart No. 490937. D Included in Carburetor KitSee Ref. No. 121. 2518-12 Assemblies include all parts shown in frames. 12 67 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 99772 user guide](http://yourpdfguides.com/dref/3640166)  
<http://yourpdfguides.com/dref/3640166>