



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 9C900 TO 9C999. You'll find the answers to all your questions on the BRIGGS & STRATTON 9C900 TO 9C999 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 9C900 TO 9C999
User guide BRIGGS & STRATTON 9C900 TO 9C999
Operating instructions BRIGGS & STRATTON 9C900 TO 9C999
Instructions for use BRIGGS & STRATTON 9C900 TO 9C999
Instruction manual BRIGGS & STRATTON 9C900 TO 9C999



FORM MS-0979-03/02/2009
REPLACES FORM MS-0979-06/11/2008
FILE IN SECT. 2 OF SERVICE MANUAL
09C900

Illustrated Parts List

Model Series

09C900

TYPE NUMBERS
0304 through 2136.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing/Shrouds	6
Brake	7
Camshaft	3
Carburetor	4
Controls	5
Crankcase Cover/Sump	3
Crankshaft	3
Cylinder	2
Cylinder Head	2
Exhaust System	5
Flywheel	6
Fuel Supply	4
Gasket Set - Engine	2
Gasket Set - Valve	2
Governor Spring	5
Ignition	5
Lubrication	2
Operator's Manual	2
Piston/Rings/Connecting Rod	3
Rewind Starter	7
Warning Label	2



PRINTED IN U.S.A.
COPYRIGHT BY BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 9C900 TO 9C999 user guide](http://yourpdfguides.com/dref/3640191)
<http://yourpdfguides.com/dref/3640191>

Manual abstract:

2 OF SERVICE MANUAL 09C900 Illustrated Parts List Model Series 09C900 TYPE NUMBERS 0304 through 2136. TABLE OF CONTENTS Air Cleaner . . .

.....
.....
.....
..... 5 Blower Housing/Shrouds

..... 6 Brake
.....
.....
.....
..... 7 Camshaft
.....
.....
.....
..... 3 Carburetor
.....
.....
.....
..... 4 Controls
.....
.....
..... 5 Crankcase Cover/Sump

.....
..... 3 Crankshaft
.....
.....
.....
..... 3 Cylinder
.....
.....
.....
..... 2 Cylinder Head
.....
.....
.....
..... 2 Exhaust System
.....
.....
..... 5 Flywheel

.....
.....
..... 6 Fuel Supply
.....

.....
..... 4 Gasket Set - Engine
.....
.....
.....
..... 2 Gasket Set - Valve
.....
..... 2 Governor Spring
.....

..... 5 Ignition
.....
.....
.....

..... 5 Lubrication ..

.....
.....
.....

... 2 Operator's Manual

.....
.....

. 2 Piston/Rings/Connecting Rod 3 Rewind Starter .

.....
.....
.....

. 7 Warning Label

.....
... 2 PRINTED IN U.S.

A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. @@@@4 03/02/2009 09C900 201 209 211 265 265A 265B 267 222 269 188 271 268 270 222A 621 426 356 333 334 24 851 635 536 534 883 300 613 535 81 832 643 836 535A 163 0979-5 Illustrations cover a range of engines. @5 03/02/2009 09C900 326 930 74 73 73B 66 71 70 67 68 75 363 257 23 78 37 304 1036 EMISSIONS LABEL 305 78 37A 0979-6 Illustrations cover a range of engines. @6 03/02/2009 09C900 921A 969A 770 921 969 608A 55 608 55 65 592 57 1211 65 592 1210 1211 56 459 1210 58 689 456 459 689 456 597 332 455 745A 745 668 922 60 597 58A 60 923 621 729 73 304 304A 923A 1208 621 815 305 933 922A 0979-7 Illustrations cover a range of engines.

@7 03/02/2009 09C900 REF. NO. 1 2 3 4 PART NO. DESCRIPTION REF. NO. 16A PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION 699653 Cylinder Assembly 399269 Kit--Bushing/Seal (Magneto Side) 299819S Seal--Oil (Magneto Side) 698691 Sump--Engine (Used After Code Date 02111200).

----- Note -----395384 Sump--Engine (Used Before Code Date 02111300). Sump--Engine (NO LONGER AVAILABLE) Used on Type No(s). 0305. @Used on Type No(s). 2130, 2136. @Used on Type No(s). 2129. 692990 Crankshaft Used on Type No(s). 2033, 2131, 2135. @Used on Type No(s). 2130, 2136. 492748 Crankshaft Used on Type No(s). 0305, 0306, 0330, 0331, 0332, 0333. @0304, 0307, 2104. 793062 Crankshaft (Used Before Code Date 08071400).

Used on Type No(s). 2129. @0305. 23 795549 Flywheel 24 222698S Key--Flywheel 25 790908 Piston Assembly (Standard) (Used After Code Date 04111400). ----- Note -----699657 Piston Assembly (Standard) (Used After Code Date 030803000 and Before Code Date 04111500). @793214 Piston Assembly (Standard) (Used Before Code Date 92092900). @8 03/02/2009 09C900 REF. NO. 26 PART NO. DESCRIPTION REF. NO. 40 43 PART NO. DESCRIPTION REF. NO. 67 PART NO.

@298982 Ring Set (Used Before Code Date 92092900). @691762 Tappet--Valve 691998 Camshaft 690644 Camshaft (Counterclockwise) Used on Type No(s). 0305. 699644 Manifold--Intake (Used After Code Date 03080300). 693446 Manifold--Intake (Used Before Code Date 03080400). 699649 Gasket--Intake (Used After Code Date 03080300). 270345S Gasket--Intake (Used Before Code Date 03080400). 691111 Screw (Intake Manifold) 692144 Housing--Rewind Starter 281336S Pulley--Starter (Used Before Code Date 97120400). Used on Type No(s). 0304, 0305, 0306, 0307, 0330, 0331, 0332, 0333.

490179 Spring--Rewind Starter (Used Before Code Date 97120400). Used on Type No(s). 0304, 0305, 0306, 0307, 0330, 0331, 0332, 0333. 697316 Rope--Starter (88 5/8" Long) 691921 Rope--Starter (70" Long) 691915 Grip--Starter Rope 690837 Screw (Rewind Starter) 399671 Clutch--Starter (Used Before Code Date 97060600). 394897 Housing--Clutch (Used Before Code Date 97060600).

691604 Ball--Clutch (Used Before Code Date 97060600). 691945 Ratchet--Clutch (Used Before Code Date 97060600). 691359 Cover--Ratchet 699850 Screen--Rotating (Used After Code Date 97120500). 691725 Screen--Rotating (Used Before Code Date 97120400). 691627 Screw (Rotating Screen) 691736 Washer (Flywheel) 692198 Screw (Flywheel Guard) 691179 Lock--Muffler Screw 691240 Shaft--Auxiliary Drive Used on Type No(s).

0305. 498809 Carburetor (Used After Code Date 96051900). ----- Note -----494775 Carburetor (Used Before Code Date 96052000). @0305. @9 03/02/2009 09C900 REF. NO. 209 PART NO. DESCRIPTION REF. NO. 268 269 270 271 287 300 304 PART NO.

DESCRIPTION REF. NO. @Used on Type No(s). 0304, 0305, 0306, 0307, 0330, 0331, 0332. @Used on Type No(s). 0304, 0305, 0306, 0307, 0330, 0331, 0332. 690254 Spring--Governor (Light Blue) Used on Type No(s). 0333, 2033, 2104, 2129, 2131, 2135. 691297 Spring--Governor (White) Used on Type No(s). 2130.

690250 Spring--Governor (Light Green) Used on Type No(s). 2136. 691859 Spring--Governed Idle 691446 Bracket--Control 691445 Bracket--Control Used on Type No(s). 2129, 2130, 2136. 691660 Screw (Starter Clutch) 692179 Clamp--Casing Used on Type No(s). 2136. 690798 Clamp--Casing Used on Type No(s). 0304, 0305, 0306, 0330, 0331, 0332, 0333, 2033, 2104, 2130, 2131, 2135. 691024 Clamp--Casing Used on Type No(s). 2129.

@694051 Housing--Blower (Non Compliance Engines) Used on Type No(s). 2129, 2130, 2136. @2129, 2130, 2136. 692390 Wire--Stop 794209 Gasket Set--Engine 19069 Puller--Flywheel 790029 Screw (Carburetor) 691074 Washer (Camshaft) 89838S Wrench--Spark Plug 691839 Spring--Choke Diaphragm 691837 Screen--Carburetor 795083 Diaphragm--Carburetor 691107 Screw (Governor Blade) 691868 Gasket--Drive Gear Cover 691236 Cup--Flywheel 692299 Plate--Pawl Friction 281505S Pawl--Ratchet 692040 Dipstick 691913 Dipstick 691876 Seal--Dipstick Tube 691320 Tube--Dipstick 692189 Grommet 691417 Screw (Air Cleaner) 698369 Filter--Air Cleaner Foam (Used After Code Date 02101000). 272235S Filter--Air Cleaner Foam (Used Before Code Date 02101100). 698472 Cleaner--Air 690800 Nut (Rewind Starter) 691696 Screw (Pawl Fric.

[You're reading an excerpt. Click here to read official BRIGGS &](#)



[STRATTON 9C900 TO 9C999 user guide](http://yourpdfguides.com/dref/3640191)
<http://yourpdfguides.com/dref/3640191>