



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 9D900 TO 9D999. You'll find the answers to all your questions on the BRIGGS & STRATTON 9D900 TO 9D999 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 9D900 TO 9D999  
User guide BRIGGS & STRATTON 9D900 TO 9D999  
Operating instructions BRIGGS & STRATTON 9D900 TO 9D999  
Instructions for use BRIGGS & STRATTON 9D900 TO 9D999  
Instruction manual BRIGGS & STRATTON 9D900 TO 9D999



FORM MS-4864-06/11/2008  
REPLACES FORM MS-4864-06/00/2008  
FILE IN SECT. 2 OF SERVICE MANUAL  
**09D900**

## Illustrated Parts List

### Model Series

### 09D900

TYPE NUMBERS  
1607 through 2241.

#### TABLE OF CONTENTS

Air Cleaner .....	5
Auxiliary Drive .....	3
Blower Housing/Shrouds .....	6
Brake .....	7
Camshaft .....	3
Carburetor .....	4
Controls .....	5
Crankcase Cover/Sump .....	3
Crankshaft .....	3
Cylinder .....	2
Cylinder Head .....	2
Exhaust System .....	5
Flywheel .....	6
Fuel Supply .....	4
Gasket Set - Engine .....	2
Gasket Set - Valve .....	2
Governor Spring .....	5
Ignition .....	5
Lubrication .....	2
Operator's Manual .....	2
Piston/Rings/Connecting Rod .....	3
Rewind Starter .....	6
Warning Label .....	2



PRINTED IN U.S.A.  
COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 9D900 TO 9D999 user guide](http://yourpdfguides.com/dref/3639732)  
<http://yourpdfguides.com/dref/3639732>

**Manual abstract:**

2 OF SERVICE MANUAL 09D900 Illustrated Parts List Model Series 09D900 TYPE NUMBERS 1607 through 2241. TABLE OF CONTENTS Air Cleaner . . .

. . . . .  
. . . . .  
. . . . .  
. . . . . 5 Auxilliary Drive . . . . .

. . . . .  
. . . . .  
. . . . . 3 Blower Housing/Shrouds . . . . .  
. . . . . 6 Brake . . . . .

. . . . .  
. . . . .  
. . . . . 7 Camshaft . . . . .

. . . . .  
. . . . .  
. . . . . 3 Carburetor . . . . .

. . . . .  
. . . . .  
. . . . . 4 Controls . . . . .

. . . . .  
. . . . .  
. . . . . 5 Crankcase Cover/Sump . . . . .

. . . . . 3 Crankshaft . . . . .  
. . . . .  
. . . . . 3 Cylinder . . . . .

. . . . .  
. . . . .  
. . . . . 2 Cylinder Head . . . . .

. . . . .  
. . . . .  
. . . . . 2 Exhaust System . . . . .

. . . . . 5 Flywheel . . . . .  
. . . . .  
. . . . .

. . . . . 6 Fuel Supply . . . . .  
. . . . .  
. . . . .

. . . . . 4 Gasket Set - Engine . . . . .  
. . . . .  
. . . . . 2 Gasket Set - Valve . . . . .

. . . . . 2 Governor Spring . . . . .  
. . . . .  
. . . . . 5 Ignition . . . . .

.....  
.....  
.....  
..... 5 Lubrication .....

.....  
.....  
.....  
2 Operator's Manual .....

..... 2 Piston/Rings/Connecting Rod ..  
.....  
..... 3 Rewind Starter .....

..... 6 Warning Label ..  
.....  
.....

2 PRINTED IN U.S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 09D900 1058 OPERATOR'S MANUAL 1330 REPAIR MANUAL 1319 WARNING LABEL 358 ENGINE GASKET SET 3 12 7 20 51 9 51A 883 11 163 444 524 REQUIRED when replacing parts with warning labels affixed. 426 200 529 1095 VALVE GASKET SET 1 7 9 2 3 668 847 523A 523 842 524 287 524 718 383 7 5 870 869 871 51 525 745 883 50 54 13 337 50A 8 54 9 51A 635 362 10 Illustrations cover a range of engines. @@@@ Parts shown without corresponding text may not be used on your specific engine. 4864-4 Assemblies include all parts shown in frames. 4 08/11/2008 09D900 201 209 211 222E 222F 621 188 265 265A 265B 267 271 269 268 270 643 534 535 333 24 851 426 334 333B 333 24 635 851 362 851A 356 163 535A 536 300 883 832 836 832B 81 613 836A 836B 300A R 832A 836 676 836A 677 676A 677 994 346 832C Illustrations cover a range of engines.

Parts shown without corresponding text may not be used on your specific engine. 4864-5 Assemblies include all parts shown in frames. 5 08/11/2008 09D900 1036 EMISSIONS LABEL 921 969 608 332 55 455 65 592 1211 930 1210 58 74 73 459 689 456 597 60 363 23 66 71 70 68 67 60 678 58 65A 55A 304A 57 58A 56 305 37 78 37A 304 305 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

4864-6 Assemblies include all parts shown in frames.  
6 08/11/2008 09D900 772B 236 925 923 621 745A 745 668 922 772 772A 236A 729 923A 1208 621 933 815 922A Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 4864-7 Assemblies include all parts shown in frames. 7 08/11/2008 09D900 REF. NO.

1 2 3 4 PART NO. DESCRIPTION REF. NO. 16 PART NO. DESCRIPTION REF. NO. 16A PART NO. DESCRIPTION 699653 Cylinder Assembly 399269 Kit-Bushing/Seal (Magneto Side) K299819S Seal-Oil (Magneto Side) 698691 Sump-Engine (Used After Code Date 02111200). ----- Note ----- 395384 Sump-Engine (Used Before Code Date 02111300). Sump-Engine (NO LONGER AVAILABLE) Used on Type No(s).

2010, 2016, 2018, 2202, 2221. 790169 Head-Cylinder K698717 Gasket-Cylinder Head 791781 Breather Assembly K695890 Gasket-Breather 691666 Screw (Breather Assembly) 691245 Tube-Breather K692218 Gasket-Crankcase (Standard) (.015" Thick) ----- Note ----- K270895 Gasket- Crankcase (.005" Thick) K270896 Gasket- Crankcase (.009" Thick) 691640 Screw (Cylinder Head) 691680 Plug-Oil Drain 796211 Crankshaft (Used After Code Date 08071300). ----- Note ----- 796212 Crankshaft (Used After Code Date 08071300). Used on Type No(s). 2001, 2018, 2027, 2032, 2037, 2040, 2045, 2089, 2093, 2095, 2223, 2226, 2227, 2230, 2237, 2238, 2240, 2241. 796213 Crankshaft (Used After Code Date 08071300). Used on Type No(s). 2041, 2213, 2228, 2239. 796215 Crankshaft (Used After Code Date 08071300). Used on Type No(s). 2222. 793062 Crankshaft (Used Before Code Date 08071400).

----- Note ----- 692990 Crankshaft Used on Type No(s). 2007, 2010, 2011, 2029, 2031, 2035, 2038, 2039, 2050, 2060, 2112, 2137, 2200, 2201, 2202, 2210. 692990 Crankshaft (Used Before Code Date 08071400). Used on Type No(s). 2001, 2018, 2027, 2032, 2037, 2040, 2045, 2089, 2093, 2095, 2223, 2226, 2227, 2230, 2237, 2238, 2240, 2241.

692991 Crankshaft Used on Type No(s). 1607, 2003, 2005, 2008, 2020, 2024, 2079, 2084, 2209, 2212, 2218. 692991 Crankshaft (Used Before Code Date 08071400). Used on Type No(s). 2041, 2213, 2228, 2239. 791342 Crankshaft (Used Before Code Date 08071400). Used on Type No(s). 2222. 4A 5 7 8 9 10 11 12 13 15 K Engine Gasket Set-Reference 358 Valve Gasket Set-Reference 1095 Illustrations cover a range of engines. @ @ 8 08/11/2008 09D900 REF.

NO. PART NO. DESCRIPTION REF. NO. PART NO. DESCRIPTION REF. NO. 33 34 35 36 37 37A 40 43 PART NO. @ @ 2010, 2016, 2018, 2202, 2221. @ @ 2010, 2016, 2018, 2202, 2221. @ @ @ @ 795695 Flywheel (Used After Code Date 08012900). Used on Type No(s). 2051, 2053, 2090, 2094, 2224, 2233, 2234. 690843 Flywheel (Used Before Code Date 08013000). Used on Type No(s).

2051, 2053, 2090, 2094, 2224, 2233, 2234. @ @ @ @ @ @ 26 790909 Ring Set (Standard) (Used After Code Date 04111400). @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ 2010, 2016, 2202, 2221. 699644 Manifold-Intake (Used After Code Date 03080300). 693446 Manifold-Intake (Used Before Code Date 03080400).

K699649 Gasket-Intake (Used After Code Date 03080300). 270345S Gasket-Intake (Used Before Code Date 03080400). @ @ @ @ @ 9 08/11/2008 09D900 REF. NO. 60 65 65A 66 67 68 70 71 73 74A 78 81 83 PART NO. DESCRIPTION REF. NO. 209 PART NO. DESCRIPTION REF. NO.

211 222E 222F PART NO. @ @ 2010, 2016, 2018, 2221. ----- Note ----- 690514 Shaft-Auxiliary Drive Used on Type No(s). 2202. 498809 Carburetor 691931 Shaft-Throttle 691623 Pin-Shaft (Drive Gear) 691901 Seat-Inlet 691190 Valve-Throttle K271139S Gasket-Air Cleaner 690398 Cover-Drive Gear 494406

*Tank-Fuel 692198 Screw (Control Bracket) 691640 Screw (Fuel Tank) (1 3/4" Long) 691108 Screw (Fuel Tank) (9/16" Long) 691912 Blade-Governor 690347 Link-Air Vane 691297 Spring-Governor ----- Note ----- 690251 Spring- Governor Used on Type No(s). 2000, 2002, 2004, 2006, 2010, 2012, 2013, 2018, 2019, 2020, 2021, 2022, 2024, 2025, 2026, 2029, 2031, 2032, 2033, 2036, 2037, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2049, 2052, 2054, 2061, 2084, 2089, 2090, 2091, 2092, 2093, 2094, 2096, 2113, 2128, 2137, 2200, 2201, 2202, 2212, 2213, 2218, 2219, 2221, 2223, 2225, 2227, 2228, 2229, 2230, 2231, 2235, 2236, 2237, 2238, 2239, 2240, 2241. 690254 Spring- Governor Used on Type No(s). 2016, 2051, 2207, 2220, 2224, 2233, 2234.*



**[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 9D900 TO 9D999 user guide](http://yourpdfguides.com/dref/3639732)**

**<http://yourpdfguides.com/dref/3639732>**

690250 Spring- Governor Used on Type No(s). 2034, 2040, 2095, 2112, 2209, 2210.

690252 Spring- Governor Used on Type No(s). 2053. 691859 Spring-Governed Idle 691446 Bracket-Control 691445 Bracket-Control Used on Type No(s). 2003, 2015, 2016, 2019, 2020, 2021, 2025, 2026, 2028, 2034, 2038, 2040, 2050, 2051, 2052, 2053, 2061, 2090, 2091, 2094, 2095, 2112, 2128, 2137, 2200, 2207, 2209, 2210, 2220, 2224, 2226, 2233, 2234, 2235. 691867 Link-Lockout (Used After Code Date 97071300).

Used on Type No(s). 2019, 2137. 691826 Link-Lockout (Used Before Code Date 97071400). Used on Type No(s). 2019.

692179 Clamp-Casing 690798 Clamp-Casing Used on Type No(s). 2001, 2005, 2007, 2010, 2024, 2026, 2042, 2050, 2060, 2084, 2095, 2112, 2200, 2207, 2209, 2212, 2213, 2226, 2241. 691024 Clamp-Casing Used on Type No(s). 2021, 2046, 2090, 2091, 2201. 691044 Screw (Casing Clamp) 691025 Casing-Control Wire 691026 Wire-Control 691027 Nut (Control Wire Casing) 691028 Lever-Control 691002 Screw (Dipstick Tube) 692307 Muffler (Super Lo Tone) 394569S Muffler (Round Lo Tone) 236 236A 90 97 101 106 130 163 178 180 188 190 190A 200 201 265 265A 265B 267 268 269 270 271 287 300 300A K Engine Gasket Set-Reference 358 Valve Gasket Set-Reference 1095 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 4864-10 Assemblies include all parts shown in frames. 10 08/11/2008 09D900 REF. NO. 304 PART NO.

DESCRIPTION REF. NO. 346 356 358 362 363 365 374 PART NO. DESCRIPTION REF. NO. 608 PART NO. DESCRIPTION 691484 Housing-Blower (Compliance Engines) ----- Note ----- 694236 Housing- Blower (Compliance Engines) Used on Type No(s). 2037, 2041, 2054, 2096, 2223, 2225, 2227, 2228, 2229, 2230, 2231, 2236, 2241. 692536 Housing-Blower (Non Compliance Engines) -0345 Screw (Linkage Cover) (7/16" Long) (Front) (Used Before Code Date 97071400). 691111 Screw (Linkage Cover) (1 1/8" Long) (Front) 690324 Screw (Band Brake Pivot) 699299 Guard-Muffler (Super Lo Tone) 699670 Guard-Muffler (Round Lo Tone) 790743 Guard-Muffler Used on Type No(s).

2003, 2006, 2016, 2019, 2021, 2027, 2032, 2033, 2042, 2043, 2049, 2051, 2053, 2054, 2061, 2089, 2094, 2096, 2128, 2137, 2207, 2223, 2224, 2225, 2227, 2228, 2229, 2230, 2231, 2233, 2234, 2235, 2236, 2237, 2239, 2240, 2241. 790744 Guard-Muffler Used on Type No(s). 2018, 2020, 2026, 2037, 2041, 2045, 2046, 2238. 690664 Screw (Muffler Guard) (13/32" Long) 790745 Screw (Muffler Guard) (1/2" Long) 691125 Screw (Muffler Guard) (2/3" Long) K691870 Seal-O Ring (Dipstick Tube) 691440 Dipstick/Tube Assembly 493880S Terminal-Spark Plug 692424 Terminal-Spark Plug 699641 Seat-Valve (Intake) (Used After Code Date 03080300). @@699642 Seat-Valve (Exhaust) (Used After Code Date 03080300).

@@@63709 Bushing-Valve Guide (Intake Valve) 745 836 836A 836B 842 847 851 851A 869 745A 772 930 691348 933 690428 957 497929S 957A 791129 969 692523 772A 976 994 1036 694394 398067 772B 815 832 832A 832B 870 1058 1095 1143 1208 1210 1211 1319 1330 277038 498526 691141 690859 499901 499901 794467 270962 871 K Engine Gasket Set-Reference 358 Valve Gasket Set-Reference 1095 Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 4864-12 Assemblies include all parts shown in frames. 12 08/11/2008 .



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 9D900 TO 9D999 user guide](http://yourpdfguides.com/dref/3639732)  
<http://yourpdfguides.com/dref/3639732>