



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BROTHER DCP-115C. You'll find the answers to all your questions on the BROTHER DCP-115C in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BROTHER DCP-115C
User guide BROTHER DCP-115C
Operating instructions BROTHER DCP-115C
Instructions for use BROTHER DCP-115C
Instruction manual BROTHER DCP-115C

brother.

DCP-115C
DCP-117C
DCP-120C
DCP-315CN

Before you can use the machine, you must set up the hardware and install the software.
Please read this 'Quick Setup Guide' for the correct setup procedure and installation instructions.

STEP 1
Setting Up the Machine

STEP 2
Installing the Driver & Software

Setup is Complete!

Keep this 'Quick Setup Guide', the User's Guide and the supplied CD-ROM in a convenient place for quick and easy reference at all times.

CE



[You're reading an excerpt. Click here to read official BROTHER DCP-115C user guide](http://yourpdfguides.com/dref/4672023)
<http://yourpdfguides.com/dref/4672023>

Manual abstract:

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... 4 Attaching the control panel cover....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.... 4 Loading paper .

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

. 4 Installing the power cord

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.. 5 Choosing your language ...

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

... 5 Installing the ink cartridges.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... 6 Print quality check

.....
.....
.....
.....

.....
.....

.....
.....
.....
.....
.....
.....
.....
.....

.....
.. 8 Setting the date and time ...

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
.. 9 STEP2 – Installing the Driver & Software Windows® For USB Interface Users (For Windows® 98/98SE/Me/2000 Professional/XP) ...

.....
.....
.....
.....
.....
.....
.....
.....

..... 12 For Network Interface Users (DCP-315CN only) (Windows® 98/98SE/Me/2000 Professional/XP)...

.....
.....
.....
.....
.....
.....
.....
.....

.... 15 Macintosh® For USB Interface Users

.....
.....
.....

.....
.....
.....
.....
.....
.....
.....

29 1 Getting Started 1 Carton components Carton components may vary from one country to another. Save all packing materials and the carton in case for any reason you must ship your machine. Quick Setup Guide CD-ROMs For Windows® For Macintosh® User's Guide Power Cord Control Panel Cover Black (LC900 BK) Magenta (LC900M) Yellow (LC900Y) Cyan (LC900C) Ink Cartridges If you are connecting the machine via USB: The interface cable is not a standard accessory. Please purchase an appropriate USB 2.0 interface cable. Please make sure you use a USB 2.0 cable that is no longer than 6 feet long (2 meters). Your DCP has a USB interface. This interface is compatible with Hi-Speed USB 2.

0; however, the maximum data transfer rate will be 12 Mbits/s. The DCP can also be connected to a computer that has a USB 1.1 interface. DO NOT connect the interface cable at this time. Connecting the interface cable is done during the software installation process. 2 Getting Started Control panel (For DCP-115C, DCP-117C, DCP-120C and DCP-315CN) 12 11 10 9 8 7 6 1 1 2 3 4 5 6 Copy keys Set key Navigation keys Stop/Exit key Start keys On/Off key 2 7 8 9 3 Scan key 4 5 Ink management key PhotoCapture key 10 Menu key 11 LCD (Liquid Crystal Display) 12 Warning LED For the details of the control panel, see Control panel overview in Chapter 1 of the User's Guide. Illustrations in this Quick Setup Guide are based on DCP-120C. The screens for Windows® in this Quick Setup Guide are based on Windows® XP. The screens for Mac OS® in this Quick Setup Guide are based on Mac OS® X 10.3.

3 STEP1 1 Setting Up the Machine Removing the protective parts Remove the protective tape and scanner glass protection sheet. 1 3 Loading paper You can load up to 100 sheets of 80 g/m2 (20 lb) paper. For details, see About paper in Chapter 1 of the User's Guide. 1 Improper Setup DO NOT connect the USB cable. Connecting the USB cable is done during the software installation process.

1 Pull the paper tray completely out of the machine and remove the output paper tray. 2 Attaching the control panel cover Attach the control panel cover to the machine. 1 2 Press and slide the paper guide (1) to fit the paper width. 1 3 Pull out the paper support (1) and unfold the paper support flap (2). 1 2 Note Use the paper support flap for Letter, Legal and A4 paper.

4 Setting Up the Machine 4 Fan the stack of paper well to avoid paper jams and misfeeds. 4 Installing the power cord Connect the power cord. 1 5 Gently put the paper into the paper tray print side down and top edge first. Check that the paper is flat in the tray and below the maximum paper mark (1). 1 Improper Setup DO NOT connect the USB cable yet. Warning The machine must be fitted with an earthed plug. Note The control panel warning LED will stay on until you have installed the ink cartridges. 5 Note • Make sure the paper side guides touch the sides of the paper. • Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause paper feed problems. Choosing your language After connecting the power cord, the LCD shows: 1 Select language q 6 Put the output paper tray back on and push the paper tray firmly back into the machine.

Press Set Key Press Set. English q e Select ab & Set 2 Press a or b to choose your language and press Set. English? q a Yes b No 5 STEP1 3 Setting Up the Machine If your language is chosen, press a (Yes). If you have set the language wrongly, you can change the language after setting the date and time. (For details, see "How to change LCD language" in Chapter 5 of the User's Guide) 4 Take out the ink cartridge. 6 Installing the ink cartridges Warning If ink gets in your eyes, wash them out with water at once, and if irritation occurs consult a doctor. 5 Carefully remove the protective yellow cap (1). 1 1 2 Make sure that the power is turned on. The LCD shows: No Cartridge Lift the scanner cover (1) from the right-hand side of the machine until it locks securely into the open position. Improper Setup 1 DO NOT touch the area shown in the illustration below.

3 Remove the protective parts (1). 1 Note If the protective yellow cap comes off when you open the bag, the cartridge will not be damaged. Keep the ink cartridge in an upright position when you put it into the slot. OK Note Do not throw away the protective parts. You will need them if you transport the machine.

6 Setting Up the Machine 6 Press firmly down on the ink cartridge until the hook snaps over it, taking care to match the slot colour (1) with the cartridge colour (2), as shown in the diagram below. Caution • DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge. • DO NOT shake the ink cartridges. If ink stains your skin or clothing, wash with soap or detergent at once.

• DO NOT repeatedly insert and remove the cartridges. If you do so, ink may seep out of the cartridge. • If you mix the colours by installing an ink cartridge in the wrong position, clean the print head several times after correcting the cartridge installation. (See Cleaning the print head in chapter 11 of the User's Guide.) • Once you open an ink cartridge, install it in the machine and use it up within six months of installation. @@@@ @@@@ @@@@ @@@@ @@@@ The cleaning process will last approximately four minutes. @@@@ @@@@ Press Colour Start. The machine starts printing the Print Quality Check Sheet (only during initial ink cartridge installation). Check the quality of the four colour blocks on the sheet. (black/ cyan/ yellow/ magenta) Print Quality Check 1.

Check the quality of the four-color blocks formed by the short lines. 2. If all the short lines are clear and visible, the quality is acceptable. the quality is acceptable. Select (Yes). If you can see missing short lines, select (No) to begin the color cleaning process and follow the prompts on the LCD. Black OK? q a Yes b No After pressing a (Yes) or b (No) for both black and colour, the LCD shows: 3 Start Cleaning? q a Yes b No 7 8 Press a (Yes), the machine will then start cleaning the colours. After cleaning is finished, press Colour Start. The machine starts printing the Print Quality Check Sheet again and goes back to step 3. ImproperniPage® and True Type® fonts.



[You're reading an excerpt. Click here to read official BROTHER DCP-115C user guide](http://yourpdfguides.com/dref/4672023)
<http://yourpdfguides.com/dref/4672023>

PaperPort® 9.0SE is a document management application for viewing scanned documents. ScanSoft® OmniPage®, which is integrated into PaperPort® 9.0SE, is an OCR application that converts an image into text and puts it into your default word processor. 10 STEP 2 Windows® Installing the Driver & Software Follow the instructions on this page for your operating system and interface cable.

For the latest drivers and documentations and to find the best solution for your problem or question, access the Brother Solutions Center directly from the driver or visit <http://solutions.brother.com> For USB Interface Users (For Windows® 98/98SE/Me/2000 Professional/XP)...

.....

.....

.....

.....

.....

.....

12 For Network Interface Users (DCP-315CN only) (Windows® 98/98SE/Me/2000 Professional/XP)

.....

.....

.....

.....

.....

.....

..... 15 Macintosh® For USB Interface Users .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

18 @@ 18 For Mac OS® 9.1 to 9.2 ...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 21 For Network Interface Users (DCP-315CN only) ...

.....

.....

.....

.....

.....

.....
.....
23 For Mac OS® X 10.2.4 or greater...
.....
.....
.....
.....

.....ver & Software For USB Interface Users Macintosh® For Mac OS® X 10.2.4 or greater Important Make sure that you have finished the instructions from Step 1 Setting Up the Machine on page 4-9. 6 7 8 Follow the on-screen instructions, and restart your Macintosh®.

Lift the scanner cover to its open position. After the DeviceSelector window appears connect the USB interface cable to your Macintosh and then to the machine. Note For Mac OS® X 10.2.0 to 10.2.3 users, upgrade to Mac OS® X 10.2.4 or greater. (For the latest information for Mac OS® X, visit [http://solutions.](http://solutions.brother.com)

brother.com) 1 Macintosh® USB Disconnect the machine from the power socket and from your computer, if you already connected an interface cable. Note The DeviceSelector window will not appear if you have connected a USB interface cable to the machine before restarting your Macintosh® or if you are overwriting a previously installed version of the Brother Software. If you encounter this problem continue with the installation but skip 13. @@For details, see the Software User's Guide on CD-ROM.

2 3 4 Turn on your Macintosh®. Put the supplied CD-ROM into your CD-ROM drive. Double-click the Start Here OSX icon to install the drivers and MFL-Pro Suite. If the language screen appears, choose your language. 9 Connect the USB cable to the USB socket marked with a symbol. You will find the USB socket above and to the left of the ink cartridge slots, as shown below. 5 Click MFL-Pro Suite to install. 18 Installing the Driver & Software 10 Carefully guide the USB cable into the trench as shown below, following the trench around and toward the back of the machine. Macintosh® 15 Double-click the Utilities folder. 16 Double-click the Printer Setup Utility icon. Improper Setup • DO NOT connect the machine to a USB port on a keyboard or a non-powered USB hub. @@ • Make sure that the cable does not restrict the cover from closing, or an error may occur. 11 Lift the scanner cover to release the lock. cord. 12 Turn on the machine by plugging in the power Note For Mac® OS X 10.

2.x users, open Print Center icon. 17 Click Add. 13 Choose USB and then click OK. 18 Choose USB. (For Mac OS® X 10.2.4 to 10.3 users) 14 Click GO, then Applications. Note For Mac OS® X 10.

4 users, go to step 19. 19 Macintosh® USB Gently push the scanner cover support down and close the scanner cover. STEP2 Installing the Driver & Software model name), and then click Add. Macintosh® 19 Choose DCP-XXXX (where XXXX is your 20 Click Printer Setup Utility, then Quit Printer Setup Utility. Macintosh® USB The MFL-Pro Suite, Brother printer driver, scanner driver and Brother ControlCenter2 have been installed and the installation is now complete.

21 To install Presto!®PageManager®, click the Presto! @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@If you encounter this problem continue but skip 13 through 16. @@For details, see Chapter 10 in the Software User's Guide on the CD-ROM. Connect the network cable to the LAN socket marked with a symbol. You will find the LAN socket above and to the left of the ink cartridge slots, as shown below. 2 3 4 Turn on your Macintosh®.

Put the supplied CD-ROM into your CD-ROM drive. 5 Click MFL-Pro Suite to install. 10 Carefully guide the network cable to the trench as shown below, following the trench around and toward the back of the machine. Then, connect the cable to your network. 6 7 Follow the on-screen instructions, and restart your Macintosh®. Lift the scanner cover to its open position. 23 Macintosh® Network Double-click the Start Here OSX icon to install the printer and scanner drivers. If the language screen appears, choose your language. 9 STEP2 Installing the Driver & Software 15 Click Browse. Macintosh® Improper Setup Make sure that the cable does not restrict the cover from closing, or an error may occur.

Note In case of using both USB and LAN cables, route both cables through the trench. 11 Lift the scanner cover to release the lock. cord. 16 Choose your model name, and then click OK. Gently push the scanner cover support down and close the scanner cover. 12 Turn on the machine by plugging in the power 17 Click Go, then Applications. 13 Choose Network and then click OK. 18 Double-click the Utilities folder. Macintosh® Network 14 If you want to use the machine's Scan key to scan over the network you must check Register your computer with the "Scan To" functions at the machine box. You must also enter a name for your Macintosh® in Display Name.

The name you enter will appear on the machine's LCD when you press the Scan key and choose a scan option. You can enter any name up to 15 characters long. (For more information on network scanning, see Chapter 11 of the Software User's Guide on the CDROM.) 19 Double-click the Printer Setup Utility icon. Note For Mac® OS X 10.

2.x users, open Print Center icon. 24 Installing the Driver & Software 20 Click Add. Macintosh® The MFL-Pro Suite, Printer Driver, Scanner Driver and ControlCenter2 have been installed. For more information about connecting the machine to a Macintosh® network, see Chapter 5 of the Network User's Guide on the CD-ROM.

21 Make the selection shown below. ® (For Mac OS X 10.2.4 to 10.3 users) 24 To install Presto!®PageManager®, click the Presto! PageManager icon and follow the on-screen instructions. Note For Mac OS® X 10.4 users, go to step 22. Note When Presto!®PageManager®is installed OCR capability is added to the Brother ControlCenter2. You can also easily scan, share, and organize photos and documents using Presto!®PageManager®. 22 Choose Brother DCP-XXXX, and then click Add.

Note XXXX is your model name. xxxxxx are the last six digits of the Ethernet address. See Chapter 5 of the Network User's Guide on the CD-ROM. 23 Click Printer Setup Utility, then Quit Printer Setup Utility. 25 Macintosh® Network Presto!®PageManager® has been installed and the installation is now complete.



[You're reading an excerpt. Click here to read official BROTHER DCP-115C user guide](http://yourpdfguides.com/dref/4672023)
<http://yourpdfguides.com/dref/4672023>

STEP2 Installing the Driver & Software Macintosh® For Mac OS® 9.1 to 9.2 Important Make sure that you have finished the instructions from Step 1 Setting Up the Machine on page 4-9. 8 Connect the network cable to the LAN socket marked with a symbol. @@@@ @@@@Lift the scanner cover to its open position.

Installing the Driver & Software 12 From the Apple® menu, click Chooser. Macintosh® Presto!®PageManager® has been installed and the installation is now complete. 13 Click the Brother Ink (IP) icon, and then choose BRN_XXXXXX (where XXXXX are the last six digits of the Ethernet address). Close the Chooser. For more information about connecting the machine to a Macintosh® network, see Chapter 5 of the Network User's Guide on the CD-ROM.

The MFL-Pro Suite, Printer Driver and Scanner Driver have been installed. Note ControlCenter2 is not supported in Mac OS® 9.x. 14 To install Presto!®PageManager®, click the Presto! PageManager icon and follow the on-screen instructions. Note You can easily scan, share, and organize photos and documents using Presto!®PageManager®.

27 Macintosh® Network For Network Users This section is for an administrator who wants to configure the machine on a network using the BRAdmin Professional utility. (DCP-315CN only) 1 Installing the BRAdmin Professional configuration utility (Windows® only) The BRAdmin Professional utility is designed to manage your Brother network connected devices such as network-ready Multifunction devices and/or network-ready printers in a Local Area Network (LAN) environment. BRAdmin Professional can also be used to manage devices from other manufacturers whose products support SNMP (Simple Network Management Protocol). For more information on BRAdmin Professional, visit us at <http://solutions.brother.com>. Setting your IP address, Subnet Mask and Gateway using BRAdmin Professional (Windows® only) 1 Start BRAdmin Professional, and choose TCP/IP. 1 Put the supplied CD-ROM into your CD-ROM drive. The opening screen will appear automatically. @@@@ @@@@Brother is a registered trademark of Brother Industries, Ltd.

Multi-Function Link is a registered trademark of Brother International Corporation. Windows and Microsoft are registered trademarks of Microsoft in the U.S. and other countries. Macintosh and True Type are registered trademarks of Apple Computer, Inc. PaperPort and OmniPage OCR are registered trademarks of ScanSoft, Inc. Presto! PageManager is a registered trademark of NewSoft Technology Corporation. Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs. All other brand and product names mentioned in this manual are trademarks or registered trademarks of their respective companies. Compilation and Publication Under the supervision of Brother Industries Ltd. , this manual has been compiled and published, covering the latest product descriptions and specifications. The contents of this manual and the specifications of this product are subject to change without notice. Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication. This product is designed for use in a Professional Environment. ©2005 Brother Industries, Ltd.

©1998-2005 TROY Group, Inc. ©1983-2005 PACIFIC SOFTWARES INC. ALL RIGHTS RESERVED. UK/IRE .



[You're reading an excerpt. Click here to read official BROTHER DCP-115C user guide](http://yourpdfguides.com/dref/4672023)
<http://yourpdfguides.com/dref/4672023>