

Manual abstract:

*Projector features 1 receiver for remote control 2 height adjustment 3 focus and zoom 4 lens cover 5 S-video port 6 composite-video port 7 audio input ports 8 USB port 9 VGA-in port 10 VGA-out port 11 power cord socket and switch * only certain models WARNING: Read and observe these precautions to reduce the risk of injury and equipment damage. Do not look directly into the lens when the lamp is on. Do not expose the projector to rain or other moisture, and do not use it near water. Keep paper, plastic, and combustible material at least 0. @@ Do not block any vents on the projector. @@@@Do not overload any outlet or extension cord. Do not circumvent the grounding prong on the power cord. @@What to do next · For support information, see the support and warranty guides. .*



[You're reading an excerpt. Click here to read official COMPAQ
VP6300 user guide
http://yourpdfguides.com/dref/3235337](http://yourpdfguides.com/dref/3235337)