




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DAEWOO FR-2701. You'll find the answers to all your questions on the DAEWOO FR-2701 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DAEWOO FR-2701
User guide DAEWOO FR-2701
Operating instructions DAEWOO FR-2701
Instructions for use DAEWOO FR-2701
Instruction manual DAEWOO FR-2701



[You're reading an excerpt. Click here to read official DAEWOO FR-2701 user guide](http://yourpdfguides.com/dref/3408058)
<http://yourpdfguides.com/dref/3408058>

Manual abstract:

11.135:58PM 2 REFRIGERATOR INSTRUCTION MANUAL MODEL NO.: FR-2701 s Thank you for selecting this refrigerator. s Before using the refrigerator, please read this manual carefully. FR-2701(¿) 00.11.135:58PM 1 FEATURE CHART 1 2 3 4 5 6 7 8 q w r e t 9 0 y 1 ICE TRAY 2 F SHELF (MOVABLE) 3 FREEZER TEMPERATURE CONTROL KNOB 4 ICE BOX 5 CHILLED CASE 6 LAMP COVER 7 REFRIGERATOR TEMPERATURE 9 VEGETABLE CASE COVER 0 VEGETABLE CASE q FREEZER POCKET w FREEZER POCKET e UTILITY POCKET r EGG CASE t BOTTLE POCKET (LARGE) y BOTTLE POCKET (SMALL) CONTROL SWITCH 8 R SHELF (MOVABLE) 1 FR-2701(¿) 00.11.135:58PM 2 Here are the features of your new refrigerator. Take a moment to know all the features designed for the convenience of the user.

s Ice Tray Fill 3/4 of the ice tray with water, as the volume expands when the water is frozen. Place the tray in the freezer compartment. To release ice cubes, twist the ice tray slightly. Ice cubes will be easier to remove if it is held for a short while under running water. s Movable refrigerator and freezer shelves Storage shelves should be adjusted depending on the height of the food stored.

To do this, pull the shelves slightly forward. s Defrost-drain Vessel Since dust accumulated on the drain case decreases the evaporation efficiency, you should clean the drain case at regular intervals. 2 FR-2701(¿) 00.11.135:58PM 3 jÆ Lamp Cover To remove the lamp cover 1.

Push up the bottom end of the lamp cover gently, then pull out. 2. Reverse procedure to join together. jÆ Vegetable case May be used for fruit and vegetable storage. Both the vegetable case and its cover shelf are removable for easy cleaning. Simply slide forward to remove. jÆ Utility Pocket (Top) The Egg Case in this pocket can be turned upside down for the use of small size goods. 1 2 CAUTION: 1. Check your voltage before inserting the power supply cord into the socket. 2.

@@3. Do not spill liquid on this unit. 4. Do not use flammable spray, such as painting, near this unit. 5. Do not place ignitable material, such as benzine, L.P. gas, alcohol etc., into this unit. 6.

Take precautions against leakage of any gas equipment near this unit. 7. Keep children from hanging on the door of this unit. 8. @@@@Unstable installation can produce noise and vibration.

· Place your refrigerator where there is no heat source nearby. High atmosphere temperature will lower cooling efficiency and increase your electricity bill. · Place the refrigerator in an area where the humidity level is low. Splashing water on the refrigerator or installing the unit in a humid area may cause short circuit and rust. · Avoid places that are exposed to coal gas or smoke, or discoloring may occur on the refrigerator.

· For good ventilation, keep enough space between the sidewalls and your refrigerator. This helps to cool efficiently and lowers the electricity bill. · Putting the refrigerator on the carpet may cause temperature rise and result in the discoloring of the carpet due to the compressor heat. In such a case, place a hard wooden board or a rubber mat between the carpet and the unit. cm 1 30 eas At l Carpet At lea st 6 cm m 6c st lea At Wooden Board, Rubber Mat 4 FR-2701(¿) 00.11.135:58PM 5 2. INSTALLATION STEPS · Select a safe place to install your refrigerator. · Level the refrigerator by using the adjustable feet. · Install the parts in their own place.

n llatio insta Safe place Maintain ~ Level Com p orig onents inal to plac their es · Check if the doors are completely closed. · Check the voltage. Then wait about an hour before plugging the power cord into the outlet. · Put food in the refrigerator after running the refrigerator for 2~3 hours. r afte food s Put 3 hour 2~ Plug in after about hour Check Check 5 FR-2701(¿) 00.11.135:58PM 6 3. WHAT YOU NEED TO KNOW BEFORE MOVING OR RELOCATING THE REFRIGERATOR! · Unplug the power cord. · Remove the grille with driver and water from the defrostdrain vessel located at the rear of the refrigerator. · Do not detach the defrost drain vessel from the compressor.

· Take food out of the refrigerator. The installation of the grille is an option. · Fasten the interior components with adhesive tape. @@@@To clean, use a soft piece of cloth. Wash with warm, soapy water, rinse and dry.

@@@@@The refrigerator is not designed for recessed installation. s Select a strong and level floor. @@There are two leveling feet at each front corner. Turn to the left to raise a corner, to the right to lower it. Use shims under the rear corners, if necessary.

@@@@@CONTROL MIN MED MAX WINTER MAX MED TEMP. CONTROL MIN The control has four settings form MIN to WINTER. @@@@Clean the refrigerator thoroughly. Wipe the outside with a dry cloth, and the inside with a damp cloth. 2. Set the temperature control knob at normal position. 3. @@@s The temperature and humidity of the surrounding environment. @@@s The combination of food and containers stored in the refrigerator. @@@@Remove icing case and food.

Leave doors ajar for ventilation and dehumidification of both compartments. 2. DEFROSTING THE REFRIGERATOR You will never have to defrost your refrigerator as it is designed to defrost itself completely and automatically. ! CAUTION To avoid the risk of electric shock or death, unplug the power cord before replacing a burned out light bulb or cleaning the inner parts. 3. RADIANT HEAT With the Refrigerating System in operation, it is likely that the cabinet will feel warm at the front edges and sides. This does not indicate trouble. It is due to the hot-line used in this type of Refrigerating System which consists of piping hot gas from the (motor-driven) compressor along the front edges, the sides of the cabinet and the center partition to prevent dewing. This has nothing to do with the storage temperature inside. (The thick line indicates the hot-line) NOTE: During spells of hot, humid weather and in rainy season, moisture may develop on the cabinet, just as water condenses around a cold glass of water.

It is not an abnormal condition ; wipe off the moisture with a dry cloth. This can also happen when the refrigerator is not installed in an appropriate place. 10 FR-2701(¿) 00.11.135:58PM `11 WHAT TO DO.

.. When not operating for a long time s Remove the power supply cord. s Dry your refrigerator by opening the door for 2-3 days. When you get ready to move s Securely fasten movable interior parts (or remove and pack them separately) s DO NOT lay down your refrigerator horizontally, or the compressor may be damaged.

Before you call for service, please check the following points first. If the refrigerator is not operating : s Is the power supply cord unplugged? s Is the home fuse or circuit out of order? If the refrigerator is warmer than usual : s Has the door been opened frequently or for a long period? s Are there any hot food or anything that has been stored without cooling? @@@@s Are there any foreign objects behind the refrigerator? @@@@(also known as DECI) warrants this product to be free from defects in material and workmanship and agrees to remedy any such defect.



[You're reading an excerpt. Click here to read official DAEWOO](#)

[FR-2701 user guide](#)

<http://yourpdfguides.com/dref/3408058>

This warranty covers 1 years labour and 1 years parts, plus an additional 4 years part warranty on COMPRESSOR only, from the date of original purchase. This warranty applies only to product purchased from an authorized DECI dealer and used within the boundaries of Canada. This warranty does not apply to product that has been improperly installed, subjected to usage for which the product was not designed, misused or abused, damaged during transportation, or which has been altered or repaired in any way that affects the reliability or detracts from its performance. How to Obtain Warranty Service Warranty service can only be provided by an authorized DECI Service centre. For the closest authorized Service centre to you, please contact your Dealer. In order to receive warranty service you must provide the authorized Service centre with a copy of proof of purchase, signifying the date of purchase and the name of the Dealer from whom you purchased the product. Statutory Warranties The purchaser may have rights under existing provincial or feder.



[You're reading an excerpt. Click here to read official DAEWOO](#)

[FR-2701 user guide](#)

<http://yourpdfguides.com/dref/3408058>