



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DAEWOO FR-530NT. You'll find the answers to all your questions on the DAEWOO FR-530NT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DAEWOO FR-530NT
User guide DAEWOO FR-530NT
Operating instructions DAEWOO FR-530NT
Instructions for use DAEWOO FR-530NT
Instruction manual DAEWOO FR-530NT

1. Installation Instructions

Suitable Installation Place

Where the floor is solid and level	Where ventilation is good	Where there is little or no heat/moisture
<ul style="list-style-type: none"> Unstable installation causes vibration and noise of refrigerator. Wooden floor or carpet can be discolored under the refrigerator. Doors may hang down due to the weight of refrigerator unless it is leveled. 	<ul style="list-style-type: none"> More than 10 cm from 3 sides of wall (left, right and back) is good enough for ventilation. Insufficient space causes noise of vibration, weakening of refrigerating power and waste of electricity. 	<ul style="list-style-type: none"> Direct sun rays, side heat of stove and gas range can weaken the refrigerating power. Avoid a place near the faucet or sink with much moisture and where water can splash. Rust and corrosion, short-circuit are surely made. Use hard board or plank on the concrete/cement floor.

Grounding


Grounding terminal is the green one connected to the power cord in the back of refrigerator.

Grounding is necessary where	water can splash easily ; bathroom etc.	there is much moisture ; basement etc.	any wet and/or watery places.
Grounding by using grounding wire	Bury copper plate to which grounding wire is connected 25 cm deep in the ground.		
Grounding by using short-circuit breaker	Short-circuit breaker is a must where the floor is always wet, for example, fish shop, restaurant kitchen etc.		
Grounding is not necessary	in case of using side-grounded outlet.		
You should not connect the ground wire to	water pipe, gas pipe, telephone line, lightning rod. There can be explosion or fire.		

Correct usage of Refrigerator

Plug in the refrigerator right after installation.	* See page 2 for details.
Set the temperature to "MAX" to perform preparatory run for 2 or 3 hours. When the inside is cold enough, put the foods in.	* When the surrounding temperature is hot in midsummer, do not open and shut the doors too often after installation.

Installation Process

<p>Attach the height adjustable legs to their holes in the left and right bottom of refrigerator. Adjust the height by turning the legs until they touch the floor.</p> <p>* Let the right adjustable leg touch the floor firmly, while the left, smoothly.</p> 

1



[You're reading an excerpt. Click here to read official DAEWOO FR-530NT user guide](http://yourpdfguides.com/dref/3408010)
<http://yourpdfguides.com/dref/3408010>

Manual abstract:

Installation Instructions Suitable Installation Place Where the floor is solid and level · Unstable installation causes vibration and noise of refrigerator. · Wooden floor or carpet can be discolored under the refrigerator. · Doors look hanged down due to the twist of refrigerator unless it is leveled. Where ventilation is good · More than 10 cm from 3 sides of wall (left, right and back) is good enough for ventilation. · Insufficient space causes noise of vibration, weakening of refrigerating power and waste of electricity. Where there is little or no heat, moisture · Direct sun lays, side heat of stove and gas range can weaken the refrigerating power. · Avoid a place near the faucet or sink with much moisture and where water can splash. Rust and corrosion, shortcircuit are surely made. · Use hard board or plank on the concrete/cement floor. Grounding Grounding terminal is the green one connected to the power cord in the back of refrigerator.

Grounding is necessary where Grounding by using grounding wire Grounding by using shortcircuit breake Grounding is not necessary You should not connect the ground wire to water can splash easily ; bathroom etc. there is much moisture ; basement etc. any wet and/or watery places. Bury copper plate to which grounding wire is connected 25 cm deep in the ground. @@in case of using side-grounded outlet. water pipe, gas pipe, telephone line, lightning-rod. @@@@When the inside is cold enough, put the foods in. @@Adjust the height by turning the legs until they touch the floor. · Let the right adjustable leg touch the floor firmly, while the left, smoothly. for details.

** When the surrounding temperature is hot in midsummer, do not open and shut the doors too often after installation. 1 2. SAFETY INSTRUCTIONS NO Never install the refrigerator where there is much moisture and water can splash. BE SURE TO KEEP NO/NEVER DO NOT DISASSEMBLE DO NOT TOUCH WARNING NO Do not allow children to hang on the doors. · The refrigerator may be tipped over to hurt children. UNPLUG GROUND WARNING ATTENTION s Improper use can cause physical damage - personal injury. s Improper use can cause injury or material damage to the household · It can be a danger of short circuit or fire. If the power cord of refrigerator is damaged, have it replaced by a repair shop by the manufacture, as special tools are required. Allow 6 cm or more clearance between wall and side and rear plate of the refrigerator for good fresh air circulation. NEVER USE When you smell something strange burning out of refrigerator, unplug it to stop running.*

· It's very dangerous to keep the abnormal refrigerator running on and on. NEVER USE Never use plug if it is loose. · There can be electric shock or fire by short circuit. WARNING VENTILATION In case of gas leak, ventilate the room instead of unplugging the refrigerator. · Explosion or fire may happen. EXCLUSIVE POWER OUTLET Use exclusive power outlet for the refrigerator only. · Several plugs in an outlet may cause fire. Do not use a double outlet or extension cord. NEVER USE Never use any spray near the refrigerator. · It can cause danger of explosion.

NEVER EAT Never eat deteriorated food stored too long in the refrigerator or in the out-of-order refrigerator. · You can be food-poisoned. ATTENTION Do not eat any frozen food immediately from the freezer compartment. · It can get you cold-burns. DISCARDING When discarding the refrigerator, remove the door packing.

· Children may be trapped inside it. NEVER STORE CLEAN PLUG Unplug and clean it with dry cloth if dirty. · Dusty and dirty plug may cause fire. This refrigerator is for storing only foods. · Do not store medicines, flammable things, and study sample, etc. NEVER DISASSEMBLE Do not repair the refrigerator on your own. CURTAIN · It can work abnormally and cause bigger trouble. NO Never install the refrigerator where there is much moisture and water can splash. · It can be a danger of short circuit or fire. NO Do not put heavy things or water contained tanks on top of refrigerator. · It's dangerous when they fall down and fire by short circuit can happen. NEVER TOUCH Do not use any sharp tools when cleaning the inside. · The cooling system can be damaged or there may be electric shock. NEVER TOUCH Do not pull and/or push the plug with wet hand. @@@@ Wipe out the surface with dry cloth.

IT SOUNDS WATER-FLOWING Foods freeze in the fresh food compartment s Has the temperature been on "MAX" continuously? s Is the surrounding temperature less than 5°C? s Were the wet or watery foods such as vegetables placed just in front of the cold air duct? in the refrigerator · The sound can be heard when the compressor stops. The system can make such a sound when the refrigerant is active DOORS ARE NOT opened easily. · Such case happens when you open the door right after closing it. Do not try to open the doors ; wait about 30 seconds or so. Refrigerator never gets cold. s Is there any power failure? s Is the plug loose from the wall outlet? Refrigerator does not get cold enough. s Has the temperature been on "MIN" continuously? Set the temperature to "MID" or "MAX". s Has hot food put in? Check food storage state. s Is the inside filled with too much food? s Is either door open or did you open and close the doors too often? s Is there a gas range or a stove near the refrigerator? Is the refrigerator in direct sun-light? Check the installation place. Front feels warm.

· Front part of cabinet may feel warm because of the hot-pipe to prevent the forming of moisture. Cracking sound comes out of the inside. · When you open the door the parts inside shrink and expand a little due to temperature change, such sound can be heard. Refrigerator is noisy. s Is the floor firm and level or the refrigerator levelled well ? s Is the back of refrigerator touching the wall ? ; ; ; Check! Freezer compartment door is opened and shut slightly.

· When you shut the fresh food compartment door quickly, the freezer compartment door is opened and shut slightly of itself. That's because of the condensed air in the fresh food compartment run to the freezer compartment. · When the surroundings is hot and humid, if you open and shut the doors frequently such happens. When you store watery food in the air clung to the inside. Tiny frostwork forms inside of the fresh food compartment Moisture collects inside. s Check if either door is open. s Did you leave the doors open too long or is moist food put with its lid off ? Moisture disappears naturally if doors are closed, but it's better to wipe it off with dry cloth. Water is flowing out when moving the refrigerator.



[You're reading an excerpt. Click here to read official DAEWOO](#)

[FR-530NT user guide](#)

<http://yourpdfguides.com/dref/3408010>

*s Have you dried and emptied the evaporator dish? Something smells. s Air ducts blocked with foods ? s Is strong odoring food stored unwrapped ? Check the food storage state. * The vegetable cases are closed, so deodorizing is almost impossible. 6 7 4. NAME OF EACH PART & FUNCTION TEMPERATURE CONTROL LEVER OF FREEZER COMPARTMENT · Use the lever when you control the temperature of freezer compartment. · Set the lever to which you want to choose temperature(MIN, MED, MAX, WINTER). FREEZER COMPARTMENT SHELF · Provided to make ice or to store frozen food.*

FREEZER COMPARTMENT POCKETS ANTI-MICROBE DEODORIZER · Anti-Microbe deodorizer, which is permanent and no need to replace or repair, gets rid of odor. · Use when storing dried fish, dumpling skin, red pepper powder bean, pizza, spices etc. @@BOTTLE POCKET · Storing big bottled drinks, juice, etc. @@@@Rollers are installed for easy drawing. FRONT COVER · Don't let the children step on it for it can be broken. 8 9 5. TEMPERATURE CONTROL TEMPERATURE CONTROL OF FREEZER COMPARTMENT 6. CARE & CLEANING Before Cleaning · When the outside(cabinet, doors) is stained with cooking oil or dirt, wipe it out quickly. ·prevent mold for 3~2 days development or odor saturation. 8.

Efficient Storage of Foods Be sure to wrap foods - fish, meat, etc. - to be stored in the freezer compartment to avoid odor. Keep foods clean ! s Be suWipe the packed foods, wash vegetables. Cool down to room temperature ! s If hot food is put in immediately, the temperature inside rises up, keeping foods fresh impossible, resulting in waste of electricity. Divide foods into one-time serving ! s Dividing food into one-time serving and storage makes it easy to take out, enhancing refrigerating power.

Frozed food can be thawed easily. divide! Wipe out Hot Food Wrap foods ! s Make sure to wrap foods such as Kimchi and fish in order to prevent drying and odor. Do not fill the inside up ! s Too much food will interfere with cold air circulation. Do not place watery food close to the cold air ducts. Open and shut doors quickly ! s Frequent opening and shutting doors causes loss of cold air, waste of electricity weakening of refrigerating power.

12 13 = NO FROST 3D COOLING REFRIGERATOR FR-530NT / FR-590NT Code: P441-1 14 .



[You're reading an excerpt. Click here to read official DAEWOO](#)

[FR-530NT user guide](#)

<http://yourpdfguides.com/dref/3408010>